

Service Manual Air-to-Water Heatpump





Indoor Unit WH-CME5

Outdoor Unit WH-WXG09ME5 WH-WXG12ME5

Destination Europe

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the products dealt with in this service information by anyone else could result in serious injury or death.

IMPORTANT SAFETY NOTICE =

There are special components used in this equipment which are important for safety. These parts are marked by ⚠ in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.

⚠ CAUTION

R290 REFRIGERANT

This AIR-TO-WATER HEATPUMP contains and operates with refrigerant R290.
THIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED BY QUALIFIED PERSONNEL
Refer to National, State, Territory and local legislation, regulations, codes, installation & operation manuals, before the installation, maintenance and/or service of this product.



TABLE OF CONTENTS

1. Safety Precautions4	14.10Base Pan Heater Control (Optional) 17
·	14.11Force Healer Mode17
2. Precautions for Use of R290 Refrigerant7	
3. Specifications12	14.13 Quiet Operation
	14.14 Sternization Wode
3.1 WH-CME5 WH-WXG09ME512	·
3.2 WH-CME5 WH-WXG12ME515	
4. Features18	14.16 Outdoor Ambient Thermo OFF Control 179
	14.17 Alternative Outdoor Ambient Sensor Control
5. Location of Controls and Components19	14.18 Force DHW Mode
5.1 Indoor Unit19	14.19SMART DHW Mode170
5.2 Outdoor Unit54	14.20 Anti Freeze Control
6. Dimensions55	
6. Diffierisions55	14.22 Boiler Bivalent Control
6.1 Indoor Unit55	14 23 External Room Thermostat Control (Optional)
6.2 Outdoor Unit56	18:
7. Refrigeration and Water Cycle Diagram57	44.0471 144 141 0 4 1
	14 25 Two Ways Valve Control 18
8. Block Diagram58	14.26 Anti-Stick Mode Operation 18
9. Wiring Connection Diagram59	44.075 / 1.055/01/0 / 1
	14.28 External Compressor Switch (Optional PCB).
9.1 Indoor Unit59	
9.2 Outdoor Unit60	14.29 Heat/Cool Switch (Optional PCB) 18
10. Electronic Circuit Diagram61	14.30 SG Ready Control (Optional PCB) 188
	14.31 Demand Control (Optional PCB) 190
10.1 Indoor Unit61	· · · · · · · · · · · · · · · · · · ·
10.2 Outdoor Unit62	Thooby control of the manner o
11. Printed Circuit Board63	14.34 Flow Sensor19
	45 Bustantian Control
11.1 Indoor Unit63	
11.2 Outdoor Unit65	
12. Installation Instruction68	15.2 Protection Control for Heating Operation
12.1 Indoor Unit69	194
	10.0 1 Total Control of Cooming Operation
12.2 Appendix	
12.4 Outdoor Unit111	4C Camilalian Mada
12.5 Appendix	
12.6 Service and Maintenance	
12.0 Service and Maintenance142	10.2 100(1(0))
13. Installation and Servicing Air-to-Water using	16.3 Expansion Vessel Pre Pressure Checking
R290143	16.4 How to Unlock Cool Mode
13.1 About R290 Refrigerant143	
13.2 Characteristics of R290 Refrigerant143	
13.3 Refrigerant piping installation • Tools used in	16.6 Dry Concrete Setup
services145	·
13.4 New installation, and Repairing of Refrigerant	17 Maintananaa Cuida 20°
Cycle System Procedures149	
13.5 Servicing150	
· ·	
14. Operation and Control152	18. Troubleshooting Guide20
14.1 Basic Function152	18.1 Refrigeration Cycle System 208
14.2 Water Pump163	18.2 Relationship Between the Condition of the
14.3 Extra Pump Function (Optional)166	
14.4 Indoor Unit Safety168	
14.5 Auto Restart Control168	
14.6 Indication Panel168	
14.7 External Heater Control (Optional)169	10.1 2.10.0000 100
14.8 Indoor Back-Up Heater Control169	
14.9 Tank Heater Control (Excluding when	
Operating in Standalone) 170	

19. Dis	assembly and Assembly Instructions.	274
	Indoor UnitOutdoor Unit	
20. Ted	chnical Data	279
20.2	Operation Characteristics	287
	oloded View and Replacement Parts Li	
	Indoor Unit	

1. Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before installation of Air-To-Water Heat Pump Indoor Unit.
- This AIR-TO-WATER HEAT PUMP INDOOR UNIT operates in combination with an outdoor unit containing refrigerant R290. This product and the outdoor unit must only be installed or serviced by qualified personnel. Refer to National, State, Territory and local legislation, regulations, codes, installation & operation manuals, before the installation, maintenance and/or service of these products.
- Electrical works and water installation works must be done by licensed electrician and licensed water system installer respectively. Be sure to use the correct rating and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation due to ignorance or negligence of the instructions may cause harm or damage, and the seriousness is classified by the following indications.

⚠ WARNING	This indication shows the possibility of causing death or serious injury.
⚠ CAUTION	This indication shows the possibility of causing injury or damage to properties only.

The items to be followed are classified by the symbols:

Symbols with white background indicate prohibited items.	
Symbols with dark background must be executed.	

- Carry out test run to confirm that no abnormality occurs after the installation. Then explain to the user how to operate, care and maintain the product as described in the operating instructions.
- This installation manual should be handed over with the unit after installation.
- Please remind the customer to keep the installation manual for future reference.
- If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.

	<u> </u> WARNING	
1.	Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. Any unfit method or using incompatible material may cause product damage, burst and serious injury.	0
2.	Do not install outdoor unit near balcony railings. If the outdoor unit is installed on the balcony of a high-rise building, small children may climb onto the outdoor unit and climb over the railing, which may lead to an accident.	0
3.	Do not use unspecified, modified, jointed or extension cable for power supply cable. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current may cause electrical shock or fire.	\Diamond
4.	Do not use unspecified cable or joint cable for power supply cable. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.	\Diamond
5.	Do not tie up the power supply cable into a bundle by band. Abnormal temperature rise on power supply cable may happen.	\Diamond
6.	Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury.	0
7.	Do not sit on or step on the unit, you may fall down accidentally.	0
8.	Do not purchase unauthorized electrical parts for installation, service, maintenance and etc They might cause electrical shock or fire.	0
9.	Do not modify wires of Outdoor Unit for installation of other components (such as heaters). Overloading of wires or wire connection points may cause electrical shock or fire.	\Diamond
10.	Do not pierce or burn as the appliance is pressurized. Do not expose the appliance to heat, flame, sparks, or other sources of ignition. Else, it may explode and cause injury or death.	0
11.	Do not pierce or burn as the appliance is pressurized. Do not expose the appliance to heat above 360°C, flame, sparks, or other sources of ignition. Else, it may explode and cause injury or death.	0
12.	Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc.	\Diamond
13.	Do not place containers of liquid on top of the indoor unit. Leakage or spillage of liquid into the indoor unit may cause damage to the indoor unit or cause a fire.	0
14.	Do not install the indoor unit where flammable gases may leak. If gas leaks and accumulates around the unit, it may cause a fire.	0
15.	Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth and prevent breathing. (Outdoor unit only)	0
16.	Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth and prevent breathing. (Indoor unit only)	0

	⚠ WARNING	
17.	Do not use joint cable for outdoor connection cable. For outdoor connections, use the specified outdoor connection cable. Refer to instruction "12.4.6 Connect the Cable to the Outdoor Unit" and connect tightly. Clamp the cable so that no external force will be acted on the terminal. If connection or fixing is not perfect, it will cause heat up or fire at the connection.	0
18.	Use the specified connection cables for the indoor unit and outdoor unit, and connect the indoor unit and outdoor unit securely, referring to "12.1.3 Connect the Cable to the Indoor Unit". Tighten the cable so that no external force is applied to the terminal. Incomplete connection or fixing may cause heat generation or ignition of the connection.	0
19.	For electrical work, follow the national regulation, legislation and this installation manual. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in the electrical work, it may cause electrical shock or fire.	0
20.	For electrical work, follow local wiring standards and regulations and this installation instructions. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in the electrical work, it will cause electrical shock or fire.	0
21.	For water circuit installation work, follow to relevant European and national regulations (including EN61770) and local plumbing and building regulation codes.	0
22.	Engage authorized dealer or specialist for installation. If installation done by the user is incorrect, it will cause electrical shock or fire.	0
23.	Engage authorized dealer or specialist for installation. If installation done by the user is incorrect, it will cause water leakage, electrical shock or fire.	0
24.	 The refrigerant cycle is completed inside the outdoor unit. No refrigerant pipework is required. Also, no pump-down operation is required. 	0
25.	For installation of refrigeration system, strictly follow this installation procedures. Incorrect installation may cause water leakage, which may lead to electrical shock or fire.	0
26.	Install at a strong and firm location which is able to withstand weight of the set. If the strength is not enough or installation is not properly done, the set will drop and cause injury.	0
27.	Comply with national wiring rules or country-specific safety measures in terms of residual current (Installing Residual Current Device (RCD) is strongly recommended).	0
28.	This equipment is strongly recommended to be installed with Residual Current Device (RCD) on-site according to the respective national wiring rules or country–specific safety measures in terms of residual current.	0
29.	Wiring must be properly routed to ensure that the control board cover is correctly secured. If the control board cover is not fully secured, it will cause fire or electrical shock.	0
30.	After installation is complete, make sure that there is no refrigerant gas leak. There is a risk of fire or explosion if the refrigerant contacts fire.	0
31.	If refrigerant gas leaks during operation, ventilate the room. Extinguish all sources of fire, if any. If the refrigerant contacts fire, there is a possibility of fire / explosion.	0
32.	Only use supplied or specified parts for installation. Other parts may cause the equipment to drop, vibrate, leak, catch fire or cause an electrical shock.	0
33.	Only use the supplied or specified installation parts. Else, it may cause unit vibrate, fall, water leakage, electrical shock, or fire.	0
34.	If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.	0
35.	When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.	0
36.	Any work carried out on the Indoor Unit after removing any panels which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.	0
37.	Any work carried out on the outdoor unit after removing any panels which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.	0
38.	All power circuits must be disconnected before accessing the unit terminals.	0
39.	This installation may be subjected to building regulation approval applicable to respective country that may require to notify the local authority before installation.	0
40.	Be aware that R290 Refrigerant is odourless and flammable.	0
41.	Ensure that all wiring polarity is correct. Otherwise, this may cause electrical shock or fire.	0
42.	This equipment must be properly earthed. Earth line must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electrical shock in case of equipment breakdown or insulation breakdown.	•
43.	This equipment must be properly earthed. Electrical earth must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electrical shock in case of insulation breakdown or earth fault of the outdoor unit.	•

	<u></u> CAUTION	
1.	Do not install the outdoor unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.	\Diamond
2.	Do not release refrigerant while repairing refrigeration components. Be careful of liquid refrigerants as it can cause frostbite.	\Diamond
3.	Do not install in humid areas such as laundry rooms. This may cause rust and damage to the unit.	\Diamond
4.	Make sure the insulation of power supply cable does not contact hot part (i.e. refrigerant piping) to prevent from insulation failure (melt).	0
5.	Do not touch the sharp aluminium fins. Sharp edges may cause injury.	\Diamond
6.	Do not apply excessive force to the water pipes as this may damage them. Water leaks may cause flooding and damage to other property.	\Diamond
7.	Prevent liquid or vapour from entering sumps or sewers since vapour is heavier than air and may form suffocating atmospheres.	0
8.	Ensure that the insulation of the power cable does not come into contact with hot areas (e.g. water pipes) to prevent insulation failure (melting) of the power cable.	0
9.	Select an installation location which is easy for maintenance. Incorrect installation, service or repair of this Indoor Unit may result in loss damage or injury and/or property.	0
10.	Select an installation location which is easy for maintenance. Incorrect installation, service or repair of this outdoor unit may increase the risk of rupture and this may result in loss, damage or injury and/or property.	0
11.	Connection of power supply to the Indoor Unit • Power supply point should be in easily accessible place for power disconnection in case of emergency. • Comply with local national wiring standard, regulation, and this installation manual. • It is strongly recommended to make permanent connection to a circuit breaker. - Power supply: use an approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0 mm.	0
12.	Power supply connection • Power supply point should be in easily accessible place for power disconnection in case of emergency. • Comply with local national wiring standard, regulation, and this installation instruction. • Strongly recommended to make permanent connection to a circuit breaker. - Power supply: Use approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0mm.	0
13.	Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire.	0
14.	Installation work. It may need two or more people to carry out the installation work. The weight of outdoor unit might cause injury if carried by one person.	0
15.	Ensure that the required ventilation openings are free from obstacles.	0
16.	Water piping in the occupied space should be installed in such a way as to prevent accidental damage during operation and service.	0
17.	Be careful not to subject the water piping to excessive vibration or pulsation.	0
18.	Protect water piping from accidental burst that may be caused by moving furniture or rebuilding activities.	0
19.	 The water piping should be routed to the shortest possible length. Avoid using dented pipes and avoid sharp bending. It must be ensured that water piping is protected from physical damage. 	0

2. Precautions for Use of R290 Refrigerant

• Pay close attention to the following points:

	<u> </u>	
1.	Mixing different types of refrigerants in the system is prohibited.	0
2.	Do not place any part of the refrigeration circuit (evaporator, air cooler, AHU, condenser, or liquid receiver) or pipework near heat source, naked flame, or gas appliance or electric heater in operation.	0
3.	Operation, maintenance, repair and recovery of refrigerants must be carried out by personnel trained and certified in the use of flammable refrigerants and in accordance with the manufacturer's recommendations. Personnel who operate, service or maintain the relevant parts of the system or equipment must be trained and certified.	0
4.	The user, owner or their authorised representative shall, where required by national regulations, regularly check alarms, mechanical ventilation, and detectors at least once a year to ensure they are functioning correctly.	0
5.	A logbook shall be maintained. The results of these checks shall be recorded in the logbook.	0
6.	In case of occupied space ventilation, it must be ensured that there are no obstacles.	0
7.	Before operating a new refrigeration system, the person responsible for operating the system must ensure that trained and certified operators are instructed in the construction, supervision, operation and maintenance of the refrigeration system, as well as the safety measures to be observed and the properties and handling of the refrigerants used in accordance with the operating manual.	0
8.	The general requirements for trained and certified personnel are as follows: a) Knowledge of legislation, regulations and standards relating to flammable refrigerants. b) Detailed knowledge and skills in handling flammable refrigerants, personal protective equipment, refrigerant leak prevention, cylinder handling, charging, leak detection, recovery, and disposal. c) Able to understand and apply in practice the requirements of national laws, regulations and standards. d) Continuously undergoing regular and further training to maintain the expertise.	9
9.	Ensure that protective devices, refrigeration circuits and accessories are adequately protected against adverse environmental effects (e.g. risk of water freezing in the relief pipe or accumulation of dirt and debris).	0

CAUTION

Installation

- Must comply with national gas regulations, state and local laws and regulations. Notify the relevant authorities in accordance with all applicable regulations.
- 1. It must be ensured that the mechanical connections are accessible for maintenance.
 - If mechanical ventilation is required, the ventilation openings must be kept free from obstacles.
 - For disposal of the product, follow the precautions in #12 and comply with national regulations.
 - Always contact your local municipal office for appropriate handling.

Servicing

2-1. Service personnel

- Qualified personnel engaged in work or entry into refrigerant circuits must have a valid qualification from an industry-recognised assessment body. This assessment body certifies the ability to safely handle refrigerants according to the industry-accepted assessment specifications.
- Maintenance should only be carried out in accordance with the equipment manufacturer's recommendations. Maintenance
 and repairs requiring the assistance of other skilled persons shall be carried out under the supervision of persons
 competent in the use of flammable refrigerants.
- Maintenance should only be carried out in accordance with the manufacturer's recommendations.
- The system is inspected, regularly supervised, and maintained by trained and certified service personnel employed by the user or responsible party.
- Make sure that the charged refrigerant do not leak.

2-2. Work procedures

- As the system contains flammable refrigerant, a safety inspection is required before commencing work on the system to
 ensure that the risk of ignition has been minimised. When repairing refrigeration unit, follow the precautions in 2-2 through
 2-8.
- To minimise the risk of flammable gas or vapour being present during the execution of the work, the work must be carried out under controlled procedures.
- All maintenance and other staff working on site shall be instructed and supervised as to the nature of the work being carried out.
- Avoid working in enclosed spaces. Always keep away from the source, and maintain a safety distance of at least 2 metres
 or perform zoning of open space areas of at least a 2-metre radius.
- Wear suitable protective equipment, including respiratory protection, depending on the situation.
- Keep ignition sources and hot metal surfaces away.
- 2-3. Checking for presence of refrigerant
- The area should be checked with a suitable refrigerant detector before and during the work to ensure that the technician is aware of potential flammable atmosphere.
- Ensure that the leak detection device used is suitable for use with flammable refrigerants, i.e. that it is not producing sparks, properly sealed or intrinsically safe.
- If a leak/spill occurs, ventilate the area immediately and stay upwind and away from the leak/spill.
- In the event of a leak/spill, notify persons downwind of the leak/spill, isolate the imminent danger area and ensure that unauthorised persons do not enter the area.
- 2-4. Availability of fire extinguishers
- When performing high-temperature work on refrigeration unit or related components, suitable fire extinguishing equipment must be prepared at hand.
- Provide a powder fire extinguisher or CO₂ extinguisher near the charging area.
- 2-5. No ignition sources

2.

- Personnel carrying out work related to refrigeration systems must not use ignition sources in such a way as to create a fire
 or explosion hazard. Smoking is not allowed when carrying out such work.
- All possible ignition sources, including cigarette smoking, must be kept well away from the site of installation, repair or removal. While performing such works, flammable refrigerants may be released into the surrounding space.
- Before carrying out any work, check the surroundings of the equipment to ensure that there are no flammability and/or
 ignition hazards.
- "No Smoking" signs must be displayed.
- 2-6. Well-ventilated areas
- Before work into refrigerant circuit or working with fire, ensure that the area is outdoor or adequately ventilated.
- Some degree of ventilation shall be maintained while the work is being carried out.
- Ventilation must safely disperse the released refrigerant, preferably to the outside atmosphere.
- 2-7. Checking refrigeration equipment
- In case of change of electrical components, the changed components must be fit for the purpose and to the correct specification.
- Always follow the manufacturer's maintenance and service guidelines.
- If there is any doubt, contact the manufacturer's technical department.
- The following checks must be applied to equipment using flammable refrigerants:
 - Ventilators and exhaust vents are in good working order and free from obstacles.
 - If an indirect refrigeration circuit is used, the presence of refrigerant in the secondary circuit should be checked.
 - Keep equipment markings remain visible and legible. Any illegible signs or markings should be corrected.
 - Refrigeration piping and components are installed in a position where they are less exposed to substances that may corrode the refrigerant, unless the components are made of inherently corrosion-resistant materials or are adequately protected against corrosion.



0

(CAUTION

2-8. Checking electrical equipment

- · Repair and maintenance of electrical components must include initial safety checks and component inspection procedures.
- Initial safety checks must include, but are not limited to:
 - Capacitor has been discharged: This check must be carried out in a safe manner to avoid the possibility of sparks.
 - No live electrical components or wiring are exposed during charging, recovery or purging of the system.
 - Earth connection is continuous.
- 2. Always follow the manufacturer's maintenance and service guidelines.
 - If there is any doubt, contact the manufacturer's technical department.
 - If a fault exists that could compromise safety, power supply must not be connected to the circuit until the problem has been
 resolved.
 - If the fault cannot be corrected immediately but the operation needs to continue, a suitable temporary solution should be used.
 - Then, the owner of the equipment must be notified or reported so that all parties are subsequently informed.

Repairing sealed components

- During repair of sealed components, all power supply must be disconnected from the equipment being worked on before removing sealed covers, etc.
- If it is absolutely necessary to supply power to equipment during servicing, a permanently operating form of leak detection should be located at the most critical points to warn of potentially hazardous situations.
- Particular attention must be paid to the following points to ensure that work on electrical components does not alter the
 casing in such a way as to affect the level of protection: These include damaged cables, excessive numbers of
 connections, terminals that differ from the original specifications, damaged seals and improperly fitted glands.
- Ensure that the equipment is securely fitted.
 - Ensure that seals and sealing materials have not deteriorated to such an extent that they no longer serve the purpose of
 preventing the ingress of flammable atmosphere.
 - Replacement parts shall be in accordance with the manufacturer's specifications.

Note: Use of silicone sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe explosion-proof components do not need to be isolated before work.

Repairing intrinsically safe components

- Do not apply any permanent inductive or capacitive loads to the circuit without ensuring that this will not exceed the
 permissible voltage and current for the equipment in use.
- 4. Intrinsically safe components are the only type that can work in the presence of a flammable atmosphere.
 - The test equipment must be at the correct rating.
 - Replace components only with parts specified by the manufacturer. Use of parts not specified by the manufacturer may result in refrigerant leakage and ignition of the refrigerant in the atmosphere.

Cabling

3.

- Ensure that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or other adverse environmental effects.
 - The checks should also take into account the effects of ageing and continuous vibration from sources such as compressors and fans.

Detection of flammable refrigerants.

- 6. Under no circumstances should potential ignition sources be used to search for or detect refrigerant leaks.
 - Do not use halide torches (or other detectors that use naked flames).

The following leak detection methods are considered acceptable for all refrigerant systems

- No leakage shall be detected if a detection device with a sensitivity of 5 grams or more of refrigerant per year is used under a pressure of at least 0.25 times the maximum permissible pressure (>0.98 MPa, max 3.90 MPa). An example is universal sniffer.
- Electronic leak detectors can be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need recalibration.
- (Calibration of the detector should be carried out in an area free from refrigerant.)
- 7. Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
 - Leak detection device must be set to a percentage of the LFL of the refrigerant, calibrated to the refrigerant used, and the appropriate percentage of gas (up to 25%) is confirmed.
 - Leak detection fluids are also suitable for use with most refrigerants, including bubble and fluorescent agents. Avoid using detergents containing chlorine, as chlorine may react with refrigerants and corrode copper tubes.
 - If a leak is suspected, all ignition sources must be removed or extinguished.
 - If a refrigerant leak which requires brazing is found, all refrigerant must be recovered from the system. To remove the refrigerant, precautions #8 must be followed.











(CAUTION

Removal and evacuation

- Conventional procedures shall be used when working into the refrigerant circuit for repair or for any other purpose.
 However, it is important to follow best practice since flammability is a consideration. The following procedures must be followed:
 - Remove refrigerant → Purge the circuit with inert gas → Create vacuum → Purge with inert gas →
 - · Open the circuit by cutting.

Do not use brazing.

8

9.

10.

11.

- The charged refrigerant shall be recovered in the correct recovery cylinder.
- The system must be purged with OFN to secure the appliance safe. (Remarks: OFN = oxygen-free nitrogen, a type of inert gas)



A

- This process may need to be repeated several times.
- Do not use compressed air or oxygen for this task.
- Purging must be achieved by breaking the vacuum in the system with OFN, continuing to fill until the working pressure is
 reached, then venting to atmosphere, and finally reducing the pressure to vacuum.
- This process must be repeated until there is no refrigerant in the system. (until the purge gas concentration detected by the leak detector is below 0.25 LFL) * 0.25 LFL = 0.525 Vol%
- When the final OFN charge is used, the system must be vented to atmospheric pressure to allow work to be carried out.
- This operation is absolutely essential when brazing pipes.
- Ensure that the outlet of the vacuum pump is not near an ignition source and that ventilation is available.

Charging procedures

- In addition to conventional charging procedures, the following requirements must be followed:
 - When charging equipment is used, ensure that contamination of different refrigerants does not occur.
 - Hoses and lines should be as short as possible to minimise the amount of refrigerant contained in them.
 - Cylinders must be stored in the appropriate position according to instructions.
 - Ensure that the refrigeration system is earthed before charging refrigerant into the system.
 - Label the system. once the charging is complete. (if not yet completed)
 - Extreme care must be taken not to overfill the cooling system.
- Before refilling the system, a pressure test must be carried out with OFN. (See #8)
- The system must be leak tested after completion of charging and before commissioning.
- A follow-up leak test must be carried out before leaving the site.
- Static build-up may occur while charging and purging refrigerant and it can cause hazardous conditions. To avoid fire
 and/or explosion, earth the containers and equipment before charging/releasing to dissipate static electricity during
 transport.

Decommissioning

- Before carrying out this procedure, it is important that the technician is familiar with the equipment and all its details.
- It is recommended to recover all refrigerants safely.
- Reuse of recovered refrigerants is prohibited.
- It is important that electrical power is available before commencing the work.
 - a) Become familiar with the equipment and its operation.
 - b) Electrically isolate the system.
 - c) Before carrying out the procedure, ensure that:
 - If required, mechanical handling equipment can be used for handling refrigerant cylinders.
 - All personal protective equipment and leak detectors are available and used correctly.
 - The recovery process is always supervised by a competent person.
 - · Recovery devices and cylinders comply with appropriate standards.
 - d) Make sure that the cylinder is placed on the scale before commencing recovery.
 - e) Start the recovery machine and operate it according to the instructions.
 - f) Do not overfill the cylinder. (No more than 80 % volume liquid charge)
 - g) Do not exceed the maximum working pressure of the cylinder, even temporarily.
 - h) Once the cylinder has been correctly filled and the process completed, ensure that the cylinder and equipment are promptly removed from the site and that all shut-off valves on the equipment are closed.
- Static build-up may occur while charging and purging refrigerant and it can cause hazardous conditions. To avoid fire and explosion, earth the containers and equipment before charging/releasing to dissipate static electricity during transport.

Labelling

- The equipment shall be labelled to indicate that it has been decommissioned and empty of refrigerant.
- Labels shall be dated and signed.

 Ensure that a lobel is attached to the aguinment indicating that to
- Ensure that a label is attached to the equipment indicating that the equipment contains flammable refrigerants.

0

(CAUTION

Recovery

- When removing refrigerant from a system for maintenance or decommissioning, it is recommended to remove all refrigerant safely.
- · When transferring refrigerant into cylinders, always use only suitable refrigerant recovery cylinders.
- Ensure that the correct number of cylinders are available to accommodate the total charge of the system.
- All cylinders used are designated for recovered refrigerants and labelled for that refrigerant. (i.e. special cylinders for recovery of refrigerant)
- · The cylinder must be equipped with a pressure relief valve and associated shut-off valve in good working order.
- Before recovery is commenced, the recovery cylinder is vented and, if possible, cooled.
- Recovery equipment must have a set of instructions on the equipment at hand, be in good working order and be suitable
 for the recovery of flammable refrigerants.
- Ensure that the recovery equipment is not a potential source of ignition and is suitable for the refrigerant being used.
- 12. In addition, a set of calibrated scales must be available and in good working order.
 - Hoses must be in good condition with leak-free disconnect couplings.
 - Before using the recovery machine, make sure that it is fully operational and properly maintained, and that relevant electrical components are sealed to prevent ignition in the event of a refrigerant release. If there is any doubt, contact the manufacturer.
 - The recovered refrigerant should be returned to the refrigerant supplier in a suitable recovery cylinder and the relevant waste transfer note should be prepared.
 - Do not mix refrigerants in the recovery unit, especially in the cylinder.
 - When removing compressor or compressor oil, ensure that it is exhausted to an acceptable level so that no flammable refrigerant remains in the lubricant.
 - The exhaust process must be carried out before the compressor is returned to the supplier.
 - To facilitate this process, only electrical heating to the compressor body is used.
 - Any draining of oil from the system must be carried out safely.

3. Specifications

3.1 WH-CME5 WH-WXG09ME5

	Item	Unit		Outdo	or Unit	
Performance Test Condition		1	EN 14511 / EN 14825			5
		Condition (Ambient/Water)		A35	5W7	
Cooling Capaci	ty	kW	9.00			
		BTU/h	30700			
Cooling EER		W/W		3.6	61	
		Condition (Ambient/Water)	A7W35 A2W3		A2W35	
Heating Capaci	ity	kW	9.00			9.00
		BTU/h	30700			30700
Heating COP		W/W	5.23			3.81
	Low Temperature Application (V	V35)	10/2	A		Caldan
	Application	Climate	Warmer	Aver	rage	Colder
	Pdesign	kW	9.0	9.	.0	9.0
	Tbivalent / TOL	°C	2/2	-10 /	′ - 10	-22 / -22
	SCOP / ns	(W/W) / %	6.33 / 250	5.00	/ 197	4.45 / 175
	Annual Consumption	kWh	1901	37.	21	4990
Haatina ErD	Class		A+++	A+	++	A+++
Heating ErP	Medium Temperature Applicatio	n (W55)	Marmor	A		Coldor
	Application	Climate	Warmer	Average		Colder
	Pdesign	kW	9.0	9.	.0	9.0
	Tbivalent / TOL	°C	2/2	-10 /	′ - 10	-22 / -22
	SCOP / ns	(W/W) / %	4.40 / 173	3.50	/ 137	3.20 / 125
	Annual Consumption	kWh	2735	5318 69		6939
	Class		A+++	A+	++	A++
		dB (A) ***	Cooling: -	Cooling: - Heating: -		Heating: -
Noise Level		Power Level dB ****	Cooling: 60	0		Heating: 58
		dB *****	-			Heating: 52
Air Flow		m³/min (ft³/min)		Cooling: 9 Heating: 8		
Refrigeration C	ontrol Device			Expansion	on Valve	
Refrigeration O	il	cm ³		PZ68S	(1600)	
Refrigerant (R2	90) Precharge / Maximum	kg (oz)		1.78 (62	2.8) / (-)	
T CAS	GWP		3			
F-GAS	CO₂eq (ton) (Precharg	ged / Maximum)		0.006	6 / (-)	
	Height	mm (inch)		1520 (59	9-27/32)	
Dimension	Width	mm (inch)	1200 (47-1/4)			
Depth		mm (inch)		430 (16	-15/16)	
Net Weight		kg (lbs)		160 ((353)	
Water Piping O	/D Outdoor Water Pipe Connector	mm (inch)	31.75 (1-1/4)			
	Туре		Hermetic N	Notor Compi	ressor (Inv	volute Scroll)
Compressor	Motor Type		Synchronous Electric Motor (6-poles)			(6-poles)
	Rated Output	kW	3.10			

lt	em	Unit		Outdoor Unit			
Туре			Propeller Fan				
	Material			PP			
	Motor Type			DC (8-poles)			
Fan	Input Power	W		-			
	Output Power	W	120 × 2				
	Fan Speed	rpm		Cooling: 510 Heating: 450			
	Fin material			Aluminium (Blue Coat)	1		
	Fin Type			Corrugated Fin			
Heat Exchanger	Row × Stage × FPI			2 × 58 × 19			
	Size (W × H × L)	mm	44	× 1473.2 × 868.2:902	1.7		
	Туре			Braze Plate			
	No. of Plates			36			
Hot Water Coil	Size (W × H × L)	mm		76.2 × 524 × 117			
	Water Flow Rate	l/min (m³/h)		Cooling: 25.8 (1.5) Heating: 25.8 (1.5)			
	Motor Type		Brushless DC M	otor (Sensorless vecto	r control system)		
Pump	No. of Speed			Variable speed	, ,		
•	Input Power	W		175			
	Туре		Vor	tex (Piezoelectric sens	sor)		
Flow Sensor	Measuring range	l/min		5 ~ 60	,		
	0 0	Ø		Single			
Power Source (Phase, Vol	tage, Cycle)	V	230				
,		Hz	50				
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35		
mpat r ower		kW	Cooling: 2.49	Heating: 1.72	Heating: 2.36		
Maximum Input Power For	Heatpump System	kW	6.60				
Outdoor Power Supply : Pl	nase (Ø) / Max. Current (A) /	Max. Input Power (W)		1Ø / 29.0 / 6.60k			
Indoor Power Supply : Pha	ise (Ø) / Max. Current (A) / M	lax. Input Power (W)	1Ø / 14.9 / 3.50k				
Power Supply 3 : Phase (@	Ø) / Max. Current (A) / Max. Ir	nput Power (W)	-/-/-				
Starting Current		А		10.9			
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35		
· ····································		А	Cooling: 10.9	Heating: 7.6	Heating: 10.5		
Maximum Current For Hea	tpump System	Α		29.0			
Power Factor Power factor means total fi outdoor fan motor.	gure of compressor and	%			Heating: 98		
Dower Cord	Number of core			-			
Power Cord	Length	m (ft)		-			
Thermostat				Electronic Control			
Protection Device			Electronic Control				
Pressure Relief Valve Water Circuit		kPa	Open: 400, Close: 280 or higher				
	Outdoor Ambient	°C (min. / max.)	Cooling: 10 / 43 Heating (Circuit): -28 / 35				
Operation Range	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating (Circuit): 25 / 55 (Below Ambient -25°C) *4 Heating (Circuit): 25 / 75 (Above Ambient -15°C) *4				
Internal Pressure Differential kPa			Cooling: 13.0 Heating: 13.0				

Item		Unit	Indoor Unit		
Performance Test Condition			EN 14511 /	EN 14825	
Noise Level		dB (A)	Cooling: 22***	Heating: 22***	
		Power Level dB	Cooling: 35****	Heating: 35****	
	Height	mm (inch)	454		
Dimension	Width	mm (inch)	52	0	
Depth		mm (inch)	116		
Net Weight		kg (lbs)	7 (15)		

Note:

- In case it is necessary to indicate the air flow volume in (I/s), the value in (m³/min.) shall be multiplied by 16.7 and rounded down the decimal point.
- If the EUROVENT Certified models can be operated under the "extra-low" temperature condition, -7°C DB and -8°C WB temperature with rated voltage 230V shall be used.
- Capacity is measured at outdoor temperature 7°C DB and 6°C WB with controlled water inlet 30°C and water outlet 35°C (EN 14511-2)
- Flowrate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and ΔT=5°C.
- *** The sound pressure level is measured with distance 1.0m from the unit and height at 1.5m. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- ***** The sound power level is measured with accordance to EN12102 under conditions of the EN14825. (Test carry out for heating at ambient 7°C DB / 6°C WB and water out 55°C)
- EER and COP classification is at 230V only in accordance with EU directive 2003/32/EC.
- **** The sound power level is measured with accordance to EN12102 under full load conditions. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- *4 Between outdoor ambient -15°C and -25°C, the water outlet temperature gradually decreases from 75°C to 55°C.

3.2 WH-CME5 WH-WXG12ME5

Item Unit			Outdoor Unit				
Performance Test Condition		·	EN 14511 / EN 14825				
		Condition (Ambient/Water)		A35	5W7		
Cooling Capac	ty	kW	9.00				
		BTU/h	30700				
Cooling EER		W/W		3.	61		
		Condition (Ambient/Water)	A7W35		A2W35		
Heating Capac	ity	kW	12.00			12.00	
		BTU/h	40900			40900	
Heating COP		W/W	5.06			3.54	
	Low Temperature Application (W35)	Warmar	۸۷۵	rago	Coldor	
Heating ErP	Application	Climate	Warmer	Ave	aye 	Colder	
	Pdesign	kW	12.0	12	2.0	12.0	
	Tbivalent / TOL	°C	2/2	-10	/ -10	-22 / -22	
	SCOP / ns	(W/W) / %	6.20 / 245	4.73	/ 186	4.38 / 172	
	Annual Consumption	kWh	2586	52	44	6758	
	Class		A+++	A+	++	A++	
	Medium Temperature Applicati	on (W55)	Warmer	Average		Colder	
	Application	Climate	vvaimei	Average		Coldel	
	Pdesign	kW	12.0	12	2.0	10.0	
	Tbivalent / TOL	°C	2/2	-10 / -10		-22 / -22	
	SCOP / ns	(W/W) / %	4.40 / 173	3.65 / 143 3.30 /		3.30 / 129	
	Annual Consumption	kWh	3647	67	92	7459	
	Class		A+++	A·	++	A++	
		dB (A) ***	Cooling: -			Heating: -	
Noise Level		Power Level dB ****	Cooling: 60)		Heating: 59	
		dB ****	-			Heating: 53	
Air Flow		m³/min (ft³/min)		Cooling: 9 Heating: 9			
Refrigeration C	ontrol Device			Expansi	on Valve		
Refrigeration C	il	cm ³		PZ68S	(1600)		
Refrigerant (R2	90) Precharge / Maximum	kg (oz)		1.78 (6	2.8) / (-)		
F.CAC	GWP			;	3		
F-GAS	CO ₂ eq (ton) (Prechai	rged / Maximum)		0.00	6 / (-)		
	Height	mm (inch)		1520 (5	9-27/32)		
Dimension	Width	mm (inch)		1200 (47-1/4)		
Depth		mm (inch)	430 (16-15/16)				
Net Weight		kg (lbs)		160	(353)		
Water Piping C	Outdoor Water Pipe Connector	mm (inch)	31.75 (1-1/4)				
Туре			Hermetic N	Notor Comp	ressor (Inv	olute Scroll)	
Compressor	Motor Type		Synchr	onous Elec	tric Motor (6-poles)	
	Rated Output	kW		3.	10		

It	em	Unit		Outdoor Unit	
	Туре		Propeller Fan		
	Material			PP	
	Motor Type			DC (8-poles)	
Fan	Input Power	W		-	
	Output Power	W	120 × 2		
	Fan Speed	rpm		Cooling: 510 Heating: 420	
	Fin material			Aluminium (Blue Coat)	
Heat Evebonger	Fin Type			Corrugated Fin	
Heat Exchanger	Row × Stage × FPI			2 × 58 × 19	
	Size (W × H × L)	mm	44	× 1473.2 × 868.2:902	.7
	Туре			Braze Plate	
	No. of Plates			36	
Hot Water Coil	Size (W × H × L)	mm		76.2 × 524 × 117	
	Water Flow Rate	l/min (m³/h)		Cooling: 25.8 (1.5) Heating: 34.4 (2.1)	
	Motor Type		Brushless DC M	otor (Sensorless vecto	r control system)
Pump	No. of Speed			Variable speed	
	Input Power	W		175	
Flow Sensor	Туре		Voi	tex (Piezoelectric sens	sor)
Flow Selisoi	Measuring range	l/min		5 ~ 60	
		Ø		Single	
Power Source (Phase, Vol	tage, Cycle)	V	230		
		Hz	50		
Input Power		Condition (Ambient/Water)	A35W7	A7W35	A2W35
		kW	Cooling: 2.49	Heating: 2.37	Heating: 3.39
Maximum Input Power For	Heatpump System	kW	6.60		
Outdoor Power Supply : Pl	nase (Ø) / Max. Current (A) /	Max. Input Power (W)	1Ø / 29.0 / 6.60k		
Indoor Power Supply : Pha	se (Ø) / Max. Current (A) / M	lax. Input Power (W)	1Ø / 14.9 / 3.50k		
) / Max. Current (A) / Max. Ir	nput Power (W)	-1-1-		
Starting Current		A		10.9	
Running Current		Condition (Ambient/Water)	A35W7	A7W35	A2W35
		Α	Cooling: 10.9	Heating: 10.4	Heating: 15.0
Maximum Current For Hea	tpump System	A		29.0	
Power Factor Power factor means total fi outdoor fan motor.	gure of compressor and	%	Cooling: 99	Heating: 99	Heating: 98
Power Cord	Number of core			-	
Power Cord	Length	m (ft)		-	
Thermostat				Electronic Control	
Protection Device			Electronic Control		
Pressure Relief Valve Water Circuit		kPa	Oper	Open: 400, Close: 280 or higher	
	Outdoor Ambient	°C (min. / max.)	Н	Cooling: 10 / 43 leating (Circuit): -28 / 3	5
Operation Range	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating (Circuit): 25 / 55 (Below Ambient -25°C) *4 Heating (Circuit): 25 / 75 (Above Ambient -15°C) *4		
Internal Pressure Different	ial	kPa	Cooling: 13.0 Heating: 24.0		

Item		Unit	Indoor Unit	
Performance Test Condition			EN 14511 /	EN 14825
Noise Level		dB (A)	Cooling: 22***	Heating: 22***
		Power Level dB	Cooling: 35****	Heating: 35****
	Height	mm (inch)	454	
Dimension	Width	mm (inch)	520	
	Depth	mm (inch)	116	
Net Weight		kg (lbs)	7 (15)	

Note:

- In case it is necessary to indicate the air flow volume in (I/s), the value in (m³/min.) shall be multiplied by 16.7 and rounded down the decimal point.
- If the EUROVENT Certified models can be operated under the "extra-low" temperature condition, -7°C DB and -8°C WB temperature with rated voltage 230V shall be used.
- Capacity is measured at outdoor temperature 7°C DB and 6°C WB with controlled water inlet 30°C and water outlet 35°C (EN 14511-2)
- Flowrate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and ΔT=5°C.
- *** The sound pressure level is measured with distance 1.0m from the unit and height at 1.5m. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- ***** The sound power level is measured with accordance to EN12102 under conditions of the EN14825. (Test carry out for heating at ambient 7°C DB / 6°C WB and water out 55°C)
- EER and COP classification is at 230V only in accordance with EU directive 2003/32/EC.
- **** The sound power level is measured with accordance to EN12102 under full load conditions. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- *4 Between outdoor ambient -15°C and -25°C, the water outlet temperature gradually decreases from 75°C to 55°C.

4. Features

- Inverter Technology
 - o Energy saving
- High Efficiency

A-class energy efficiency pump

- o Water pump speed can be set by selection at control panel
- Improved deice cycle

Protection Feature

- o Random auto restart after power failure for safety restart operation
- o Gas leakage protection
- o Prevent compressor reverse cycle
- o Inner protector to protect compressor

Serviceability Feature

- Breakdown Self Diagnosis function
- o System Status Check Buttons for servicing purpose
- o Front maintenance design for outdoor unit

5. Location of Controls and Components


5.1 Indoor Unit

5.1.1 Remote Controller Buttons and Display

(B) (C) (D) The LCD display as shown in this manual are for instructional purpose only, and may differ from the actual unit. **Buttons / Indicator** 雪雪水量三氢單新僵<u>面</u> 10:34am,Mon (H) **Quick Menu button ** (E) **Back button** (A) 40°c Returns to the previous screen (3) **LCD Display** 18°c (Actual - Dark background with white icons) $^{\circ}$ Main Menu button 2 For function setup (4) **ON/OFF** button Starts/Stops operation Operation indicator (6) Illuminates during operation, blinks during (1)(5) 6 When the backlight is off, press any button to turn (Do not press button (5)) The time until the backlight turns off can be changed **Cross key buttons** in the Menu (Personal setup) Selects an item. Up Press centre Left Right Down **Enter button** No glove Fixes the selected content. No pen

Display

(A) Mode selection



Operation icons

The status of operation is displayed.

Icon will not display (under operation OFF screen) whenever operation is OFF except weekly timer.



Holiday operation status



Weekly Timer operation status



Quiet operation status



Zone:Room Thermostat →Internal sensor status



Powerful operation status



Demand Control or SG ready or SHP status



Bivalent status

Room Heater status



Tank Heater status



Solar status



(Boiler) Temperature of each zone

The zone 2 will shown in LCD display if is connected with Optional PCB

- (D) Time and day
- Water Tank temperature (with electric anode operation icon)
- **Outdoor temperature**
- Sensor type/Set temperature type icons



Water Temperature →Compensation curve



Water Temperature →Direct



Pool only



Room Thermostat

→External



Room Thermostat →Internal



Room Thermistor

(H) Water pressure (bar)

*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners. *2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

*3 Only displayed when Tank connection is Yes.

5.1.2 Initialization

Before starting to install the various menu settings, please initiate the Remote Controller by selecting the language of operation and installing the date and time correctly.

When power is turned on for the first time, it becomes the setting screen automatically. It can also be set from personal setting of the menu.

Selecting the language

Wait while the display is initializing. When initializing screen ends, it turns to normal screen.

When any button is pressed, language setting screen appears.

- Scroll with \(\sqrt{} \) and \(\sqrt{} \) to select the language.

Setting the clock

- Select with

 ✓ or

 how to display the time, either 24h or am/pm format (for example, 15:00 or 3:00pm).
- 2 Press to confirm the selection.
- Once the time is set, time and day will appear on the display even if the Remote Controller is turned OFF.


Checking the front grilles


Final precaution step to check and confirm whether outdoor front grille is fixed before operating the unit for safety purpose.


Select Yes if outdoor front grille is already fixed. Then it will proceed to main screen.

Select No if outdoor front grille is not yet fixed. A caution message will pop up to remind on the installation.

*The display will not appear once you set it.









5.1.3 Quick Menu

After the initial settings have been completed, you can select a quick menu from the following options and edit the setting.





To return to the Main Screen,

Press or .

^{*1} Only displayed when Tank connection is Yes.

^{*2} It is not displayed when the outdoor unit is used alone. When the indoor unit has the heater, it is displayed even if set not to operate the heater.

5.1.4 How to Use the Quick Menu



Select this icon to turn the Tank DHW on or off.

Press do confirm your selection.



Note:


- Force DHW is disabled when Force Heater is turned on.
- When Force DHW is turned off, operation & mode should change back to the previous memorized status.

Powerful

Select this icon to operate the heating system powerfully.

Press do confirm your selection.

(The powerful operation starts approximately 1 minute after is pressed.)



Note:


• Powerful is disabled when operation is turned OFF.


小人 Quiet

Select this icon to operate quietly.

Press 🔟 to confirm your selection.

(The quiet operation starts approximately 1 minute after is pressed.)






≨ Force Heater

Select to force the Heater on.

Press 🖊 to confirm your selection.

(The Force Heater mode starts approximately 1 minute after $\begin{tabular}{c} \end{tabular}$ is pressed.)



Note:

- Force Heater is disabled whenever operation is already on and "Disabled due to operation ON!" will be displayed.
- It is not displayed when the outdoor unit is used alone, and when the heater is set to OFF even if the indoor unit is connected.


Disabled due to operation ON!


[⊅]Close

Weekly Timer

Select this icon to delete (cancel) or change the pre-set Weekly Timer.

Press do confirm your selection.





Note:

- Timer is disabled when Force Heater is turned on or Heat-Cool SW is enabled.
- If you have preset the Weekly Timer on 2 zones, you must repeat the same procedure with Zone 2.

/常 Force Defrost

Select to defrost the frozen pipes.

Press 🔟 to confirm your selection.

(When the mode is accepted, below screen will be displayed.)

Request accepted!

[⊅]Close

* Error Reset

Select to restore the previous settings when error has occurred.


Press do confirm your selection.

(When the mode has been accepted, below screen will be displayed.)

Request accepted!

[⊅]Close

• Make sure all units are turned off before selecting this mode which restores the whole system to the previous settings.



Select to lock the Remote Controller.

(When the mode has been accepted, below screen will be displayed.)

Do you want to lock remote control?

Yes

Select "Yes".

(The Main Screen will be locked.)

• If "No" is selected, the screen will return to the Main Screen.

To unlock the Remote Controller

Press anv kev.

(When the mode has been accepted, below screen will be displayed.)




Enter any 4 digits of number (if the number is correct, the screen will be unlocked).

To reset forgotten password (under operation OFF screen)

Press \supset , \longrightarrow and \searrow continuously for 5 seconds.

(When the mode has been accepted, below screen will be displayed.)



Select "Reset".

1.Password is reset to 0000 2.Remote control is unlocked

(The screen will be off after 3 seconds.)


5.1.5 Menus (For User)

Select menus and determine settings according to the system available in the household. All initial settings must be done by an authorised dealer or a specialist. It is recommended that all alterations of the initial settings are also done by an authorised dealer or a specialist.

- After initial installation, you may manually adjust the settings.
- The initial setting remains active until the user changes it.
- The Remote Controller can be used for multiple installations.
- Ensure the operation indicator is OFF before setting.
- The system may not work properly if set wrongly. Please consult an authorised dealer/specialist.

To display <Main Menu>: \equiv To select menu: $\land \lor < \gt$

To confirm the selected content:



Menu	Default Setting	Setting Options / Display		
1 Function setup				
1.1 > Weekly timer				
Once the weekly timer is set up, User can edit from Quick Menu. To set up to 6 patterns of operation on a daily basis.	set the patte	Select day of the week and set the patterns needed ime / Operation ON/OFF / Mode) 1.		10:34am, Mon d Thu Fri Sat 40°C
Disabled if Heat-Cool SW is select "Yes" or if Force Heater is on.	Timer copy Select day	of the week		€ 12/10°C
1.2 > Holiday timer	,			
To save energy, a holiday period may be set to either turn	OFF		ON OFF	
OFF the system or lower the	> ON			
temperature during the period.	Date a	art and end. nd time		10:34am,Mon Hour : Min
Weekly timer setting may be tem		ed temperature Holiday timer setting	2024 / 01 / 01	10 : 34 am
but it will be restored once the H			\$→ Select	[₊-]Confirm
1.3 > Quiet timer				
To operate quietly during the preset period.		art Quiet : nd time	Quiet Pattern Tir	10:34am, Mon ne Level 0am 0
6 patterns may be set. Level 0 means the mode is off.		quietness: ~ 3	2 5:0 3 11:0	0pm 1 0pm 3 Edit

Me	nu	Default Setting	Setting Options / Display
1.4	> Quiet priority		
	 To select priority during Quiet mode between Sound and Capacity. If Sound priority is selected, unit will operate in quiet condition only. If Capacity priority is selected, unit will operate in quiet condition but it will prioritize on providing required capacity at the same time. 	Sound	Sound V Capacity
1.5	> *1 Room heater		
	To set the room heater ON or OFF.	OFF	ON OFF
1.6	> *2 Tank heater		
	To set the tank heater ON or OFF.	OFF	ON OFF
1.7	> *2 Sterilization		
	To set the auto sterilization ON or OFF.	ON	ON OFF
			rent scalding with hot water, or overheating of shower. I of sterilization function field settings according to the local
1.8	> *3 DHW mode (Domestic Hot	Water)	
	To set the DHW mode to Standard or Smart. • Standard mode have faster DHW Tank heat up time. Meanwhile Smart mode take longer time to heat up DHW time with lower energy consumption.	Standard	Standard — Smart
	To set the tank sensor to Top or Center. • Selection of the tank sensor to top slow down the start of boiling up the tank and reduce power consumption. Please change this selection to "Center" when the hot water becomes insufficient.	Тор	Top ————————————————————————————————————

^{*1} It is not displayed when the outdoor unit is used alone or depending on the settings.
*2 Only displayed when Tank connection is Yes.
*3 Only displayed when connect Panasonic AIR-TO-WATER HYDROMODULE+TANK.

| Sim : 0h | Sim : 0h

pump's internal calculation.

If [Approx.] is NOT shown on Energy Monitor display, data** displayed on the remote controller is obtained by External Meters.

Select and retrieve

Select and retrieve

Data stored on the Aguarea unit can be mixed between internal calculation and External Meters.

**In order to know the exact consumption or generation, please use as reference always the External Meters' data.

Compressor

[⊅]Back

Heater

₹

1. Current frequency:

2. (OFF-ON) counter

3. Total ON time

Total ON time

10:34am, Mon

10:34am, Mon

0h

0 Hz

o

0 h

- *1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
- *2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).
- *3 The items displayed differ depending on the Appliance and connected units.
- The items displayed differ depending on the Appliance and confin
- *4 It is not displayed when the outdoor unit is used alone.
- *5 Only displayed when Tank connection is Yes.

2.4 > Compressor

performance.

2.5 > Heater

Shows the compressor

Total hours of ON time for

*4 Room heater/ *5 Tank heater.

- *6 If [Approx.] is shown on Energy Monitor display, data displayed on the remote controller is obtained through heat pump's internal
 - If [Approx.] is NOT shown on Energy Monitor display, data displayed on the remote controller is obtained by External Meters.
- *7 Only displayed when each connection is Yes.

Ме	nu	Default Setting	Setting Options / [Display	
3	Personal setup				
3.1	> Remote control No.				
	 To display remote control number of a particular remote controller so that installer and end user are well informed. Main remote controller is displayed as RC-1. Second remote controller is displayed as RC-2. 	Select and retrieve		RC No.	10:34am,Mon
3.2	> Touch sound				
	Turns the operation sound.	3	OFF/1/2/3/4	Touch sound Level 3 3 \$\times\$	9:53am,Mon
3.3	> LCD contrast				
	Sets the screen contrast.	3		LCD contrast Low Select	10:34am, Mon High Confirm
3.4	> Backlight			17 Jeiect [4-]	Commi
0.1	Sets the duration of screen backlight.	1 min		Backlight 15 secs 1 min → Select [+]	10:34am,Mon 5 mins 10 mins
3.5	> Backlight intensity			F Select [⊷]	Confirm
3.3	Sets screen backlight brightness.	4		Dark	10:34am, Mon Bright Confirm
3.6	> *1 Clock format				
	Sets the type of clock display.	am/pm		Clock format 24h am/p ^Select [→]	
3.7	> Date & Time			55.555	2
	Sets the present date and time.	Year / Month / I	Day / Hour / Min	Date & Time Year/Month/Day 2024 / 01 / 01	10:34am,Mon Hour : Min 10 : 34 am
*1 Th	e default setting is am/pm, but 24h is	displayed on the selection	screen.	\$ Select	[4] Confirm

Me	nu	Default Setting	Setting Options / D	Display	
3.8	> Language				
	Sets the display language for the top screen.	ITALIANO / ESP/ SWEDISH / NORW CZECH / NEDERL SUOMI / MAGYAR HRVATSKI / LIETU\ БЪЛГАРСКИ / EE ROMÂNĂ / SHQIF	ÇAIS / DEUTSCH / ÁÑOL / DANISH / VEGIAN / POLISH / LANDS / TÜRKÇE / L / SLOVENŠČINA / /IŲ / PORTUGUÊS / ESTI / LATVIEŠU / P / SLOVENČINA / AÄHCЬKA / EΛΛΗΝΙΚΑ	Language ENGLISH FRANÇAIS DEUTSCH ITALIANO Select [+	10:34am, Mon
3.9	> Unlock password				
	4 digit password for all the settings.	0000		Unlock password	10:34am, Mon
				\$Select [+]Confirm
4 4.1	Service contact > Contact 1 / Contact 2				
	Preset contact number for installer.	Select an	nd retrieve	Service setup Contact 1 Name : Bryan A : 088123	

Menus (For Installer) 5.1.6

Menu	Default Setting	Setting Options / Display	
5 Installer setup > System setu	•		
5.1 > *1 Optional PCB connectivity	•		
To connect to the external PCB required for servicing.	No	Yes No	

- If the external PCB is connected (optional), the system will have following additional functions:
 - ① Control over 2 zones (including the swimming pool and the function to heat water in it).
 - Solar function (the solar thermal panels connected to either the DHW (Domestic Hot Water) Tank or the Buffer Tank.
 DHW is not applicable for WH-ADC *models.
 - ③ External compressor switch.
- 4 External error signal.
 5 SG ready control.
 6 Demand control.

- 7 Heat-Cool SW

5.2	> Zone & Sensor				
J.Z	To select the sensors and to	Zone		Zone & Sensor	10:34am, Mon
	select title sensors and to select either 1 zone or 2 zone system.	After selecting 1 or 2 zone system, proceed to the selection of room or swimming pool. If the swimming pool is selected, the		Zone 1 Zone	system system
		temperature must be \(\triangle T \) temperature betw		→Select [-	⊷]Confirm
		Sensor			
		* For room thermostat, selection of external c • If select internal, there of RC-1 or RC-2 (only	or internal.		10:34am, Mon
		selection is 1 zone sy Select RC-1 if main re	stem). emote controller's ed for room temperature	Room th	ermostat ermistor ⊷] Confirm
5.3	> *1 Heater capacity	_			
	To reduce the heater power if unnecessary.* 3 kW / 6 kW / 9 kW			Heater capacity	10:34am,Mon
	* Options of kW vary depending on the model.			[-]Confirm
5.4	> Anti freezing				
	To activate or deactivate the water freeze prevention when the system is OFF	Yes		Ye	
5.5	> *2 Tank connection				
	To connect tank to the system.	No		Ye.	<u> </u>

^{**1} It is not displayed when the outdoor unit is used alone.

^{*2} It is not displayed when connect Panasonic AIR-TO-WATER HYDROMODULE+TANK.

Menu	Default Setting	Setting Options / Display
5.6 >*1 DHW capacity		
To select tank heating capacity to variable or standard. Variable capacity heat up tank with fast mode and keep the tank temperature with efficient mode. While standard capacity heat up tank with rated heating capacity. When "Efficiency" is selected the "5.25 Heating control" setting, the tank heat-up process will be delayed until a much lower tank water temperature is reached, which improves the efficiency of the heating process. To ensure sufficient hot water, select either "Standard" in this setting or "Comfort" in the "5.25 Heating control" setting.	Variable	Variable Standard
5.7 > *2 Buffer tank connection		
To connect tank to the system and if selected YES, to set	No	Yes No
$\triangle T$ temperature.	> Yes	
		Buffer tank 10:34am,Mor
	5 °C	Set △T for Buffer Range: (0°C~10°C) Tank AT for Buffer tank Range: (0°C~10°C) Steps: ±1°C 5 °C
		\$Select [₄-] Confirm
5.8 > *1 Tank heater		
To select external or internal tank heater and if External is selected, set a timer for the heater to come on. * This option is available if Tank connection is selected (YES).	External	Tank heater 10:34am,Mor External Internal Select [] Confirm
	> External	
	1:30	Tank heater 10:34am,Mor Tank heater: ON time Range: (0:20~3:00) Steps: ±0:05 \$\$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$
		+2elect [+1/contilm

^{*1} Only displayed when Tank connection is Yes.
*2 It is not displayed when the outdoor unit is used alone and Panasonic AIR-TO-WATER HYDROMODULE+TANK 2 Zone model.

lenu	Default Setting	Setting Options / D	Display	
9 > Base pan heater				
To select whether or not optional base pan heater is	No		Yes A No	
connected.	> Yes			
* Type A - The base pan heater activates only during deice operation. * Type B - The base pan heater activates when outdoor ambient temperature is 5 °C or lower.	А	Set base pan heater type*.	Base pan heater type 10:34am, Mon A B B Select [-]Confirm	
10 > *1 Alternative outdoor sensor				
To select an alternative outdoor sensor.	No		Yes No	
1 > Bivalent connection	1			
To select to enable or disable bivalent connection.	No		Yes No	
> Yes				
To select either auto control pattern or SG ready input control pattern or smart control pattern. * This selection only display to select when optional pcb connection set to Yes.	Auto		Auto SG ready Smart	
To select a bivalent connection	> Yes > Auto			
to allow an additional heat source such as a boiler to heat- up the buffer tank and domestic hot water tank when heatpump capacity is insufficient at low outdoor temperature. The	-5 °C	Set outdoor temperature for turn ON Bivalent connection.	Bivalent connection 10:34am, Mon Turn ON: Outdoor temp Range: (-15°C~35°C) Steps: ±1°C \$\frac{-5}{2}\$ °C	
bivalent feature can be set-up	Yes > After selecting	the outdoor temperatu	re	
either in alternative mode	Control pattern	•	Bivalent connection 10:34am, Mor	
(heatpump and boiler operate alternately), or in parallel	Alternative / Paralle	l / Advanced parallel	Control pattern	
mode (both heatpump and boiler operate simultaneously), or in advance parallel mode	Select advanced para the tanks.	allel for bivalent use of	Alternative Parallel Advanced parallel Select [+-] Confirm	
(heatpump operates and boiler turns on for buffer-tank and/or	Control pattern > Alte	ernative		
domestic hot water depending on the control pattern setting options).	OFF	Option to set external pump either ON or OFF during bivalent operation. Set to ON if system is simple bivalent connection.	External pump ON OFF Select ON OFF	

*1 It is not displayed when the outdoor unit is used alone.

Default Setting	Setting Options / D	Display	
Control pattern >	Advanced parallel		
Heat	Selection of the tank	Bivalent con Advanced pa	
 "Heat" implies Buindlies Domestic 	ffer Tank and "DHW" Hot Water Tank.		Heat DHW
Control nottorn	Advanced parallel > Heat >	→Select	[+-] Confirm
Control pattern >	Advanced parallel > Heat >	I	
		Bivalent con Advanced pa	
 Buffer Tank is acti "Yes". 	vated only after selecting	Advanced pr	Yes No
		↓ Select	[+]Confirm
		Bivalent con	nection 10:34am, Mor
	Set the temperature	Heat start: 1	
-8 °C	threshold to start the bivalent heat source.	Range: (-10 Steps: ±1°C	°C~0°C)
		\$Select	[4] Confirm
		Bivalent con	nection 10:34am, Mor
0:30	Delay timer to start the bivalent heat source (in hour and minutes).	Heat start: D Range: (0:0: Steps: ±0:0!	0~1:30)
	(iii flour and fillidics).	\$Select	[4] Confirm
		Bivalent con	nection 10:34am, Mor
	Set the temperature	Heat stop: T	
-2 °C	threshold to stop the bivalent heat source.	Range: (-10 Steps: ±1°C	°C~0°C)
		\$Select	[+]Confirm
		Bivalent con	nection 10:34am, Mor
	Delay timer to stop	Heat stop: D	
0:30	the bivalent heat source (in hour and minutes).	Range: (0:0 Steps: ±0:0!	
	(III flour and minutes).	\$Select	[4] Confirm
Control pattern >	Advanced parallel > DHW >	Yes	
, and the second second		Bivalent con	nection 10:34am, Mor
		Advanced pa	· · · · · · · · · · · · · · · · · · ·
 DHW Tank is active "Yes". 	vated only after selecting		Yes No
		_Select	[+-] Confirm
		Bivalent con	
	Delay timer to start	DHW: Delay	· · · · · · · · · · · · · · · · · · ·
0:30	the bivalent heat source (in hour and minutes).	Range: (0:30 Steps: ±0:0!	0~1:30)
	(iii iioai ana iiiiiates).	A .	

\$Select

[4]Confirm

Menu

Menu	Default Setting	Setting Options / D	Display		
SG ready input control for	> Yes > SG ready				
bivalent system follow below input condition. SG signal Operation pattern Vcc-bit1 Vcc-bit2 Open Open Boiler OFF Short Open Short Boiler ON Short Short Short Boiler ON Short Short Short Boiler ON	OFF	Option to set external pump either ON or OFF during bivalent operation. Set to ON if system is simple bivalent connection.	Bivalent connection 10:34am,Mon External pump ON OFF Select [+-] Confirm		
To do settings related to	> Yes > Smart				
electricity and boiler so that unit is able to determine whether to operate heat pump or boiler at a particular period depends on operating cost of both heat sources. These settings are electricity price, boiler price, season, schedule etc.	OFF	Option to set external pump either ON or OFF during bivalent operation. Set to ON if system is simple bivalent connection.	Bivalent connection 10:34am,Mon External pump ON OFF Select [] Confirm		
	> Yes > Smart > After selecting for the external pump > Energy price				
	 Select Electricity to set on electricity price. Select Boiler to set on boiler price and its efficiency. 		Bivalent connection 10:34am,Mon Energy price Electricity Boiler Select [→] Confirm		
	> Yes > Smart > After selecting for the external pump > Energy price > Electricity				
		lectricity price 10 kWh er a setting screen as then start setting the ce. articular electricity price), press < or > to go tricity price. tricity price. to the setting the ce. to go to value provided by	Range: (0~999.9 */kWh) Steps: ±0.1*/kWh O.0 Steps: ±0.1*/kWh O.0 Steps: ±0.1*/kWh O.0 O.0		

Remark: * Currency setting depends on where you use this product.

- Select "1" to edit both start time and electricity price. Select "2" to edit electricity price only.



Remark: * Currency setting depends on where you use this product.

Menu

Menu	Default Setting	Setting Options / D	isplay		
	- Range of start time displayed can be in "24h" or "am/pm" format depend on setting of "Clock format".		Season 1 Pattern 1: St Range: (0.00 Steps: ±1ho	art time 0~23.00)	3.00
			\$Select	[₄]Confiri	m
	- Range of electricity p	rice is 0 ~ 10 which	Season 1	10:3	34am,Mon
	refers back to the 10		Pattern 1: Pr		.0 */kWh
	price set previously (Electricity": Electricity price 1 ~ E		Range: (0~1 Steps: ±1	0)	0
	The price displayed of indicates the previous price 1 to Electricity p * When the price is set price will be treated a	on the upper right corner is set value of Electricity price 10. to "0", the electricity is 0.0 * / kWh. It is for istaller when 0.0 is the	\$Select	[₊-] Confiri	m
5.12 > *1 External SW					
	No			Yes No	
5.13 > *2 Solar connection					
The optional PCB connectivity must be selected YES to	No			Yes No	
enable the function. • If the optional PCB	> Yes				
connectivity is not selected,			Solar connec	tion 10:3	34am, Mor
the function will not appear on				Buffer tank	
the display. • DHW is not applicable for	Buffer tank	Selection of the tank	→ DHW tank		
WH-ADC models.			_Select	[₄-]Confir	m
	> Yes > After selecting	ng the tank	A DCICCE	[4-]COIIII	•••
	* 100 * 71101 00100111	lg the talk	Solar connec	tion 10:3	34am, Mor
			ΔT Turn ON		
	10 °C	Set △T ON temperature	Range: (6°C Steps: ±1°C	-15℃)	10 °c
			\$Select	[₄]Confir	m
	> Yes > After selecting	ig the tank > \triangle T ON tem	perature		
	5 °C	Set △T OFF	Solar connect ΔT Turn OFF Range: (2°C-	:	34am, Mor
		temperature	Steps: ±1°C	[+-] Confir	m 5 °C

^{*1} It is not displayed when the outdoor unit is used alone.

t is not displayed when the outdoor unit is used alone and Panasonic AIR-TO-WATER HYDROMODULE+TANK 2 Zone model.

Menu	Default Setting	Setting Options / D	Display		
-	> Yes > After selecti	ng the tank > △T ON tem	perature > △T OFF	temperature	
	5 °C	Set Antifreeze temperature	Solar connection Anti freeze Range: (-20°C~10°C Steps: ±1°C	10:34am, Mon	
		temperature		Confirm	
		ng the tank > △T ON tem ntifreeze temperature	perature > △T OFF temperatur		
	80 °C	Set Hi limit	Solar connection Hi limit Range: (70°C~90°C) Steps: ±5°C	80 °C	
5.14 > *1 External error signal			\$Select [←]	Confirm	
5.14 / External error signal	No		Yes No	_	
5.15 > *1 Demand control					
	No		Yes No	•	
5.16 >*1 SG ready		1			
	No		Yes No		
	> Yes > After selecti	ng Capacity			
	120 %	Capacity (1) & (2) of DHW (in %), Heat (in %) and Cool (in °C)	SG ready Capacity [1-0]: DHW Range: (50%~150% Steps: ±5% \$Select []		
	> Yes > After selecti	ng Power consumption >	> *HPU stop consur	nption	
	* ^{2, *4} 3.6kW	*HPU stop consumption	SG ready HPU stop consump Range: (0.5kW~10. Steps: ±0.1kW \$\$		
	> Yes > After selecti	ng *HPU stop consumpt	ion > Consumption		
	*33.6kW	Consumption (1) & (2) of DHW (in kW), Heat (in kW) and Cool (in kW)	SG ready Consumption [1-0]: Range: (0.5kW~10. Steps: ±0.1kW		

Remark: * HPU means Heat pump unit (Outdoor unit).

^{*1} It is not displayed when the outdoor unit is used alone.

*2 Depending on the model, it may be less than 3.6kW.

*3 Depending on the model, it may be less than 3.6kW or more than 3.6kW.

*4 Even though the setting value is lower than 3.0kW, actual power consumption can be 3.0kW caused by back-up heater operation.

Me	nu	Default Setting	Setting Options / Display
5.17	> *1 External compressor SW		
		No	Yes No
		> Yes	
			Ext. compressor SW 11:34am,Mon
		Heat source	Heater Heat source
5.18	Circulation liquid		^Select [₄-] Confirm
J. 10	> Circulation liquid To select whether to circulate		Circulation liquid 10:34am, Mon
	water or glycol in the system.	Water	Water
		vvator	Glycol
			\$\times \text{Select} \[-4 \] \text{Confirm}
5.19	> *1, *2 Heat-Cool SW		
		No	Yes A No
5.20	> *1 Force heater		
	To turn on Force heater either manually (by default) or automatically.	Manual	Force heater 10:34am,Mon Auto Manual Select [+] Confirm
5.21	> Force defrost		Sciett []commi
	If auto selection is set, outdoor unit will start defrost operation if long heating hour operate during low outdoor temperature.	Manual	Auto Manual
5.22	> *1 Defrost signal		
	To turn on defrost signal to stop fan coil during defrost operation. (If defrost signal set to yes, bivalent function will not available to use)	No	Yes No

^{*1} It is not displayed when the outdoor unit is used alone.
*2 Only displayed when COOL mode is unlocked. (This mean when COOL mode is available)

Menu		Default Setting	Setting Options / I	Display	
5.23 > Pump flow	rate				
To set variable control or fix pu	flow pump ump duty control.	ΔT		ΔT ▼ Max. Du	ıty
5.24 > DHW Defro	ost				
Allow system to using hot water unit for better re	r instead of room	Yes		Yes V	
5.25 > Heating co	ntrol				
To select unit o condition wheth set temperature	ner to achieve	Comfort		Comfo Efficien	
save energy.		> Efficiency			
1st, 2nd, and 3 Increasing the increase the ca It is a function f Tank operation. When "Variable the "5.6 DHW of the tank heat-udelayed until a water temperat which improves	g will transition to rd stage. time will slowly apacity. for Heating + . " is selected in capacity" setting, up process will be much lower tank ture is reached, as the efficiency of cess. To ensure ater, select in this setting in the "5.6 DHW	0:20		Heating control Efficiency: Stage 1 Range: (0:00~1:00) Steps: ±0:05 \$\$ Select [+] Capacity Ist stage 2nd st	Confirm Total tin
5.26 > External m	eter				
to be used d connection. There are go meters and of electricity me For generation there are two systems:- a) One gene- system:	various types of eters. on meters, o connection eration meter	Heat-cool meter: No * Tank meter: No Elec. meter HP: No Elec. meter 1 (PV): No Elec. meter 2 (Building) Elec. meter 3 (Reserve * Only available if both Tank connection are s	: No) : No Heat-cool meter and	External meter Elec. meter HP Elec. meter 1 (PV) Elec. meter 2 (Buil Elec. meter 3 (Res	
b) Two gene	l meter only eration meter	> Heat-cool meter			
system:	I meter and Tank	- Set Heat-cool meter to generation meter is co - It is to measure energ pump unit during heat operation (one genera during heating, cooling (two generation meter	onnected. y generation of heat ing and cooling only ation meter system) or g and DHW operation	Yes No	

Remark : Elec. means "Electricity", HP means "Heat pump"

Menu	Default Setting Setting Options / Display
	> Tank meter
	- Set Tank meter to Yes when this generation
	meter is connected.
	- It is to measure energy generation of heat pump unit during DHW operation*.
	* Only available if both Heat-cool meter and
	Tank connection are set to Yes.
	Only set Tank meter to Yes when the
	connection is two generation meter system.
	> Elec. meter HP
	- Set Elec. meter HP to Yes when this
	electricity meter is connected.
	- It is to measure energy consumption of heat pump unit.
	> Elec. meter 1 (PV)
	- Set Elec. meter 1 (PV) to Yes when this
	electricity meter is connected.
	- It is to measure energy generation of solar
	system. This data will be displayed only on
	Cloud system.
	> Elec. meter 2 (Building)
	- Set Elec. meter 2 (Building) to Yes when this
	electricity meter is connected.
	- It is to measure energy consumption of the
	building. This data will be displayed only on Cloud system.
	·
	> Elec. meter 3 (Reserve)
	- Set Elec. meter 3 (Reserve) to Yes when this electricity meter is connected.
	- It is to measure energy consumption. This
	data will be displayed only on Cloud system.
5.27 > Electrical anode	
To enable or disable operation	Yes (for -AN models)
of electrical anode.	No (for non -AN models)
	Yes : display)
	No : no display 4() c
	error : blinking)

Remark : Elec. means "Electricity" HP means "Heat pump"

Me	nu	Default Setting	Setting Options / [Display	
5.28	> *1 Extra pump				
	Selects whether the extra pump is used in the circulation circuit	No		•	No Heat DHW
	for heating or in the circulation	> DHW	'		
	circuit for DHW, or it is not used. If set to "No", the pump is not used.			DHW Pump ON time	11:34pm,Mon
	If set to "Heat", the extra pump is used as a pump for the circulation circuit (for heating/	8:00 am / 8:00	Set Pump ON time	_	: 00 am
	cooling).			\$ Select	[4] Confirm
	If set to "DHW", the extra pump			DHW Pump OFF tim	11:34pm,Mon
	circulates domestic hot water in the circuit for DHW to prevent the domestic hot water from getting cold.	8:00 pm / 20:00	Set Pump OFF time	8	: 00 pm
	- If set to "Comfort", hot water			\$> Select	[₊-]Confirm
	is continuously circulated during DHW operation. - If set to "Efficiency", the extra pump turns ON and OFF alternatively following ON/OFF time setting.			DHW	11:34pm,Mon
		Efficiency	Select Comfort or Efficiency	E	Comfort Efficiency
				*Select	[₊-]Confirm
		> DHW > After selecti	ing Efficiency		
		0:15	Set ON time	DHW	11:34pm,Mon
				ON time Range: (0:05- Steps: ±0:05	~1:00)
				\$Select	[+]Confirm
				DHW	11:34pm,Mon
				OFF time	· · ·
		0:15	Set OFF time	Range: (0:05- Steps: ±0:05	~1:00)
				\$Select	[₊-] Confirm
5.29	> External heater				
	Set to "YES" after an external heater is installed. (This menu is only displayed for the Control Module model (indoor unit))	No			Yes No
5.30	> Static pressure				
	If set to "No", the fans in the outdoor unit rotate at a normal speed. If set to "YES", the fans in the outdoor unit rotate at a higher speed than normal for response to high static pressure.	No		•	Yes No

*1 It is not displayed when the outdoor unit is used alone.

Menu	Default Setting	Setting Options / Display
5.31 > *1 Cooling capacity		
Selects the cooling capacity. If set to "Efficiency", the cooling operation is performed at rated capacity for efficient cooling. If set to "Comfort", the cooling operation is performed at maximum capacity.	Efficiency	Comfort Efficiency

*1 Only displayed when COOL mode is unlocked	(This means when COOL mode is available).
--	---

Me	enu	Default Setting	Setting Options / D	Display		
6	Installer setup > Operation s	etup				
	To access to the four major functions or modes.	4 main	modes *1, *2 Auto / *3 Tank	Operation setup 10:34am,Mon Heat Cool Auto Tank		
	V II4			Select [←] Confirm		
6.1	> Heat To set various water & ambient temperatures for heating.	Outdoor temp. △T for he	or heating ON / for heating OFF / eating ON / ON/OFF	Operation setup 10:34am, Mon Heat Water temp. for heating ON Outdoor temp. for heating OFF AT for heating ON Select [+] Confirm		
		> Water temp. for hea	ating ON			
		Compensation curve	Heating ON temperatures in compensation curve or direct input.	Operation setup 10:34am, Mon Heat ON: Water temp. Compensation curve Direct Select [+] Confirm		
		> Water temp for hea	│ ating ON>Compensatio			
		X axis: -5 °C, 15 °C Y axis: 55 °C, 35 °C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis).	Heat ON: Water temp.:Zone1 55°C 75 35°C 25 -20 -5°C 15°C 15 4⇒Select -1 Confirm		
		Temperature range fo WH-WXG model: 25 ° Regardless of the abouthe operating conditio If 2 zone system is see 2.	°C ~ 75 °C ove setting, there is a limi n on page 3. lected, the 4 temperature	axis: See below it to the water temperature. Refer to e points must also be input for Zone isplay if only 1 zone system.		
		> Water temp. for hea				
		35 °C	Temperature for heating ON	Operation setup 10:34am,Mon Heat ON: Water temp.:Zone2 Range: (25°C~75°C) Steps: ±1°C \$5elect [+] Confirm		
		the operating conditio • If 2 zone system is se	°C ~ 75 °C ove setting, there is a limi n on page 3. lected, temperature set p	it to the water temperature. Refer to point must input for Zone 2. isplay if only 1 zone system.		

^{*1} The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.

*2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

*3 Only displayed when Tank connection is Yes.

Menu	Default Setting	Setting Options / D	isplay	
	> Outdoor temp. for	heating OFF		
	> Outdoor temp. for	heating OFF > Heat OFF	outdoor temp.	
		Set outdoor temp to	Operation setup Heat OFF: Outdoor	10:34am, Mor temp.
	24 °C	stop heating. Setting range is	Range: (6°C~35°C) Steps: ±1°C	24 °c
		6°C~35°C	\$Select [←]	Confirm
	> Outdoor temp. for	heating OFF > Heat ON	outdoor temp.	
	23 °C	Set outdoor temp to start heating. Setting range is	Operation setup Heat ON: Outdoor to Range: (5°C~23°C) Steps: ±1°C	10:34am,Mor emp. 23 °C
		5°C~X°C (X is heating OFF temp1)		Confirm
	> Outdoor temp. for	heating OFF > Heat ON I	Delay time	
	Zutuoor temp. 101	Theating of 1 7 Heat ON 1	Operation setup	10:34am,Mor
	0:30 min	Set delay time from heating OFF to heating ON.	Heat ON: Delay time Range: (0:30~24:00) Steps: ±0:30	
		incoming of the	\$Select [↩]	Confirm
	> △T for heating O	N		
		Set △T for heating ON.	Operation setup	10:34am, Moi
	5 °C	* This setting will not available to set when pump flowrate set to	Range: (1°C~15°C) Steps: ±1°C	5 ℃
	. *1.1	Max. duty.	\$Select [←]	Confirm
	> *1 Heater ON/OFF		ON	
	> Heater ON/OFF >	Outdoor temp. for heate		40:24em Mai
			Operation setup Heater ON: Outdoor	10:34am,Moi r temp.
	0 °C	Temperature for heater ON	Range: (-20°C~15°C Steps: ±1°C	
			\$Select [←]	Confirm
	> Heater ON/OFF >	Delay time for heater ON	1	
			Operation setup Heater ON: Delay ti	10:34am,Mor me
	0:30 min	Delay time for heater to turn on	Range: (0:10~1:00) Steps: ±0:10	0:30
			\$Select [←]	Confirm
	> Heater ON/OFF >	Water temperature for he	neater ON	
			Operation setup	10:34am,Mo
	-4 °C	Setting of water temperature to turn on from water set	Heater ON: ΔT of to Range: (-10°C~-2°C) Steps: ±1°C	
		temperature.	\$Select [←]	Confirm

Menu	Default Setting	Setting Options / D	isplay		
	> Heater ON/OFF > V	Vater temperature for he	eater OFF		
	-2 °C	Setting of water temperature to turn off from water set temperature.	Operation setup Heater OFF: ΔT of Range: (-8°C~0°C) Steps: ±1°C	10:34am,Mon target Temp.	
6.2 >*1, *2 Cool			♣2ciect [+-]	Commi	
To set various water & ambient temperatures for cooling.		Water temperatures for cooling ON and △T for cooling ON.		10:34am, Mon	
	> Water temp. for cod	oling ON	→Select [←	Commi	
	Compensation curve	Cooling ON temperatures in compensation curve or direct input.	Operation setup Cool ON: Water ten Compensati Dire	on curve	
	> Water temp. for cooling ON > Compensation curve				
	X axis: 20 °C, 30 °C Y axis: 15 °C, 10 °C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis)	Cool ON: Water ten 15°C 20 10°C 5 15 20°C 4>Select []	np: Zone1 30°C 30 Confirm	
	• If 2 zone system is selected, the 4 temperature points must also be input for Zone				
	2. • "Zone 1" and "Zone 2	" will not appear on the di	splay if only 1 zone	system.	
	> Water temp. for cooling ON > Direct				
	10 °C	Set temperature for Cooling ON	Operation setup Cool ON: Water ten Range: (5°C~20°C) Steps: ±1°C	10 °c	
	• If 2 zone system is se	lected, temperature set p		Confirm	
		will not appear on the di			
	> △T for cooling ON				
	5 °C	Set △T for cooling ON * This setting will not available to set when pump flowrate set to	Operation setup Cool ON: ΔT Range: (1°C~15°C) Steps: ±1°C	10:34am, Mon	
		Max. duty.	\$Select [+-]	Confirm	

*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
*2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

Menu	Default Setting	Setting Options / D	isplay	
6.3 >*1, *2 Auto				
Automatic switch from Heat to Cool or Cool to Heat.	Outdoor temperatures for switching from Heat to Cool or Cool to Heat. Outdoor temp. for (Heat to Cool) / Outdoor temp. for (Cool to Heat)		Operation setup Auto Outdoor temp. for Outdoor temp. for Select	
	> Outdoor temp. for	(Heat to Cool)	A201001 []	
	15 °C	Set outdoor temperature for switching from Heat to Cool.	Operation setup Auto: Outdoor temp Range: (11°C~25°C) Steps: ±1°C	
	> Outdoor temp. for	(Cool to Heat)	♣361661 [4 -]	Commin
	10 °C	Set outdoor temperature for switching from Cool to Heat.	Operation setup Auto: Outdoor temp Range: (5°C~14°C) Steps: ±1°C	10°C
6.4 > *3 Tank			\$Select [↩]	Confirm
Setting functions for the tank.	Floor operation time (max) / Tank heat up time (max) / Tank re-heat temp. / Sterilization		Operation setup Tank Floor operation tim Tank heat up time Tank re-heat temp. →Select	(max)
	The display will show	3 functions at a time.		
	> Floor operation tin	ne (max)		
	8:00	Maximum time for floor operation (in hours and minutes)	Operation setup Tank: Floor ope. tin Range: (0:30~10:00 Steps: ±0:30	8:00
	> Tank heat up time	(max)	\$Select [₄-]	Confirm
	rank neat up tille	(IIIdA)	Operation setup	10:34am, Mon
	1:00	Maximum time for heating the tank (in hours and minutes)	Tank: Heat up time Range: (0:05~4:00) Steps: ±0:05	(max)
			\$Select [+-]	Confirm
	> Tank re-heat temp.			
	-8 °C	Set temperature to perform reboil of tank water.	Operation setup Tank: Re-heat temp Range: (-12°C~-2°C) Steps: ±1°C	
			\$Select [+-]	Confirm

*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
*2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

*3 Only displayed when Tank connection is Yes.

Menu	Default Setting	Setting Options / D	isplay
	> Sterilization		
	Monday	Sterilization may be set for 1 or more days of the week. Sun / Mon / Tue /	Operation setup 10:34am, Mon Sterilization: Day Sun Mon Tue Wed Thu Fri Sat - V
		Wed / Thu / Fri / Sat	◆Day \$☑/☐ [←]Confirm
	> Sterilization: Time		
	12:00	Time of the selected day(s) of the week to sterilize the tank 0:00 ~ 23:59	Operation setup 10:34am,Mon Sterilization: Time 12:00 pm ⇒ Select [→] Confirm
	> Sterilization: Boilin	ng temp.	<u> </u>
	65 °C	Set hoiling	Operation setup 10:34am,Mon Sterilization: Boiling temp. *1 Range: (55°C-65°C) Steps: ±1°C Select [] Confirm
	> Sterilization: Ope. t	time (max)	
	0:10	Set sterilizing time (in hours and minutes)	Operation setup 10:34am, Mon Sterilization: Ope. time (max) Range: (0:05~1:00) Steps: ±0:05
			\$Select [4] Confirm
7 Installer setup > Service set	ир		
7.1 > Pump maximum speed			
To set the maximum speed of the pump.		max. duty and operation of the pump.	Service setup 10:34am,Mon Flow rate Max. Duty Operation
	Max. Duty: 0	XX.X L/min 0x40 ~ 0xFE, DFF/Air Purge	46.0 L/min OxCE → OFF ⇒ Select
7.2 > *2 Zone2 pump speed			
To set the zone2 pump speed.	Max. Duty: 0	XX.X L/min 0x46 ~ 0xC5,	Service setup 11:34pm,Mon Flow rate Max. Duty Operation
	Pump:	ON/OFF	10.0 L/min 0x50 OFF


\$ Select

^{*1} When using external heater, 55°C ~ 75°C. *2 Only displayed when Panasonic AIR-TO-WATER HYDROMODULE+TANK 2Zone model.


Menu	Default Setting	Setting Options / D	Display	
7.3 > Dry concrete				
To dry the concrete (floor, walls, etc.) during construction.	Edit to set the temperature of dry concrete.		Service setup Dry concrete ON	10:34am,Mon
Do not use this menu for any other purposes and in period	ON	/ Edit	Edit Select [←]	Confirm
other than during construction	> Edit		Applicate [4.1	
	Stages: 1 Temperature: 25 °C	Heating temperature for drying the concrete. Select the desired stages: 1 ~ 10,	Dry concrete: 1/10 Range: (25°C~55°C) Steps: ±1°C	10:34am,Mon
	> ON	range: 1 ~ 99	^Select [←]	Confirm
	Confirm the setting temperatures of dry concrete for each stage.		Service setup Dry concrete: Status Stage Water set temp. Actual water temp. [the office of the set	10:34am, Mon : 1/10 : 25°C :25°C/25°C
7.4 > Service contact	_			
To set up to 2 contact names and numbers for the User.	-	me and contact number. / Contact 2	Service setup Service contact: Contac	
	> Contact 1 / Contact	12	→Select [←]	Commin
		ne or number.	Service contact Contact 1	10:34am, Mon
	Name / p	phone icon	Name : Bryan Ad	
	Contact name:	and number alphabet a ~ z.	ABCDEFGHIJKLM STUVWXYZ abco jklmnopqrstuv √→Select [⊷]	lefghi BS
	Contact nu	ımber: 1 ~ 9	Number: 2 3 4 5 6 7 8 9 × 0 4 4 >> Select [+]) - <u>BS</u>

Menu	Default Setting	Setting Options / Dis	splay
8 Installer setup > Remote cor	ntrol setup		
 To select whether to use one remote controller or two remote controllers. 		Selection of one or two remote controllers.	Single Dual
Select Single when one remote controller is connected. Select Dual when		When Dual is selected, Main remote controller (RC-1) will	
two remote controllers are connected. Second remote controller can be used for zone 2 room temperature control.	Single	start to communicate with second remote controller (RC-2) and display "RC-1 & RC-2 sync. in progress".	RC-1 & RC-2 sync. in progress!
		They are ready to be used after this pop up screen disappears.	
		When both remote controllers have communication failure, it will display "Communication with	Communication with RC-2 failed!

5.1.7 Main Components




5.2 Outdoor Unit




6. Dimensions

6.1 Indoor Unit




6.2 Outdoor Unit



7. Refrigeration and Water Cycle Diagram


OUTDOOR UNIT



- → REFRIGERANT CYCLE [HEATING]
- ····➤ REFRIGERANT CYCLE [COOLING]


TH1	Outdoor discharge sensor
TH2	-
TH3	Outdoor heat exchanger sensor
TH4	Outdoor ambient sensor
TH5	Evaporator outlet sensor
TH6	Refrigerant sensor
TH7	Water inlet 2 sensor
TH8	Water outlet sensor 2
TH9	Outdoor heat exchanger middle sensor
TH10	Bypass outlet sensor
TH11	Bypass inlet sensor
TH12	Economizer outlet sensor

8. Block Diagram




9. Wiring Connection Diagram

9.1 Indoor Unit



9.2 Outdoor Unit




Resistance of Compressor Windings

MODEL	WH-WXG09ME5 / WH-WXG12ME5
CONNECTION	7CD081XA02
U - V	0.210 Ω
V - W	0.210 Ω
U - W	0.210 Ω


Note: Resistance at 20°C of ambient temperature.

10. Electronic Circuit Diagram

10.1 Indoor Unit




10.2 Outdoor Unit




11. Printed Circuit Board

11.1 Indoor Unit

11.1.1 Main Printed Circuit Board




11.1.2 Sub Printed Circuit Board (Optional)




11.2 Outdoor Unit


11.2.1 Main Printed Circuit Board



11.2.2 Noise Filter Printed Circuit Board



11.2.3 Sub Printed Circuit Board




12. Installation Instruction

Attached Accessories

No.	Accessories part	Qty.
1	Installation plate	1
2	Network adaptor (CZ-TAW*)	1

Optional Accessories

No.	Accessories part	Qty.
3	Remote controller Case (PAW-A2W-COV-KL)	1
4	Extension Cable (CZ-TAW1-CBL)	1
5	Optional PCB (CZ-NS7P)	1
6	Remote controller (CZ-RTW2-1)*1	1



Field Supply Parts (Optional)

No.	Part		Model	Specification	Manufacturer
	2-way valve kit	Electromotoric Actuator	SFA21/18	AC230V, 12 VA	Siemens
'	*Cooling model	2-port Valve	VXI46/25	-	Siemens
ii	2 Isit	Electromotoric Actuator	SFA21/18	AC230V, 12 VA	Siemens
II	3-way valve kit	3-port Valve	VVI46/25	-	Siemens
	De ave the average tot	Wired	PAW-A2W-RTWIRED	A C220V	
iii Ro	Room thermostat	Wireless	PAW-A2W-RTWIRELESS	AC230V	-
iv	Mixing valve	-	13020800	AC 230V, 5 VA	ESBE
V	Pump	-	Yonos Pico 1.0 25/1-8	AC 230V, 0.6 A max	Wilo
vi	Buffer tank sensor	-	PAW-A2W-TSBU	-	-
vii	Outdoor sensor	-	PAW-A2W-TSOD	-	-
viii	Zone water sensor	-	PAW-A2W-TSHC	-	-
ix	Zone room sensor	-	PAW-A2W-TSRT	-	-
х	Solar sensor	-	PAW-A2W-TSSO	-	-
xi	Outlet water sensor	-	PAW-A2W-TSBH	-	-

■ It is recommended to select the field supply parts in the table above.

^{*1} If you need the 2nd remote controller, buy 6 and set it up.


12.1 Indoor Unit

12.1.1 Select the Best Location

Obtain customer's approval before deciding the installation location.


- Ensure that there are no heat sources or vapours near the Indoor Unit.
- Good air circulation in the room.
- Ensure to keep distance of spaces as illustrated below from walls, ceilings, or other obstacles.
- A place where flammable gas leaking might not occur.
- The Indoor Unit must be installed on a vertical wall.
- When installing electrical equipment in a wooden building of metal lath or wire lath, according to electrical facility technical standards, no electrical contact between equipment and building is allowed. An insulator must be installed in between them.
- Do not install the Indoor Unit at outdoor. This is designed for indoor installation only.

12.1.1.1 Required Space for Installation



12.1.1.2 Installation Position

The mounting wall is strong and solid enough to prevent it from vibration.



The edge of the installation plate 1 should be more than 115 mm from the wall on both right and left sides.

The distance from the ground to the top of the unit should be more than 1339 mm to facilitate easier handling of the Remote controller.

- Always mount the installation plate horizontally by aligning the marking thread and using a level gauge.
- Mount the installation plate on the wall with 3 sets of plug, screw, and washer with size M6 (field supply). The combined thickness of the screw head and washer must be less than 6 mm.

12.1.2 Install the Indoor Unit and Open the Front Cover


№ WARNING

Q

This section is for authorized and licensed electrician only. Work behind the front cover ① secured by screws must only be carried out under the supervision of a qualified contractor, installation engineer, or service person.

12.1.2.1 Install the Indoor Unit


- 1. Engage the slots on the Indoor Unit to the hooks of installation plate 1.
- 2. Ensure the hooks are properly seated on the installation plate by moving it left and right.



12.1.2.2 Open the Front Cover


Before opening the front cover ① of the Indoor Unit, always switch off all power supplies (e.g. the Indoor Unit power supply, the outdoor unit power supply, and the heater power supply).

- 1. Remove the 2 mounting screws located at the top of the enclosure ②.
- 2. Gently pull the upper section of the front cover ① towards you.
 - (The front cover will stops once it has opened about 2 degrees.)
- 3. Gently rotate the front cover ① to open 180 degrees.




12.1.2.3 Fix the Indoor Unit

Fasten two screws (M6) at the bottom holes of the Indoor Unit.



12.1.2.4 An Example of System Installation



* This system requires the Optional PCB (CZ-NS7P).

12.1.3 Connect the Cable to the Indoor Unit

№ WARNING

This section is for authorized and licensed electrician only. Work behind the front cover ① (secured by screws) must only be carried out under the supervision of a qualified contractor, installation engineer, or service person.

1. Remove the terminal cover.

Remove one screw from the terminal cover (9), and move it upward.

2. Connect the power supply cable.

The specification of the power supply cable must be as follows:


- Cable size: 5 × min 1.5 mm² (WH-CME8), 3 × min 1.5 mm² (WH-CME5)
- Cable type: 60245 IEC 57 or heavier, with an approved polychloroprene sheath.
- The earth wire must be longer than other wires.

The specification of the isolating device (disconnecting means) and RCD must be as follows:

- The isolating device: 20A (WH-CME8), 15/16A (WH-CME5)
- Recommended RCD: 30mA, 4P, type A (WH-CME8), 30mA, 2P, type A (WH-CME5)
- The isolating device must be connected to the power supply cable.
- The isolating device must have a contact gap of at least 3.0 mm.

The method of wiring a cable is shown below.

Go through the cable from the left squared bushing hole.



Terminal screw	Tightening torque cN•m {kgf•cm}
M4	157~196 {16~20}
M5	196~245 {20~25)

*1 - Earth wire should be longer than other cables for safety reasons

Terminals of RCCB/ELCB tightening torque cN•m {kgf•cm}	160~200 {16.3~20.4}	
Holder tightening torque cN•m {kgf•cm}	70~130 {7.1~13.3}	

3. Connect the ID-OD communication cable.


The specification of the ID-OD communication cable must be as follows:

- Cable size: 2 × min 0.75 mm²
- Cable type: 60245 IEC 57 or heavier, with a double-insulated approved polychloroprene sheath.

The method of wiring a cable is shown below.

Go through the cable from the left squared bushing hole.

* Do not connect a 1-phase indoor unit to a 3-phase outdoor unit.



Terminal screw	Tightening torque cN•m {kgf•cm}	
M4	157~196 {16~20}	
M5	196~245 (20~25)	

4. Assemble the terminal cover.

Reverse step 1.

Tightening torque cN•m {kgf•cm}	98.1 {10.2}
---------------------------------	-------------

12.1.3.1 Compliance with IEC/EN 61000-3-2 and IEC/EN 61000-3-3

- The power supply of this Indoor Unit complies with IEC/EN 61000-3-2.
- The power supply of this Indoor Unit complies with IEC/EN 61000-3-3, and it can be connected to the current supply network.

12.1.3.2 External Heater


External heater can be used as an In-line heater or a buffer tank heater.

- Connect a heater of 9kW (3kW × 3) or less (WH-CME8).
- Connect a heater of 3kW (3kW × 1) or less (WH-CME5).
- Each heater shall be equipped with an 85°C OLP that can directly turn OFF the power supply. The OLP shall be non-automatic return type.
- The external heater shall be equipped with an 85°C OLP for signal line. The OLP can be either automatic or non-automatic return type.
- Using it as an In-line heater, be sure to install Optional outlet water sensor (PAW-A2W-TSBH) at the heater outlet.
- Using it as a buffer tank heater, be sure to install Optional Buffer tank sensor (PAW-A2W-TSBU).
- Ground the In-line heater body or buffer tank body in case of electrical leakage. (See illustration next page)


<u></u> WARNING
Incorrect electrical work may result in electric shock or fire. Please follow this installation manual.

How to connect to the main circulation circuit as an In-line heater

• WH-CME8




WH-CME5




How to connect to the buffer tank as a buffer tank heater

WH-CME8



WH-CME5



The connecting cable between the external heater (in-line heater or buffer tank heater) and the Indoor Unit should be a double-insulated approved polychloroprene sheathed cord with type designation 60245 IEC 57 or heavier. Cable size is 1.5mm² or more.

Maximum cable length of OLP for signal and outlet water sensor: 30m.


The tightening torque for the terminals are as shown in the table below.

Terminal screw	Tightening torque cN•m {kgf•cm}
M4	157~196 {16~20}
M5	196~245 {20~25)


- The heater capacity is designed to be 3kW per element.
- You can monitor the COP for the heater using in the "Energy Monitor" setting by remote controller. However, if
 installed heater capacity is 1 kW or 2 kW, the remote controller will display a lower value than the actual COP.
 For example, when the installed heater capacity is 1 kW, the COP is displayed as 0.33 of the actual value.

12.1.3.3 Wire Stripping and Connecting Requirements

Terminal size	Ø d [mm]	A [mm]
M4	4.2 or more	10.0 or less
M5	5.2 or more	12.5 or less



12.1.3.4 Cable Arrangement



12.1.4 Connect to External Devices (Optional)


♠ WARNING

This section is for authorized and licensed electrician only. Work behind the front cover ① secured by screws must only be carried out under the supervision of a qualified contractor, installation engineer, or service person.

12.1.4.1 Cable Specifications

- All connections must comply with local national wiring standards.
- It is strongly recommended to use parts and accessories recommended by the manufacturer for installation.
- For connection to PCB 4.
- The two-way valve must be of the spring and electronic type. Refer to the "Field Supply Parts" table for details. The valve cable must be (3 × min 1.5 mm²), and of type designation 60245 IEC 57 or heavier.
 - *Note: The two-way valve must be a CE-marked component.
 - The maximum load for the valve is 12 VA.
- 2. The three-way valve must be of the spring and electronic type. The valve cable must be (3 × min 1.5 mm²), and of type designation 60245 IEC 57 or heavier.
 - *Note: The three-way valve must be a CE-marked component.
 - The three-way valve must be directed towards the room by default.
 - The maximum load for the valve is 12 VA.
- 3. The room thermostat 1 cable must be (4 or 3 × min 0.5 mm²), and of type designation 60245 IEC 57 or heavier.
- 4. The maximum output power of the booster heater must be ≤ 3 kW. The booster heater cable must be (3 × min 1.5 mm²), and of type designation 60245 IEC 57 or heavier.
- 5. The extra pump cable must be (2 × min 1.5 mm²), and of type designation 60245 IEC 57 or heavier.
- 6. The boiler contact cable/defrost signal cable must be (2 × min 0.5 mm²), and of type designation 60245 IEC 57 or heavier.
- The external control must be connected to a 1-pole switch with a minimum 3.0 mm contact gap. Its cable must be (2 × min 0.5 mm²), and of type designation 60245 IEC 57 or heavier.
 - *Note: The switch used must be a CE-compliant component.
 - The maximum operating current must be less than $3 \, A_{rms}$.
- 8. The tank sensor must be of the resistance type. Refer to the graph below for the sensor's characteristics and details. Its cable must be (2 × min 0.3 mm²), double insulation layer (with an insulation strength of minimum 30 V) of either PVC-sheathed or rubber-sheathed.


Tank Sensor Resistance Vs Temperature



Tank sensor characteristic


- 9. The room temperature zone 1 cable must be (2 × min 0.3 mm²), double insulation layer (with an insulation strength of minimum 30 V).
- 10. The outdoor ambient sensor cable must be (2 × min 0.3 mm²), double insulation layer (with an insulation strength of minimum 30 V).
- The OLP for booster heater cable must be (2 × min 0.5 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
- 12. The buffer tank sensor cable must be (2 × min 0.3 mm²), double insulation layer (with an insulation strength of minimum 30 V).
- Connection to Optional PCB 5.
- Before connecting the cables to Optional PCB, remove the network adaptor holder (12) (Refer to the installation manual of CZ-NS7P for details).
- The water pump cables for zone 1 and zone 2 must be (2 × min 1.5 mm²), and of type designation 60245 IEC 57 or heavier.
- The solar water pump cable must be (2 × min 1.5 mm²), and of type designation 60245 IEC 57 or heavier.
- The pool water pump cable must be (2 × min 1.5 mm²), and of type designation 60245 IEC 57 or heavier.
- 4. The room thermostat 2 cable must be (4 or 3 × min 0.5 mm²), and of type designation 60245 IEC 57 or heavier.
- 5. The cables for mixing valves 1 and 2 must be (3 × min 1.5 mm²), and of type designation 60245 IEC 57 or heavier.
- 6. The room temperature zone 2 cable must be (2 × min 0.3 mm²), double insulation layer (with an insulation strength of minimum 30 V).
- 7. The pool temperature sensor and the solar temperature sensor cable must be (2 × min 0.3 mm²), double insulation layer (with an insulation strength of minimum 30 V).
- 8. The water temperature cables for zone 1 and zone 2 must be (2 × min 0.3 mm²), double insulation layer (with an insulation strength of minimum 30 V).
- The demand signal cable must be (2 × min 0.3 mm²), double insulation layer (with an insulation strength of minimum 30 V).

- 10. The SG signal cable must be (3 × min 0.3 mm²), double insulation layer (with an insulation strength of minimum 30 V).
- 11. The heat/cool switch cable must be (2 × min 0.3 mm²), double insulation layer (with an insulation strength of minimum 30 V).
- 12. The external compressor switch cable must be (2 × min 0.3 mm²), double insulation layer (with an insulation strength of minimum 30 V).
- How to access the Optional PCB 5.




12.1.4.2 Cable Arrangement

How to guide the optional cables and power supply cord connecting (view without internal wiring)



Terminal screw	Tightening torque cN•m {kgf•cm}
M4	157~196 {16~20}
M5	196~245 (20~25)




- Bushing hole A is used for power supply cable (including external heater power supply), outlet water sensor cable, OLP for signal line cable and ID-OD communication cable
- Bushing hole B and C are used for
- Water pump zone 1 cable
- Water pump zone 2 cable
- Solar water pump cable
- Pool water pump cable
- Room thermostat 1 cable
- Room thermostat 2 cable
- Booster heater cable
- Mixing valve 1 cable
- Mixing valve 2 cable
- 2-way valve cable
- 3-way valve cable
- Extra pump cable
- Boiler contact cable/Defrost signal cable
- Bushing hole D and E are used for
- External control cable
- Outdoor ambient sensor cable
- Remote controller cable
- Room temperature zone 1 cable
- Room temperature zone 2 cable
- Buffer tank sensor cable
- Pool temperature sensor cable
- OLP for booster heater cable
- Water temperature zone 1 cable
- Water temperature zone 2 cable
- Demand signal cable
- Solar temperature sensor cable
- SG signal cable
- Heat/Cool switch cable
- External compressor switch cable
- Tank sensor cable
- Ensure all sensor cables are not in touching the front panel.
- Once all wiring work is done, tie the cable with the banding strap (field supply).

12.1.4.3 Cable Length

When connecting cables between the Indoor Unit and external devices, the length of the cables must not exceed the maximum length as shown in the table below.

External device	Maximum cable length [m]
2-way valve, 3-way valve, Mixing valve, Room Thermostat, Booster heater, Extra pump, Solar water pump, Pool water pump, Zone water pump, Boiler contact/Defrost signal, External control, Demand signal, SG signal, Heat/Cool switch, External compressor switch, OLP for booster heater	50
Room temperature, Outdoor ambient sensor, Buffer tank sensor, Pool temperature sensor, Solar temperature sensor, Zone water temperature sensor, Tank sensor	30

12.1.4.4 Connection of PCB



Signal inputs

Room Thermostat	L N=AC230V, Heat, Cool=Thermostat heat, Cool terminals
OLP for booster heater	Dry contact: Vcc-Bit1, Vcc-Bit2 open/short (System setup necessary) It is connected to the safety device (OLP) of DHW tank.
External control	Dry contact: Open=not operating, Short=operating (System setup required) Operation can be switched on and off by an external switch.
Remote controller	Connected (Use 2 cores wire for relocation and extension. Total cable length shall be 50m or less.)


■ Thermistor inputs

Zone room sensor	PAW-A2W-TSRT
Outdoor ambient sensor	PAW-A2W-TSOD
Tank sensor	Use Panasonic specified part
Buffer tank sensor	PAW-A2W-TSBU

Outputs

3-way valve	AC230V N=Neutral Open, Close=direction (For switching the circuit when connecting to DHW tank)
2-way valve	AC230V N=Neutral Open, Close (Prevent water circuit pass in Cool mode)
Extra pump	AC230V (for use when the pump capacity of the indoor unit is insufficient).
Booster heater	AC230V (Used when using booster heater in DHW tank)
Boiler contact/ Defrost signal	Dry contact (System setup required)

12.1.4.5 Connection of Optional PCB (CZ-NS7P)



Signal inputs

Room Thermostat	L N =AC230V, Heat, Cool=Thermostat Heat/Cool terminals
SG signal	Dry contact Vcc-Bit1, Vcc-Bit2 Open/short (system setup required) Switching SW (Connect to 2-contact controller).
Heat/Cool switch	Dry contact Open=Heat, Short=Cool (System setup required)
External compressor switch	Dry contact Open=Comp.OFF, Short=Comp.ON (System setup required)
Demand signal	DC 0-10V (System setup required) Connect to a controller with DC 0-10V.

■ Thermistor inputs

Zone room sensor	PAW-A2W-TSRT
Pool water sensor	PAW-A2W-TSHC
Zone water sensor	PAW-A2W-TSHC
Solar sensor	PAW-A2W-TSSO


Outputs

Mixing valve	AC230V N=Neutral Open, Close=mixed Direction Operating time: 30s to 120s	AC230V, 6 VA
Pool water pump	AC230V	AC230V, 0.6 A max.
Solar water pump	AC230V	AC230V, 0.6 A max.
Zone water pump	AC230V	AC230V, 0.6 A max.


12.1.4.6 Recommended External Device Specification

This section explains about the external devices (optional) recommended by Panasonic. Always ensure to use the correct external device during system installation.


- Optional sensor.
- Buffer tank sensor: PAW-A2W-TSBU
 Use it to measure the buffer tank temperature.
 Insert the sensor into the sensor pocket on the tank.




Zone water sensor: PAW-A2W-TSHC
 Use it to measure the control zone temperature.
 Mount it on the water piping by using the stainless steel metal strap and contact paste (both are included).




3. Outdoor ambient sensor: PAW-A2W-TSOD If the installation location of the outdoor unit is exposed to direct sunlight, the outdoor air temperature sensor will be unable to measure the actual outdoor ambient temperature correctly.



4. Zone room sensor: PAW-A2W-TSRT Install the room temperature sensor to the room where the temperature control is required.



Solar sensor: PAW-A2W-TSSO
 Use it to measure the solar panel temperature.
 Insert the sensor into the sensor pocket and paste it on the solar panel surface.



See the table below for the characteristic of the sensors (No. 1 to 5).

Temperature (°C)	Resistance value (kΩ)
30	5.326
25	6.523
20	8.044
15	9.980
10	12.443
5	15.604
0	19.70
-5	25.05
-10	32.10
-15	41.45
-20	53.92
-25	70.53
-30	93.05
-35	124.24
-40	167.82

Temperature (°C)	Resistance value (kΩ)
150	0.147
140	0.186
130	0.236
120	0.302
110	0.390
100	0.511
90	0.686
80	0.932
70	1.279
65	1.504
60	1.777
55	2.106
50	2.508
45	3.003
40	3.615
35	4.375

Outlet water sensor: PAW-A2W-TSBH
 Use it to detect the water temperature of the
 In-line heater outlet water.
 Mount it on the water piping by using the stainless
 steel metal strap and contact paste (both items

are included).

Unit in mm

78

25

79

See the table below for the characteristic of the outlet water sensor (No. 6).

Temperature (°C)	Resistance value (kΩ)
30	16.07
25	20.00
20	25.07
15	31.67
10	40.35
5	51.85
0	67.24
-5	88.05
-10	116.49
-15	155.80
-20	210.77
-25	288.63
-30	400.41
-35	563.15
-40	803.72

Temperature (°C)	Resistance value (kΩ)
150	0.40
140	0.50
130	0.63
120	0.81
110	1.06
100	1.40
90	1.87
80	2.54
70	3.52
65	4.17
60	4.97
55	5.96
50	7.18
45	8.70
40	10.60
35	13.01


Optional pump

Each power supply: AC230V/50Hz, 0.6Amax

Total power supply: Less than 500W

Recommended part: Yonos Pico 1.0 25/1-8:

Manufactured by Wilo



· Optional mixing valve


Power supply: AC230V/50Hz, 5VA (Input

open/Output close)

Operating time: 120 seconds.


Recommended part: 13020800: Manufactured by

ESBE




12.1.4.7 Network Adaptor 2 Installation

- 1. Insert a flathead screwdriver into the slot on the network adaptor and remove the cover.
- 2. Connect cable coming out from the left side of the network adaptor holder to the connector inside the network adaptor.



3. Pull the CN-CNT cable through the hole in the bottom of the network adaptor and re-attach the front cover to the back cover.




4. Fix the network adaptor 2 to network adaptor holder.

Guide the cable as shown in the diagram so that external forces cannot act on the connector in the network adaptor.


12.1.4.8 Connection of M-Bus or Modbus, etc.

When connecting devices such as Panasonic A2W compatible M-Bus or Modbus, it is necessary to change the connection position of the network adaptor on the PCB.



- Replace the lead wire connector of the network adaptor connected to CN-CNT2 with CN-CNT.
- Insert the M-Bus or Modbus, etc. lead wire connector into CN-CNT2.

When connecting Optional PCB to devices such as M-Bus or Modbus, it is necessary to change the connection position of the network adaptor on the PCB.



- Insert the Optional PCB lead wire connector into CN-CNT.
- Replace the lead wire connector of the network adaptor connected to CN-CNT2 with CN-CNT on Optional PCB.
- Insert the M-Bus or Modbus, etc. lead wire connector into CN-CNT2.

12.1.5 Install Remote Controller as Room Thermostat

♠ WARNING

This section is for authorized and licensed electrician only. Work behind the front cover ① secured by screws must only be carried out under the supervision of a qualified contractor, installation engineer, or service person.


 Remote controller 3 mounted to the indoor unit can be moved to the room and serve as a Room Thermostat.

12.1.5.1 Installation Location

- Install at the height of 1 to 1.5 m from the floor where average room temperature can be detected properly.
- Install vertically against the wall.
- Avoid the following locations for installation.
 - Location exposed to direct sunlight or direct air.
 - 2. In the shadow or backside of objects deviated from the room airflow.
 - 3. Location where condensation occurs (The remote controller is not moisture proof or drip proof.)
 - 4. Location near heat source.
 - 5. Uneven surface.
- Keep distance of 1 m or more from the TV, radio and PC.

(Cause of fuzzy image or noise)


12.1.5.2 Wiring the Remote Controller




- Remote controller cable shall be 2 × min 0.3 mm², of double insulation PVC-sheathed or rubber sheathed cable. Total cable length shall be 50 m or less.
- Do not connect cables to other terminals of Indoor Unit (e.g. power source wiring terminal); malfunction be caused.
- Do not bundle together with the power supply cable or store in the same metal tube; operation error may be caused.
- When using a second remote controller (optional), connect it to the terminal of the indoor unit and secure it tightly.

12.1.5.3 Remove the Remote Controller from the Indoor Unit


1. Remove both left and right decoration panel (10) and (11) from the front cover (1) while gently pushing them from the behind.




2. Remove the 4 screws and take out the holder with remote controller (3).



3. Remove the body from the base.




4. Remove the cable between remote controller ③ and Indoor Unit terminal.



12.1.5.4 Mounting the Remote Controller


For exposure type

Preparation: Make 2 holes for the screws using a screwdriver.




For embedded type

Preparation: Make 2 holes for the screws using a screwdriver.



12.1.5.5 Replace the Remote Controller Cover

- Replace the existing remote controller with remote controller Case To plug the hole after removing the remote controller, fit a remote controller case 3 in place of the removed remote controller:
 - Refer Section "Remove the remote controller from the indoor unit" for removing the remote controller.
 - 2. Remove the body from the base of the remote controller case 3.



3. Reverse steps 1-4 in the section "Remove the remote controller from the indoor unit" to secure the remote controller case 3 to the indoor unit.

12.1.6 Check RCCB/ELCB

12.1.6.1 Check the RCCB/ELCB

Ensure that the RCCB/ELCB is in the "ON" position before performing any checks.

Turn ON the indoor unit.

This test can only be conducted when power is supplied to the indoor unit.

↑ WARNING

When power is supplied to the indoor unit, avoid touching any parts other than the RCCB/ELCB test button to prevent an electric shock. Before accessing the terminals, all supply circuits must be disconnected.

Press the TEST button on the RCCB/ELCB. The lever would turn down if it is functioning correctly.

- If the RCCB/ELCB malfunctions, contact an authorized dealer.
- Turn OFF the indoor unit.
- If the RCCB/ELCB operates correctly, set the lever to 'ON' again after the test.

12.1.7 Close Front Cover

Gently close the front cover and fix with 2 screws.


Tightening torque cN•m {kgf•cm} 147

12.1.8 Reconfirmation

12.1.8.1 Check Water Pressure

*(0.50 bar = 0.05 MPa)


Water pressure must not be lower than 0.50 bar. (Check the water pressure by the remote controller.) If it is lower, fill Space Heating/Cooling pipes with water through the tube connector on the outdoor unit.



12.1.8.2 Check Pressure Relief Valve

*The pressure relief valve is located on the outdoor unit.

- 1. Pull the lever horizontally and verify that the pressure relief valve is functioning correctly.
- Release the lever when water begins to flow from the drain pipe of the pressure relief valve. If air continues to come out of the drain pipe, keep raising the lever until all the air is fully discharged.
- Verify that the water flow from the drain pipe has stopped.
- 4. If water is leaking, pull the lever several times and then return it to ensure that the leak stops.
- 5. If water continues to flow from the drain, drain the water from the system. Turn OFF the system and contact your local authorized dealer.



12.1.8.3 Check for Air Accumulation

 Open the air vent plugs on the heating panel, fan convector, etc., and remove the air accumulated in the equipment and piping.

12.1.8.4 Expansion Vessel Pre Pressure Check

 The system where the Indoor Unit is installed should be equipped with an expansion vessel with the initial pressure of 1 bar.

12.1.9 Test Run

- Before the test run ensure that the following items are checked:
 - a) Pipework is properly installed.
 - b) Electrical cable connections are correctly made.
 - c) The indoor unit is filled with water and all trapped air is released.
 - Turn ON the power supply after the indoor unit is completely filled.
- Switch ON the power supply of the indoor unit. Set the indoor unit RCCB/ELCB (5) to the "ON" position. Then, please refer to the Operation Instruction for using the remote controller (3).

Note

During winter, turn ON the power supply and allow the unit to stand by for at least 15 minutes before conducting a test run. This will give the refrigerant sufficient time to warm up and help prevent incorrect error code readings.

- 3. For normal operation, the water pressure should be between 0.5 bar and 4 bar (0.05 MPa and 0.4 MPa). If the pressure is outside this range, adjust the water pump speed to achieve the correct pressure. If adjusting the speed of the water pump does not resolve the issue, contact a local authorized dealer.
- After the test run, clean the magnetic water filter set according to the "Maintenance for Magnetic Water Filter" section in the Installation Manual of the AIR-TO-WATER HEATPUMP OUTDOOR UNIT. Reinstall the filter after cleaning.

12.1.9.1 Check Water Flow of the Water Circuit

Select Installer setup \rightarrow Service setup \rightarrow Pump maximum speed \rightarrow Air purge.

Confirm that the maximum water flow rate is not less than 25 l/min when the main pump is in operation.

- Water flow can be checked in Service setup (Pump maximum speed)
 [Heating operation at low water temperature with lower flow rate may cause "H75" during defrost process.]
- * If there is no water flow or H62 is displayed, stop pump operation and release the air (See "CHECK AIR ACCUMULATION").

12.1.10 Maintenance

- To ensure the safety and optimum performance of the indoor unit, seasonal inspections of the indoor unit and functional checks of RCCB/ELCB, field wiring and pipe should be carried out on a regular basis. This maintenance and scheduled inspection should be carried out by authorized dealer.
- Regular maintenance of the expansion vessel (at least once a year) is recommended and should be performed by authorized dealer. First, make sure that the expansion or pressure tank is completely drained of water, that the system is switched off, and that there are no live electrical components. If you need to reset the preload pressure, set 1bar.

12.2 Appendix


12.2.1 Variation of System


This section introduces some variation of systems using Air-To-Water Heat pump and actual setting method. For this model, the Zone 1 external room thermistor and Zone 1 external room thermostat must be always connected to the main room board, irrespective of whether they are connected to a board (CZ-NS7P) sold separately.

12.2.1.1 Introduce Applications Related to Temperature Setting

12.2.1.1.1 Temperature Setting Variation for Heating


Remote controller





- Connect floor heating and radiators directly to the outdoor unit.
- The remote controller is located on the indoor unit.
- This is the simplest system.

2. Room thermostat




Connect floor heating and radiators directly to the outdoor unit.

Remove the remote controller from the indoor unit and install it in the room where the floor heating is installed. This is an application that uses remote controller.

Refer to 12.1.5 Install Remote Controller as Room Thermostat (Optional).

3. External room thermostat




Connect floor heating and radiators directly to the outdoor unit.

The remote controller is located on the indoor unit.

Install separate External Room Thermostat (field supply) in the room where floor heating is installed.

This is an application that uses External Room Thermostat.

4. Room thermistor



Connect floor heating or radiator directly to the outdoor unit.

The remote controller is located on the indoor unit.

An external room thermistor (specified by Panasonic) is installed in the room where the floor heating is installed.

This is an application that uses an external room thermistor.

There are two ways of setting the circulating water temperature.

Direct: Sets the circulating water temperature directly (fixed value).

Correction curve: sets the circulating water temperature according to the outside temperature.

In case of Room thermistor, the compensation curve is shifted according to the thermo ON/OFF situation.


• (Example) If room temperature increasing speed is;

Very slow \rightarrow Shift the compensation curve upwards

Very fast → Shift compensation curve downwards

12.2.1.1.2 Examples of Installations

Floor heating 1 + Floor heating 2



Connect Floor heating to the 2 circuits via buffer tank as shown in the figure.

Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits.

Remove the remote controller from the indoor unit and attach it to either circuit to use as a Room Thermostat.

Install an external Room Thermostat (field-supply) on a another circuit.


Both circuits can set the circulating water temperature independently.

Install the buffer tank thermistor on the buffer tank.

The buffer tank connection settings and the ΔT temperature settings for heating operation are required separately. This system requires an Optional PCB (CZ-NS7P).

Note: Buffer tank thermistor must be connected to PCB (4).

Floor heating + Radiator



Connect Floor heating and radiators to the 2 circuits via buffer tank, as shown in the figure above. Install pumps and thermistors (specified by Panasonic) on both circuits.

Install a mixing valve in the circuit with lower temperature among the 2 circuits. (Generally, where floor heating and radiator circuits are installed in 2 zones, install mixing valve in the floor heating circuit.)


The remote controller is located on the indoor unit.

The temperature setting selects the circulating water temperature for both circuits. Both circuits can be set the circulating water temperature independently.

Install thermistor on the buffer tank. The buffer tank connection settings and the ΔT temperature settings for heating operation are required separately.

This system requires the Optional PCB (CZ-NS7P). Note: if there is no mixing valve on the secondary side, the circulating water temperature may be higher than the set temperature.

Note: Buffer tank thermistor must be connected to PCB (4).



Connect floor heating and swimming pool to the 2 circuits via buffer tank, as shown in the figure above.

Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits.

Additional pool heat exchanger, pool pumps and pool sensor are installed in the pool circuit.

Remove the remote controller from the indoor unit and install it in the room where the floor heating is installed. The floor heating and the pool circulation water temperatures can be set separately. Install thermistor on the buffer tank.


The buffer tank connection settings and the ΔT temperature settings for heating operation are required separately. This system requires the Optional PCB (CZ-NS7P).

*Be sure to connect the pool to "Zone 2".

When connected to a swimming pool, operating in 'Cool' will stop the pool operation.

Note: Buffer tank thermistor must be connected to PCB (4).

Swimming pool only



This is an application that connect to the swimming pool only.

Connect the pool heat exchanger directly to the tank unit without buffer tank.


Install a pool pump and pool thermistor (specified by Panasonic) at the secondary side of the pool heat exchanger.

The pool temperature can be set with a remote controller.

This system requires the Optional PCB (CZ-NS7P).

The cooling mode cannot be selected for this application. (Not displayed on the remote controller).

Simple 2 zone (Floor heating + Radiators)



This is an example of simple 2 zone control without buffer tank.

The built-in pump in the Outdoor unit acts as the pump for zone 1.

Install mixing valve, pump and thermistor (specified by Panasonic) at zone 2 circuit.

The temperature in Zone 1 is not adjustable, so always assign the hot side to Zone 1.

To display the temperature of zone 1 on the remote controller, zone 1 thermistor is required.

The circulating water temperature for both circuits can be set independently.

(However, the temperature of high temperature side and low temperature side cannot be reversed.)

This system requires the Optional PCB (CZ-NS7P).


Note:

- Thermistor 1 has no direct influence on the operation. However, if thermistor 1 is not installed, an error will occur.
- Adjust the flow rate so that zone 1 and zone 2 are balanced. If not correctly adjusted, performance may be
 affected.

(If the pump flow rate in zone 2 is too high, hot water may not flow to zone 1)

The flow rate can be checked from "Actuator Check" under maintenance menu.

Buffer tank connection




This is an application that connects the buffer tank to the indoor unit.

The temperature of the buffer tank is detected by a buffer tank thermistor (specified by Panasonic).

If Optional PCB is not connected, external pump can be used for circulation in the floor heating circuit.

Note: Buffer tank thermistor must be connected to PCB (4).



This is an application that connect the buffer tank unit to the indoor unit and then to the solar water heater to heat the buffer tank.

The temperature of the buffer tank is detected by a buffer tank thermistor (specified by Panasonic).

The temperature of the solar panel is detected by a solar thermistor (specified by Panasonic).

Buffer tanks are stand-alone tanks with built-in solar heat exchange coils.


During winter season, solar pump for circuit protection will be activated continuously. If you wish not to activate the solar pump operation, use glycol and set the anti-freezing operation start temperature to -20°C.

Heat accumulation operates automatically by comparing the temperature of tank thermistor and solar thermistor.

This system requires the Optional PCB (CZ-NS7P).

Note: Buffer tank thermistor must be connected to PCB (4).

Boiler connection



This is an application that connects the boiler to the buffer tank, to compensate for insufficient capacity by operate boiler when outdoor temperature drops & heat pump capacity is insufficient.

Boiler is connected parallel with heat pump and used as heating circuit.

The boiler output can be controlled either by SG-ready input from a board (sold separately) or by automatic control via three mode selection patterns.

(Operation setting of boiler shall be responsible by installer.)

This system requires the Optional PCB (CZ-NS7P) for SG-ready input control.

Depending on the settings of the boiler, it is recommended to install buffer tank as temperature of circulating water may get higher. (In particular, if the advanced parallel setting is selected, it must be connected to a buffer tank.) Note: Buffer tank thermistor must be connected to PCB 4.




/ CAUTION

Make sure the boiler and its integration in the system complies with applicable legislation. Ensure that the return water temperature from the heating circuit to the indoor unit does not exceed 70°C. Boiler is turned off by safety control when the water temperature of the heating circuit exceed 85°C.

12.2.2 System Installation


12.2.2.1 Remote Controller Outline

The LCD display as shown in this manual are for instructional purpose only, and may differ from the actual unit.



Name Function A: Main screen Display information Open/Close the main menu B: Menu C: Triangle (Move) Select and change item D: Operate Start/Stop operation Back to previous item E: Back F: Quick Menu Open/Close the Quick menu Confirm G: Enter

(Actual - Dark background with white icons).



1: Function icon

Displays the set functions/status.

Holiday mode

Demand control

Weekly timer

Quiet mode

Remote controller room thermostat

Solar

Powerful mode

8 Boiler

Water pressure (circulation circuit) () (1.50) Displays water pressure in bar (blinks when less than 0.5)

Heat pump operating

3: Mode

Displays the setting mode and the current mode status.

• Heating

Street Cooling Hot water

Auto

supply

Auto heating

Auto cooling

Temp setting

Set room temp

Compensation ↓ ♦ Set direct water temp

Set pool temp

Displays outdoor temperature

Outdoor temp

Displays current tank temperature (it is set temperature when enclosed by line)

Displays current heating temperature (it is set temperature when enclosed by line)

Electrical anodes

Display Heat temp


Display tank temp


Normal

Abnormal (Flashing)


Not used (Hidden)


First time of power ON (Start of installation)






12.2.2.2 Installer Setup







12.2.2.3 System Setup

1. Optional PCB connectivity

Initial setting: No

If any functions below is necessary, purchase and install (CZ-NS7P). Select Yes after installing it.

- 2-zone control
- Pool
- Solar
- · External error signal output
- · Demand control
- · SG ready
- · Stop heat source unit by external SW
- · Heat-Cool SW

2. Zone & Sensor

Initial setting: Room and Water temp.

If there is no Optional PCB

Select sensor of room temperature control from the following 3 items

- (1) Water temperature (circulation water temperature)
- 2 Room thermostat (Internal or External)
- (3) Room thermistor

If there is Optional PCB

(1) Select either 1-zone control or 2 zone control.

For 1-zone, select either room or pool, select sensor

For 2-zone, select the sensor in zone 1, then the either room or pool for zone 2 and select the sensor

Note: In 2-zone system, pool function can be set to zone 2 only.

System setup	12:00 pm, Mon
Optional PCB conne	ectivity
Zone & Sensor	
Heater capacity	
Anti freezing	
Select	[→] Confirm

3. Heater capacity

Initial setting: Depend on model

If there is external heater, set the heater capacity.

Note: Some heaters cannot select the capacity.

System setup	12:00 pm, Mon
Optional PCB connectivity	ty
Zone & Sensor	
Heater capacity	
Anti freezing	
♣ Select [←] Confirm

4. Anti freezing

Initial setting: Yes

Operate anti-freezing of water circulation circuit.

If set to yes, the pump will start when the water temperature reaches its freezing temperature.

If the temperature does not reach the pump stop temperature, heat pump will be activated.

Note: If set to No, when the water temperature reaches its freezing temperature or below, the water circulation circuit may freeze and cause malfunction.

5. Tank connection

Initial setting: No

Select whether it is connected to hot water tank or not. If set to Yes, it enables the hot water function settings. Hot water temperature of the tank can be set from main screen.

System setup 12:00 pm, Mon
Zone & Sensor
Heater capacity
Anti freezing
Tank connection

\$\Displays \text{ Select} \text{ Confirm}\$

6. DHW capacity

Initial setting: Variable

Variable DHW capacity setting normally run with efficient boiling which is energy saving heating. However while hot water usage high and tank water temperature low, variable DHW mode run with fast heat up which heat up the tank with high heating capacity.

If standard DHW capacity setting is selected, heat pump run with heating rated capacity at tank heat up operation.

System setup	12:00 pm, Mon
Heater capacity	
Anti freezing	
Tank connection	
DHW capacity	
Select	[←] Confirm

7. Buffer Tank connection

Initial setting: No

Select whether it is connected to buffer tank for heating or not. If buffer tank is used, set to Yes.

Connect buffer tank thermistor and set ΔT (ΔT use to increase primary side temperature against secondary side target temperature).

If the buffer tank capacity is not so large, set larger value for ΔT .

System setup 12:00 pm, Mon
Anti freezing
Tank connection
DHW capacity
Buffer tank connection

Select [4] Confirm

8. Tank heater

Initial setting: External


Note: Does not display if there is no tank for hot water supply.

Set "Tank heater" to "ON" in the "Function setup" from remote controller when using heater to boil the tank.

External A setting which is using booster heater installed on DHW tank to boil the tank.

The permissible heater capacity is 3kW and below. The operation to boil the tank with heater is as below. In addition, set the "Tank heater: ON time" appropriately.

For 75°C setting



9. Base pan heater

Initial setting: No

Select whether Base pan heater is installed or not. If set to Yes, select to use either heater A or B.


A: Turn ON Heater when heating with defrost operation only

B: Turn ON Heater at heating

10. Alternative outdoor sensor Initial setting: No Set to Yes if outdoor sensor is installed. Controlled by optional outdoor sensor without reading the outdoor sensor of heat pump unit. System setup Buffer tank connection Tank heater Base pan heater Alternative outdoor sensor

Select

[←] Confirm



After Bivalent connection set YES, there are three options of control pattern (Auto / SG Ready / Smart).


1) Auto

There are 3 different modes in the boiler auto pattern operation. Movement of each modes are shown below.

- 2 Alternative (switch to boiler operation when drops below setting temperature)
- 3 Parallel (allow boiler operation when drops below setting temperature)
- 4 Advanced Parallel (able to slightly delay boiler operation time of parallel operation)

When the boiler operation is "ON", "boiler contact" is "ON", "_"(underscore) will be displayed below the boiler icon. Set target temperature of boiler to be the same as heat pump temperature.

When boiler temperature is higher than heat pump temperature, zone temperature cannot be achieved if mixing valve is not installed. This product only allows one signal to control the boiler operation. Operation setting of boiler shall be responsible by installer.



In Advanced Parallel mode, setting for both heating and tank can be made simultaneously. During operation of "Heating/Tank" mode, when each time the mode is switched, the boiler output will be reset to OFF. Please have a good understanding on the boiler control characteristic in order to select the optimal setting for the system.

- 2) SG ready (Only available to set when optional PCB set to YES)
 - SG Ready input from optional PCB terminal control ON/OFF of boiler and heat pump as below condition

SG signal		Operation pattern	
Vcc-bit1	Vcc-bit2		
Open	Open	Heat pump OFF, Boiler OFF	
Short	Open	Heat pump ON, Boiler OFF	
Open	Short	Heat pump OFF, Boiler ON	
Short	Short	Heat pump ON, Boiler ON	

* This bivalent SG ready input is sharing same terminal as [16. SG ready] connection. Only one of these two setting can be set at the same time.

When one is set, another setting will reset to not set.


There are Energy price (both electricity and boiler) and Schedule to be set on remote controller.

Operation setting of Energy price and Schedule shall be responsible by installer.

Based on these settings, system will calculate the final price for both electricity and boiler.

When final price of Electricity is lower than Boiler's, heat pump will operate.

When final price of Electricity is higher than Boiler's, boiler will operate.



12. External SW Initial setting: No

Able to turn ON/OFF the operation by external switch.

12:00 pm, Mon System setup Base pan heater Alternative outdoor sensor Bivalent connection External SW [←] Confirm Select

[📤] Confirm

12:00 pm, Mon

System setup

Alternative outdoor sensor

Bivalent connection External SW

Solar connection

Select

13. Solar connection

Initial setting: No

Set when solar water heater is installed.

Setting include items below.

- 1) Set either buffer tank or DHW tank for connection with solar water heater.
- (2) Set temperature difference between solar panel thermistor and buffer tank or DHW tank thermistor to operate the solar pump.
- ③ Set temperature difference between solar panel thermistor and buffer tank or DHW tank thermistor to stop the solar pump.
- Anti-freezing operation start temperature (change setting based on usage of glycol.)
- Solar pump stop operation when it exceeds high limit temperature (when tank temperature exceed designated temperature (70~90°C))

Note: Does not display if there is no Optional PCB. System setup 12:00 pm, Mon 14. External Error Signal Initial setting: No

Set when external error display unit is installed.

Turn ON Dry Contact SW when error happened.

Note: Does not display if there is no Optional PCB.

When error occurs, error signal will be ON.

After turn OFF "close" from the display, error signal will still remain ON.

	Bivalent connection
	External SW
ĺ	Solar connection
	External error signal
	♣ Select [♣] Confirm

15. Demand control

Initial setting: No

Set when there is demand control.

Adjust terminal voltage within 1 \sim 10 V to change the operating current limit.

Note: Does not display if there is no Optional PCB.

12:00 pm, Mon

[🗗] Confirm

Analog input [v]	Rate [%]		
0.0 0.1 ~ 0.6	4	not activate	
0.7 0.8		10	not activate
0.9 ~ 1.1		,	10
1.2 1.3		15	10
1.4 ~ 1.6		,	15
1.7 1.8		20	15
1.9 ~ 2.1		2	20
2.2		25	20
2.4 ~ 2.6		2	25
2.7		30	25
2.9 ~ 3.1		30	
3.2 3.3		35	30
3.4 ~ 3.6		35	
3.7 3.8		40	35

Analog input [v]			ate %]
3.9 ~ 4.1	7		10
4.2		45	40
4.4 ~ 4.6		4	5
4.7		50	45
4.9 ~ 5.1		5	0
5.2 5.3		55	50
5.4 ~ 5.6	П	5	55
5.7 5.8		60	55
5.9 ~ 6.1		6	0
6.2 6.3		65	60
6.4 ~ 6.6		6	35
6.7 6.8		70	65
6.9 ~ 7.1		7	70
7.2		75	70

Analog input [v]		Rate [%]		
7.4 ~ 7.6		▲ 75		
7.7	ĺ	80	75	
7.8		00	75	
7.9 ~ 8.1		80		
8.2		85	80	
8.3		65	60	
8.4 ~ 8.6		85		
8.7		90	85	
8.8		90	0.5	
8.9 ~ 9.1	Ш	90		
9.2		95	90	
9.3		93	90	
9.4 ~ 9.6	95			
9.7		100	95	
9.8			90	
9.9 ~	100			

Select

^{*}A minimum operating current is applied on each model for protection purpose.
*0.2 voltage hysteresis is provided.

^{*}The value of voltage after 2nd decimal point are cut off.

16. SG Ready Initial setting: No System setup 12:00 pm, Mon Solar connection Switch operation of heat pump by open-short of 2 terminals. External error signal The following settings are possible. Capacity: limit by capacity. Demand control Power consumption: limit by power consumption. SG Ready [←] Confirm Select SG signal Operation pattern Vcc-bit1 Vcc-bit2 Open Open Normal Heat pump/heater OFF Short Open Open Short Capacity 1 Short Capacity 2 Short Select Capacity Capacity setting 1 DHW capacity - Heating capacity ____%. - Cooling capacity ____°C Capacity setting 2 SG ready - Yes - Capacity setting - DHW capacity ____%. - Heating capacity ____%. - Cooling capacity ____°C Select Power consumption HPU stop consumption kW HPU stop consumption value never exceeded If the value is exceeded, heating is provided by the heater only. Power consumption setting 1 - Power consumption of DHW ____kW - Heating power consumption ____kW SG ready - Yes - Power consumption setting

Cooling power consumption ____kW

Power consumption of DHW ___kWHeating power consumption kW

*Optional functions means Solar, Boiler, zone control and so on.

Note: Does not display if there is no Optional PCB.

Power consumption setting 2

- Cooling power consumption ___ kW (If SG ready is set to 'Yes', Bivalent control pattern is set to 'Auto'). Note: Does not display if there is no Optional PCB. 12:00 pm, Mon 17. External compressor SW Initial setting: No System setup External error signal Set when external compressor SW is connected. Demand control After external compressor SW set to Yes, there are 2 options of control pattern to be select (Heat source / Heater), SG Ready 1) Heat source External compressor SW Open signal will stop Heat pump, Outdoor water pump and Heater (Booster [←] Confirm Heater and back-up Heater) operations. Select Optional functions are not canceled. 2) Heater Open signal will stop back-up heater operations. Heat pump and optional functions are not canceled.

19. Heat-Cool SW

Initial setting: Disable

Able to switch (fix) heating & cooling by external switch.

(Open): Fix at Heating (Heating +DHW) (Short): Fix at Cooling (Cooling +DHW)

Note: This setting is disabled for model without Cooling. Note: Does not display if there is no Optional PCB.

Timer function cannot be used. Cannot use Auto mode.

System setup 12:00 pm, Mon
SG Ready
External compressor SW

Circulation liquid
Heat-Cool SW

Select

[] Confirm

20. Force Heater

Initial setting: Manual

Under manual mode, user can turn ON force heater through quick menu.

If selection is 'auto', force heater mode will turn automatically if pop up error happen during operation.

Note: When external heater is No and tank heater is OFF, force heater does not turn ON even if selection is 'auto'.

Force heater operation follows the latest mode selection. Mode selection is disable under force heater operation.

Heater source will ON during force heater mode.

System setup 12:00 pm, Mon

External compressor SW

Circulation liquid

Heat-Cool SW

Force heater

Select

[🞝] Confirm

12:00 pm, Mon

21. Force Defrost

Initial setting: Manual

Under manual mode, user can turn ON force defrost through quick menu.

If selection is 'auto', outdoor unit will run defrost operation once if heat pump have long hour of heating without any defrost operation before at low ambient condition. (Even if auto is selected, user still can turn ON force defrost through quick menu)

System setup

Circulation liquid

Heat-Cool SW

Force heater

Force defrost

\$\textsquare\$ Select [←] Confirm

22. Defrost signal

Initial setting: No

Defrost signal and bivalent connection have the same connection port in the main PCB. When defrost signal set to YES, bivalent connection reset to NO. Only one function can be set between defrost signal and bivalent.

When defrost signal set to YES, during defrost operation is running at outdoor unit defrost signal contact turn ON. Defrost signal contact turn OFF after defrost operation end.

(Purpose of this contact output is to stop indoor fan coil or water pump during defrost operation).

System setup 12:00 pm, Mon

Heat-Cool SW

Force heater

Force defrost

Defrost signal

Select [←] Confirm

23. Pump flowrate

Initial setting: ∆T

If pump flowrate setting is ΔT , unit adjust pump duty to get different of water inlet and outlet base on setting on * ΔT for heating ON and * ΔT for cooling ON in operation setup menu during room side operation.

If pump flowrate setting is set to Max. duty, unit will set the pump duty to the set duty at *Pump maximum speed in service setup menu during room side operation.

System setup 12:00 pm, Mon

Force heater

Force defrost

Defrost signal

Pump flowrate

; Select [←] Confirm

24. DHW defrost

Initial setting: Yes

When DHW defrost set to YES, hot water of domestic hot water tank will be used during defrost cycle.

When DHW defrost set to NO, hot water of floor heating circuit will be used during defrost cycle.

System setup	12:00 pm, Mon
Force defrost	
Defrost signal	
Pump flowrate	
DHW Defrost	
Select	[🗗] Confirm

25. Heating control

Initial setting: Comfort

Compressor frequency control can be selected from two modes: Comfort and Efficiency.


Select "Comfort"

- The compressor operates at the maximum frequency at the upper zone limit and reaches the set temperature faster.

Select "Efficiency"

 The compressor frequency is gradually increased to reduce power consumption. The system have 3 steps to achieve maximum compressor frequency. You can set period time of each stage on R/C.

(compressor frequency for each stage)
1st stage: 50% of the maximum frequency
2nd stage: 66% of the maximum frequency
3rd stage: 83% of the maximum frequency




Total time

26. External meter

Initial setting: [Heat-cool meter : No]

Tank meter : No] *only available when Heat-cool meter select Yes [Elec. meter HP : No]

[Elec. meter 1 (PV meter) : No] [Elec. meter 2 (Building) : No] [Elec. meter 3 (Reserve) : No]



1st stage 2nd stage 3rd stage

There are two systems for generation meter connection : one generation meter system (Heat-cool meter) or two generation meter system (Heat-cool meter and Tank meter)

Both systems can provide all generation data of heating, cooling and DHW directly from external meter.

If Heat-cool meter is set to Yes, it will read from external meter for heat pump's energy generation data during heating, cooling and DHW operation*1.

If Heat-cool meter is set to No, it will base on unit's calculation for heat pump's energy generation data during heating, cooling and DHW operation.

If Tank meter is set to Yes, it will read from external meter for heat pump's energy generation data during DHW operation *1.

If Elec. meter HP is set to Yes, it will read from external meter for heat pump's energy consumption data.

If Elec. meter HP is set to No, it will base on unit's calculation for heat pump's energy consumption data.

If Elec. meter 1 (PV meter) is set to Yes, it will read from external meter for energy generation data of solar system and display it on Cloud system.

If Elec. meter 2 (Building) is set to Yes, it will read from external meter for energy consumption data of the building and display it on Cloud system.

If Elec. meter 3 (Reserve) is set to Yes, it will read from external meter for energy consumption data obtained from reserved electricity meter and display it on Cloud system.

¹ Set Heat-cool meter to Yes and set Tank meter to No when 1 generation meter system is installed.

Set Heat-cool meter to Yes and set Tank meter to Yes when 2 generation meter system is installed.

Remark: Elec. meter HP refers to Electricity meter that measures Heat Pump unit's consumption.

Elec. meter 1 / 2 / 3 refers to Electricity meter no. 1 / no. 2 / no. 3

27. Electrical anode

Initial setting: No

Power can be supplied from the indoor unit when an electric anode is attached to an external tank.

System setup 12:00 pm, Mon

DHW Defrost
Heating control
External meter

Electrical anode

Select [] Confirm

28. Extra pump Selects whether the circulation circul

Initial setting: Heat

Selects whether the extra pump is used in the circulation circuit for heating or in the circulation circuit for DHW, or it is not used.

If select for DHW, make choices such as the pump ON/OFF time and whether Comfort or Etticiency is a priority.


Select DHW

- Pump ON time 8:00 - Pump OFF time 20:00

Select Comfort (Exit extra pump settings)

Select Efficiency

- ON time 0:15 (0:05 ~ 1:00) - OFF time 0:15 (0:05 ~ 1:00)



29. External heater

Initial setting: No

Select the type of external heater.

"In-line": Select this if you're using the external heater as an In-line heater.

"Buffer tank": Select this if you're using the external heater as a buffer tank heater.

Please refer to 12.1.3 Connect the Cable to the Indoor Unit "how to install external heater" for details.

System setup	12:00 pm, Mon
External meter	·
Electrical anode	
Extra pump	
External heater	
Select	[🗗] Confirm

30. Static pressure

Initial setting: No

If set to No, the outdoor fan motor operates at a normal speed.

If set to YES, the outdoor fan motor operates at a higher speed than normal in response to high static pressure.

System setup	12:00 pm, Mon
Electrical anode	
Extra pump	
External heater	
Static pressure	
Select	[🞜] Confirm

31. Cooling capacity

Initial setting: Efficiency

Select the cooling capacity.

If set to "Efficiency", the unit performs cooling operation efficiently at rated capacity. If set to "Comfort", the cooling operation is performed at maximum capacity.

12.2.2.4 Operation Setup

Heat

32. Water temp. for heating ON


Initial setting: compensation curve

Set target water temperature to operate heating operation.

Compensation curve: Target water temperature change in conjunction with outdoor ambient temperature change.

Direct: Set direct circulation water temperature.

In 2 zone system, zone 1 and zone 2 water temperature can be set separately.



33. Outdoor temp. for heating OFF

If the operation of the outdoor unit is frequently switched on and off depending on the outdoor air temperature, the following settings can be used to reduce the frequency.

a. Outdoor temp. for heating OFF

Initial setting: 24°C

Set outdoor temp. to stop heating Setting range is 6°C~35°C


b. Outdoor temp. for heating ON Initial setting: 23°C


Set outdoor temp. to start heating.

Setting range is 5°C~X°C (X is heating OFF temp. -1)

c. Heating ON delay time Initial setting: 0:30min

Set delay time from heating OFF to heating ON.






34. ΔT for heating ON

Initial setting: 5°C

Set temp difference between out temp & return temp of circulating water of Heating operation.

When temp gap is enlarged, it is energy saving but less comfort. When the gap gets smaller, energy saving effect gets worse but it is more comfortable. Setting range is $1^{\circ}C\sim15^{\circ}C$



35. Heater ON/OFF

a. Outdoor temp. for heater ON

Initial setting: 0°C

Set outdoor temp when back-up heater starts to operate.

Setting range is -20°C ~ 15°C

User shall set whether to use or not to use heater.

b. Heater ON delay time

Initial setting: 30 minutes

Set delay time from compressor ON for heater to turn ON if not achieve water set temperature.

Setting range is 10 minutes ~ 60 minutes

c. Heater ON: ΔT of target Temp

Initial setting: -4°C


Set water temperature for heater to turn ON at heat mode. Setting range is -10°C ~ -2°C


d. Heater OFF: ΔT of target Temp


Initial setting: -2°C

Set water temperature for heater to turn OFF at heat mode. Setting range is $-3^{\circ}C \sim 0^{\circ}C$

106







Cool

36. Water temp. for cooling ON

Initial setting: compensation curve


Set target water temperature to operate cooling operation.

Compensation curve: Target water temperature change in conjunction with

Direct: Set direct circulation water temperature.

In 2 zone system, zone 1 and zone 2 water temperature can be set separately.

outdoor ambient temperature change.




37. ΔT for cooling ON

Initial setting: 5°C

Set temp difference between out temp & return temp of circulating water of Cooling operation.

When temp gap is enlarged, it is energy saving but less comfort. When the gap gets smaller, energy saving effect gets worse but it is more comfortable. Setting range is 1° C ~ 15° C




Auto

38. Outdoor temp. for (Heat to Cool)

Initial setting: 15°C

Set outdoor temp that switches from heating to cooling by Auto setting. Setting range is $11^{\circ}C \sim 25^{\circ}C$

Timing of judgement is every 1 hour




39. Outdoor temp. for (Cool to Heat)

Initial setting: 10°C


Set outdoor temp that switches from Cooling to Heating by Auto setting. Setting range is 5° C $\sim 14^{\circ}$ C


Timing of judgement is every 1 hour



Tank

40. Floor operation time (max) Initial setting: 8h Heat Set max operating hours of heating. When max operation time is shortened, it can boil the tank more frequently. 30min ~ 10h Setting range is 30 minutes ~ 10 hours. It is a function for Heating + Tank operation. Tank








43. Sterilisation Initial setting: 65°C 10 mins.

Set timer to perform sterilization.

- 1 Set operating day & time. (Weekly timer format)
- 2 Sterilization temperature (55~75°C)
- Operation time (Time to run sterilization when it reached setting temperature. 5 ~ 60 minutes)

User shall set whether to use or not to use sterilization mode.



12.2.2.5 Service Setup

44. Pump maximum speed


Initial setting: Varies according to model


Normally setting is not necessary.

Adjust when needed to reduce the pump sound, etc.

Besides that, the unit has Air Purge function.


When the Pump flow setting is Max. Duty, this duty setting is the duty of fixed pump that runs during operation.






46. Service contact

Able to set the name & telephone no. of contact person when there is breakdown etc. or client has trouble. (2 items)






12.2.2.6 Remote Control Setup

47. RC selection

Initial setting: Single

If there is only one remote controller, set to "Single". If two remote controllers are installed, set to "Dual".

For details on the Dual setting, refer to the instruction manual of the optional remote controller.



12.3 Service and Maintenance

If you forget your password and cannot operate the remote controller

+ + \rightarrow Press for 5 seconds.

If the password unlock screen appears, press "Confirm" to reset the password.

It will be set to 0000. Please reset the password to a new one. Note: This screen appears only when the remote controller is password-locked.

12.3.1 Maintenance Menu

How to set up the Maintenance menu

Maintenance menu

12:00 pm, Mon

Actuator check

Test mode

Sensor setup

Reset password

Select

Confirm

+ + \rightarrow Press for 5 seconds.

Items that can be set

- Actuator check (Manual ON/OFF of all functional parts)
 Note: As there is no protection action, be careful not to
 cause any errors when operating each part (e.g.,
 do not turn ON the pump when there is no water.)
- 2 Test mode (Test run) This mode is generally not used.
- ③ Sensor setup (Offset gap of detected temperature of each sensor, can be set within a range of -3°C to 3°C). Note: Use this setting only if the sensor is deviated as It affects temperature control.
- Reset password (Password reset)

12.3.2 Custom Menu

How to set up a Custom menu

Custom menu

12:00 pm, Mon

Cool mode

Back-up heater

Reset energy monitor

Reset operation history

Select

Confirm

Custom menu 12:00 pm, Mon
Back-up heater
Reset energy monitor
Reset operation history

Anti-stick mode

Select [4] Confirm

Items that can be set

Cool mode (Select Cooling function: Enable/Disable)
 Default setting is Disable.

Note: Enabling or disabling Cool Mode may affect electricity usage, be careful and do not simply change it. In Cool mode, ensure that piping is properly insulated; otherwise, condensation may occur, leading to water dripping on the floor and potentially causing damage.

② Back-up heaters (Select Back-up heaters: Enable/Disable)

Note: This setting differs from the customer's choice to use or not use the back-up heater. It disables the heater power for freeze protection. (This setting should only be used if requested by the utility company.) This setting may result in a lower heating temperature, potential failure of defrosting, and system stoppages (H75 error). Installation must be performed by a qualified personnel. If the system stops frequently, the issue may be due to insufficient circulation flow or a heating set temperature that is too low.

3 Reset energy monitor (Deletes the memory of the energy monitor).

Use this function when moving house or handing over the unit.

Reset operation history (Deletes the memory of the operation history)

Use this function when moving house or handing over the unit.

5 Anti-stick mode (select Anti-stick mode: Enable/Disable) Default setting is Enable.

The actuator is automatically activated every Monday at 3:00 am to prevent the actuating parts from sticking together.

If you wish to stop the periodic activation, select "Disable" Parts and other components that are not operated for an extended period may stick if Anti-stick mode is disabled.

12.4 Outdoor Unit

Attached accessories

No.	Accessories part	Qty.
1	Drain Elbow	1
2	Screw	8
3	Rubber Cap	3
4	Rubber Cap	15
5	Discharge Grille (Left Top)	1
6	Discharge Grille (Left Bottom)	1
7	Discharge Grille (Right Top)	1
8	Discharge Grille (Right Bottom)	1

Optional Accessories

No.	Accessories part	Qty.
9	Remote Controller set (CZ-RTW2TAW1C) *Include Remote Controller + Network adaptor with 10m cable	1
10	Remote Controller (CZ-RTW2, CZ-RTW2-1)	1
11	Base Pan Heater CZ-NE4P	1

- When you purchase an indoor unit, the remote controller and network adaptor are included.
- When the outdoor unit is used alone, either 9 or
 10 is always required.
- If you need the 2nd remote controller, purchase
 10 and set it up as the 2nd remote controller.
- When installing the outdoor units in cold climates, it is strongly recommended to install a base pan heater (optional). For installation details, refer to the installation manual of the base pan heater (optional).

Field Supply Accessories (Optional)

Part	3-way valve kit		
	Electromtoric Actuator	3-port Valve	
Model	SFA 21/18	VXI 46/25	
Specification	AC230V, 12VA	-	
Supplier	Sien	nens	

12.4.1 Select the Best Location

- If an awning is placed over the unit to avoid direct sunlight or rain, be careful not to disturb the heat dissipation from the capacitor.
- Avoid installation where the ambient temperature may fall below -28°C.
- A protective zone is defined in the area close to the perimeter of the product. Refer to 12.4.2 Protective Zone section.
- Do not place obstacles that could short-circuit the discharge air.
- The lifespan of Outdoor Unit may be shorter if it is installed near the sea, in areas with high sulphur content or high oil content (e.g. machine oil).
- For maximum length and elevation between outdoor unit and indoor unit, refer to "Cooling/Heating Pipework" in 12.4.5 Piping Installation.

12.4.2 Protective Zone

This outdoor unit is filled with R290 (Extremely flammable gas, safety A3 group per ISO 817). Note that this refrigerant has a higher density than air. In case of a refrigerant leak, the leaked refrigerant may accumulate near the ground.

Prevent accumulation of refrigerant in any way that is potentially dangerous, explosive or risk suffocation. Prevent refrigerant from entering the building through building openings. Prevent accumulation of refrigerant in the drain grooves.


A protective zone is defined around this outdoor unit. There must be no building openings, windows, doors, light shafts, cellar entrances, escape hatches, flat-roof windows or ventilation openings in the protective zone.

There must be no ignition sources, such as heat above 360°C, sparks, open flame, plug sockets, light switches, lamps, electrical switches or other permanent ignitions sources, in the protective zone.


The protective zone must not extend to adjacent buildings or public traffic areas (boundaries of neighbors, the public road, neighbor's private roads, subsidence area, depressions, pump shafts, sewers intakes, waste water shafts and so on.).

In the protective zone, you are not permitted to make any subsequent structural alterations which infringe the stated rules for the protective zone.


 Protective zone for ground installation (or flat-roof installation) at the open areas




Protective zone for ground installation in front of a building wall



 Protective zone for ground installation in a building corner




4) Protective zone for wall installation in front of a building wall



The protective zone under the product extends to the floor.


 Protective zone for wall installation in a building corner




The protective zone under the product extends to the floor.

12.4.3 Install Outdoor Unit

12.4.3.1 Dimension Diagram




12.4.3.2 Main Components Diagram




12.4.3.3 Install the Outdoor Unit

- After selecting the best location, start installation according to the Installation Diagram.
- 1. When installing at roof, please consider strong wind and earthquake. Please fasten the installation stand firmly with bolt or nails.
- For mounting on concrete or solid surfaces, fix the unit using M10 or W 3/8 bolts and nuts.
 Make sure that the unit is installed vertically against the horizontal plane.
 (Install the unit using anchor bolt as shown below.)



12.4.3.4 Disposal of Outdoor Unit Drain Water

- When the Drain elbow 1 is used, please ensure to:
 - The unit must be mounted on a stand at least 50 mm high.
 - Seal the ø32 mm holes with Rubber caps 3. (Refer to the diagram below and install from the outside)
 - If drain water leaks, attach rubber caps 4 when necessary. (Refer to the diagram below and install from the outside)
 - When disposing drain water from the outdoor unit, use a tray (field supply) if necessary.
- If the unit is used in an area where temperature falls below 0°C for 2 or 3 consecutive days, it is recommended not to use the Drain elbow 1 Rubber caps 3 and Rubber caps 4 since drain water will freeze up and obstruct fan rotation.




12.4.4 Install a Sleeve of Piping (Drilll a Hole in the Wall)

- 1. Make a through hole. (Check pipe diameter and insulation thickness)
- 2. Insert the piping sleeve into the hole.
- 3. Fix the bushing to the sleeve.
- 4. Cut the sleeve until it extrudes about 15 mm from the wall.




5. Finish by sealing the sleeve with putty or caulking compound at the final stage.




12.4.5 Piping Installation

12.4.5.1 Typical Piping Installation


When outdoor unit is used alone (Same for Control Module connection)



When indoor unit (hydromodule + tank) is connected




When indoor unit (Bi-bloc) is connected



12.4.5.2 Water Piping Installation

- Please engage a licensed water circuit installer to install this water circuit.
- This water circuit must comply with relevant European and national regulations (including EN61770), and local building regulation codes.
- Ensure the components installed in the water circuit could withstand water pressure during operation.
- Do not use worn out tube or detachable hose set.
- Do not apply excessive force to the pipe. There is a risk of damage.
- Choose proper sealer which can withstand the pressures and temperatures of the system.
- Make sure to use two spanners to tighten the connection. Further tighten the nuts with torque wrench to the specified torque as stated in the table.
- Cover the pipe end to prevent dirt and dust when inserting it through a wall.
- If non-brass metallic piping is used for installation, make sure to insulate the pipes to prevent galvanic corrosion.
- Do not connect galvanised pipes. This may cause galvanic corrosion.
- Use correct nut for all Outdoor Unit tube connections and clean all tubes with tap water before installation.



	Size	Torque
Water Inlet Port (a)	R 1¼"	117.6 N•m
Water Outlet Port (b)	K 1/4	117.0 119111

:
<u></u> CAUTION
Do not overtighten, overtightening may cause water leakage.

- Make sure to insulate the water circuit pipes to prevent reduction of heating capacity.
- After installation, check the water leakage condition in connection area during test run.
- Failure to connect the tube appropriately might cause the Outdoor Unit malfunction.
- Protection from frost:

When water is left inside the system, freezing up is very likely to happen, which could damage the system.

Make sure the power supply is turned off before draining.

When outdoor unit is used alone

Install an expansion tank (set pressure: 1 bar) to the circulation circuit.

For capacity, refer to 12.4.11 Reconfirmation.

12.4.5.3 Space Cooling/Heating Pipework

- Failure to connect the tube appropriately might cause the Outdoor Unit malfunction.
- Refer to the table below for the rated flow rate of each particular Outdoor Unit.

Model	Rated flow rate (L/min)	
iviodei	Cooling	Heat
WH-WXG09ME8 WH-WXG09ME5	25.8	25.8
WH-WXG12ME8 WH-WXG12ME5	25.8	34.4
WH-WXG16ME8	25.8	45.9

When outdoor unit is used alone

- Connect Outdoor unit Zone 1 Water inlet (a) to outlet connector of Zone 1 Panel/Floor heater.
- Connect Outdoor unit Zone 1 Water outlet (b) to inlet connector of Zone 1 Panel/Floor heater.

When connected to indoor unit

Refer to the Indoor Unit Installation Manual.

- * In the case of Control Module model, it is the same as outdoor unit alone case.
- * Do not connect a 1-phase indoor unit to a 3-phase outdoor unit.

Pipe diameter and length

Model	Water piping between outdoor unit and indoor unit			
Woder	Inner diameter	Maximum length	Insulator thickness	Maximum Elevation
WH-WXG09ME8 WH-WXG09ME5	ø 25 mm			
WH-WXG12ME8 WH-WXG12ME5	ø 32 mm	30m	30 mm or more	30m
WH-WXG16ME8				

* However, if the indoor unit is located more than 10 m below, the water pressure in the circulation circuit (outdoor unit section) shall be 0.5 to 1 bar. If the outdoor unit is located below, install an extra pump on the outdoor side.

Refer to "12.4.5.4 Special Installation Patterns" in next page.


* WH-WXG16ME8 may require installation of an extra pump depending on piping length.

	Water piping (When outdoor unit is used alone)			
Model	Inner diameter	Insulation thickness	Maximum elevation between outdoor unit and Panel/Floor heater	
WH-WXG09ME8 WH-WXG09ME5	ø 25 mm			
WH-WXG12ME8 WH-WXG12ME5	ø 32 mm	30 mm or more	10m	
WH-WXG16ME8				

12.4.5.4 Special Installation Patterns


Special construction patterns mentioned here refer to the case where there is a substantial difference in elevation (e.g. more than 10 m) between the outdoor unit installation and the Panel/Floor heater (or indoor unit). In this case, attention must be paid since incorrect water filling during installation may prevent the system from operating correctly and may cause water leak.

① When outdoor unit is located below and Panel/Floor heater is 30 m above it



- Pressure checked by remote controller:
 3.5 ~ 4 bar. (at an elevation difference of 30 m)
- When installing an extra pump, connect it to the water outlet of the outdoor unit.
 (If installed to the water inlet, the safety valve is activated and the water is drained)
- Indoor unit is required to install an extra pump.

2 When outdoor unit is located above and Panel/Floor heater is 30 m below it



- Pressure checked by remote controller:
 0.5 ~ 1 bar. (at an elevation difference of 30 m)
- When installing an extra pump, connect it to the water outlet of the indoor unit.
- Indoor unit is required to install an extra pump.

12.4.6 Connect the Cable to the Outdoor Unit

\wedge	WARNING


This section is intended for licensed electricians. Work inside terminal board covers (3) fixed with work screws must be carried out by an installer or service personnel under the supervision of qualified personnel.

⚠ CAUTION

Make sure to install the discharge grille to the outdoor unit before powering ON to protect againts a rotating fan.

(Refer to the unit wiring diagram for details)

• For safety, install the discharge grille (left side) 5 • 6 using screws 2 before connecting the cables.



12.4.6.1 Fixing of Power Supply Cable and Connecting Cable

- 1. An isolating device must be connected to the power supply cable.
 - Isolating device (disconnecting means) should have minimum 3.0 mm contact gap.
 - Use approved polychloroprene sheathed flexible cable of type designation 60245 IEC 57 or heavier. Connect
 the other end of the cable to isolating device (Disconnecting means). See table below for cable size
 requirements.

Power Supply Cable

Model	WH-WXG09ME8 WH-WXG12ME8	WH-WXG16ME8	WH-WXG09ME5 WH-WXG12ME5	
Cable specification	5 × min 1.5 mm ²	5 × min 2.5 mm ²	3 × min 4.0 mm ²	
Cable Diameter	ø 8.5 ~ 10.0 mm	ø 12.0 ~ 14.0 mm		
Cable gland (see diagram in 2 next page)		Α		
Isolating Devices	20A 25A		32A	
Recommended RCD	30mA, 4	P, typeA	30mA, 2P, typeA	


• Earth wire shall be longer than the other wires as shown in the figure 3 for the electrical safety in case of the slipping out of the cord from the Holder (Clamper).


- 2. Connecting cable must be an approved polychloroprene sheathed flexible cable (see table below), type designation 60245 IEC 57 or heavier. The sheath diameter of some connecting cables must be within specifications compatible with the cable gland.
- * Do not connect a 1-phase indoor unit to a 3-phase outdoor unit.

	Connection between Indoor unit and outdoor unit	Tank temperature sensor	Remote controller
Cable Specifications	2 × min 0.75 mm ²	2 × min 0.3 mm ²	2 × min 0.3 mm ²


	3-Way Valve	Boiler
Cable Specifications	3 × min 1.5 mm ²	2 × min 0.5 mm ²
Cable Diameter	ø 8.5 ~ 10.0 mm	ø 4.0 ~ 7.0 mm
Cable gland to be used (see diagram in below)	В	С

- 3. Route the cables as follows.
 - Do not damage the cables by sharp edges.
 - Remove the front plate ① and pull the power cable (cabtyre cable *1) and connection cable through into the rear bushing. Be sure to use the bushing and do not lose it.
 - Remove the terminal board cover ③ and cable gland cap and insert the cables into the cable gland on the bottom of the electrical control unit box.
 - 3 Connect to 3-phase/1-phase RCCB/ELCB 4 and optional terminal board 5.
 - Fix the cable gland by referring to [Figure 2]*2
 - 5 Set the terminal board cover 3 by referring to [Figure 2] *2
 - *1 Locally procure the specified cabtyre cable.
 - *2 Screws of cable gland and terminal board cover ③ must be tightened to the specified tightening torque to prevent ingress of gas.






Route the cables as shown in the diagram above.




 \bigstar

12.4.6.2 Connection Between Indoor Unit and Outdoor Unit


When outdoor unit is used alone, leave the short-circuit wires "C2" and "C3" attached as shown in the diagram below.



When connecting to an indoor unit, remove the short-circuit wires "C2" and "C3" and connect as shown in the diagram below.



12.4.6.3 Wire Stripping and Connecting Requirement



Terminal screw	Tightening torque cN•m {kgf•cm}
M4	157 ~ 196 {16 ~ 20}
M5	196 ~ 245 {20 ~ 25}

12.4.6.4 Connection Requirement

For model WH-WXG09ME8, WH-WXG12ME8

- The equipment's Power Supply complies with IEC/EN 61000-3-2.
- The equipment's Power Supply complies with IEC/EN 61000-3-3 and can be connected to current supply network.

For model WH-WXG16ME8, WH-WXG09ME5, WH-WXG12ME5

- The equipment's Power Supply complies with IEC/EN 61000-3-12.
- The equipment's Power Supply complies with IEC/EN 61000-3-3 and can be connected to current supply network.

12.4.7 Install Remote Controller

Remote controller is an optional item.

Be sure to purchase it if the outdoor unit is used alone.


If you have purchased an indoor unit, it is included.

When relocating the remote controller, install in accordance with its Installation Manual.

12.4.7.1 Installation Location

- When using as Room Thermostat, install at the height of 1 to 1.5 m from the floor (Location where average room temperature can be detected).
- Install vertically against the wall.
- Avoid the following locations for installation.
 - 1. By the window, etc. where is exposed to direct sunlight or direct air
 - 2. In the shadow or backside of objects deviated from the room airflow
 - 3. Location where condensation occurs (Remote Controller is not moisture proof or drip proof)
 - 4. Location near heat source
 - 5. Uneven surface
 - 6. Outdoors
- Keep distance of 1 m or more from the TV, radio and PC. (Cause of fuzzy image or noise)


12.4.7.2 Remote Controller Wiring (If the Outdoor Unit is Used Alone)




- Remote Controller cable shall be (2 × min 0.3 mm²) of double insulation PVC-sheathed or rubber sheathed cable. Total cable length shall be 50 m or less.
 - (UV protection should be provided for the portion exposed to the outdoors)
- Be careful not to connect cables to other terminals of Outdoor Unit (e.g. power source wiring terminal).
 Malfunction may occur.
- Do not bundle together with the power source wiring or store in the same metal tube. Operation error may occur.
- When using the 2nd Remote Controller (optional), connect it to the terminal by tightening it together.

12.4.8 Network Adaptor Installation


 Insert a flat head screwdriver into the slot on the top of the adaptor and remove the cover. Connect the CN-CNT cable to the connector inside the adaptor.



2. Pull the CN-CNT cable through the hole at the bottom of the adaptor and reattach the cover.



Connect the CN-CNT cable to the CN-CNT connector on the outdoor unit.




For details, refer to the instructions supplied with the network adaptor. For installation location, refer to "Installation location" in 12.4.7 Install Remote Controller.

12.4.9 Piping Insulation

 Carry out insulation of pipe connections according to "Space Cooling/Heating Pipework" in 12.4.5 Piping Installation. Wrap the pipes end-to-end with insulation to prevent condensation.

12.4.10 Charging the Water

- Make sure all the piping installations are properly done before carrying out the steps below.
- 1. Start filling water to the Space Heating /Cooling circuit via Zone 1 Water inlet (a) (with pressure more than 1 bar (0.1MPa))
- 2. Stop filling water if the free water flow through Drain pipe of Pressure Relief Valve 12. (Check the Outdoor Unit)
- 3. Turn ON the Outdoor Unit.
- Remote control menu → Installer setup → Service setup → Pump maximum speed → Turn on the pump.
- 5. Make sure Water Pump (7) is running.
- 6. Check and make sure no water leaking at the tube connecting points.




12.4.11 Reconfirmation

12.4.11.1 Check Water Pressure

* (0.50 bar = 0.05 MPa)

Water pressure should not be lower than 0.5 bar. (Check the water pressure by the remote controller) If necessary, add water into Space Heating /Cooling pipes (through the Zone 1 water inlet ⓐ).

Icon flashes if dropped below "0.50 bar"



12.4.11.2 Check Pressure Relief Valve

- 1. Pull the lever in the horizontal direction and confirm that the pressure relief valve works properly.
- 2. Release the lever when water comes out of the drain pipe of the pressure relief valve. (While the air continues to come out of the drain pipe, keep raising the lever to completely discharge the air)
- 3. Confirm that the water from the drain pipe stops.
- 4. If water is leaking, pull the lever several times and return it to make sure the water stops.
- If water keeps coming out of the drain, drain water.
 Turn off the system and contact your local authorized dealer.

12.4.11.3 Check Air Accumulation

- Open the air vent plugs on the heating panel, fan convector, etc., and remove the air accumulated in the equipment and piping.
- If the outdoor unit and the indoor unit are installed on different floors, open the air vent plug on the water plug of the outdoor unit and the air vent plug on the heater bottle inside the indoor unit to remove the air.

(Be careful, water will come out)

12.4.11.4 Expansion Vessel Volume and Set Pressure

- This outdoor unit does not have a built-in expansion tank.
- Capacity of expansion vessel should be calculated using the formula below:
- Install an expansion vessel (set pressure: 1 bar) to the circulation circuit.

See formula below for capacity:

$$V = \frac{\epsilon x Vo}{1 - \frac{98 + P_1}{98 + P_2}}$$

V : Required gas amount <expansion vessel volume: L>

Vo : System total water volume <L>

ε: Water expansion rate
 P1: Expansion tank charging pressure
 P2: Maximum system
 5 x 80°C = 0.0219
 P1 = 100 kPa
 P2 = 400 kPa

pressure

It is recommended to calculate the required volume of vessel with a margin of approximately

Water expansion rate table

Water temperature (°C)	Water expansion rate ε
10	0.0003
20	0.0019
30	0.0044
40	0.0078
50	0.0121
60	0.0171
70	0.0228
80	0.0291
90	0.0360

When an indoor unit is introduced and it is installed more than 7m lower than the outdoor unit

Increase the initial pressure in the expansion tank as per the calculations below.

Pg= (H*10+30) kPa

Pg: Initial pressure of expansion tank (kPa) H: Difference in elevation (m)

12.4.11.5 Check RCCB/ELCB

- Ensure the RCCB/ELCB is set to "ON" condition before checking RCCB/ELCB.
- Turn on the power supply to the outdoor unit.
 This testing can only be done when power is supplied to the outdoor unit.

№ WARNING

Be careful not to touch parts other than the TEST button of RCCB/ELCB when the power is supplied to Outdoor Unit. Else, electrical shock may happen. Before obtaining access to terminals, all supply circuits must be disconnected.


- Press the "TEST" button on the RCCB/ELCB. The lever would turn down if it functions normal.
- Contact authorized dealer if the RCCB/ELCB malfunction.
- If the RCCB/ELCB operates correctly, set the lever to 'ON' again after the test.

12.4.11.6 Check Connecting Bar

♠ CAUTION

A connecting bar is mounted on compressor during transportation.

Please make sure to remove it before installing the unit. Otherwise, it can result in abnormal noise and the bending of a pipe.




How to remove the connecting bar


10.8 ~ 17.6 N•m (110 ~ 180 kgf•cm).


- 1. Remove the 4 screws from the connecting bar.
- 2. Remove the connecting bar.
- 3. Dispose of the connecting bar and 4 screws.
- * If it is difficult to remove the connecting bar, loosen 2 nuts from the compressor.
 In that case, please make sure that they are tightened with the specified torque of

12.4.12 Install Discharge Grille

- 1 Install the front plate 1
- Remove the 4 screws securing the cabinet front plate $\widehat{(1)}$.
- Insert the 4 claws of the discharge grille (right side) 7 and 8, and tighten the 4 screws.







12.4.13 Test Run

- Before test run, make sure below items have been checked:
 - a) Pipework are properly done.
 - Electric cable connecting work are properly done.
 - c) The Space Heating/Cooling circuit is filled up with water and trapped air is released.
- 2. Switch ON the power supply of the Outdoor Unit. Set the Outdoor Unit RCCB/ELCB to "ON" condition. Then, please refer to the Operation Instruction for operation of Remote Controller.

Note

During winter, turn on the power supply and standby the unit for at least 15 minutes before test run. Allow sufficient time to warm up refrigerant and prevent wrong error code judgement.

- 3. For normal operation, the water pressure reading should be in between 0.5 bar and 4 bar (0.05 MPa and 0.4 MPa). If necessary, adjust the speed of the water pump 7 accordingly to obtain normal water pressure operating range. If adjusting the speed of the water pump 7 does not solve the problem, contact a local authorized dealer.
- 4. After test run, please clean the magnetic water filter (8). Reinstall it after the cleaning is finished. (Refer to 12.4.14 Maintenance)

12.4.13.1 Check Water Flow of Water Circuit

Select Installer setup \rightarrow Service setup \rightarrow Pump maximum speed \rightarrow Air purge.

Confirm the rated flow rate has been reached. If don't reach, change max duty or install the extra pump.

*Water flow can be check in Service setup (Pump maximum speed)

[Heating operation at low water temperature with lower water flow may trigger "H75" during defrost process.]

*If there is no flow or H62 is displayed, stop operating the pump and release the air. (See "CHECK AIR ACCUMULATION" in 12.4.11 Reconfirmation)


12.4.14 Maintenance

 In order to ensure safety and optimal performance of the Outdoor Unit, seasonal inspections, functional check of RCCB/ELCB, field wiring and piping have to be carried out at regular intervals. This maintenance and scheduled inspection should be carried out by authorized dealer.

12.4.14.1 Maintenance for Magnetic Water Filter (8)

- 1. Turn OFF the power supply.
- 2. Place a container below Magnetic Water Filter (8).
- Turn to remove the Magnet Bar at bottom of Magnetic Water Filter (8).
- 4. Remove the Cap of Discharge Port with Allen key (8mm).
- Open the Service Valve with Allen key (4mm) to release the dirty water from the Discharge Port into a container. Close the service valve when the container is full to avoid spillage in the outdoor unit. Dispose the dirty water.
- 6. Reinstall the Cap of Discharge Port and Magnet
- 7. Re-charge the water to Space Heating / Cooling circuit if necessary.

 (For details, refer to 12.4.10 Charging the Water)
- 8. Turn ON the power supply.



12.4.14.2 Maintenance for Expansion Vessel

 Regular maintenance of the expansion vessel (at least once a year) is recommended and should be performed by authorized dealer. First, make sure that the expansion or pressure tank is completely drained of water, that the system is switched off, and that there are no live electrical components. If you need to reset the preload pressure, set 1bar.

CAUTION

Do not clean the outdoor unit with hydrocarbon solvents when Outdoor Unit needs to be cleaned during installation or servicing.

12.5 Appendix


12.5.1 Variation of System


This section introduces variation of various systems using Air-To-Water Heatpump and actual setting method. (NOTE): This model does not have a built-in expansion vessel to prevent the pressure in the water circuit from rising in the event of temperature rise. Be sure to purchase in the market and install it.

12.5.1.1 Introduce Applications Related to Temperature Setting

12.5.1.1.1 Temperature Setting Variation for Heating


1. Remote controller






Connect floor heating or radiator directly to the Outdoor Unit. Install remote controller on the wall of the room. This is the basic form of the simplest system.

2. Room Thermostat






Connect floor heating or radiator directly to the Outdoor Unit.


Install the remote controller in the room where floor heating is installed.

This is an application that uses remote controller as Room Thermostat.


12.5.1.1.2 Examples of Installations


1. DHW (Domestic Hot Water) Tank connection





2. Boiler connection





This is an application that connects the boiler to the Outdoor Unit, to compensate for insufficient capacity by operate boiler when outdoor temperature drops & heat pump capacity is insufficient.


Boiler is connected parallel with heat pump and used as heating circuit.

Besides that, an application that connects to the DHW tank's circuit to heat up tank 's hot water is also possible. Boiler output can be control by either SG ready input from Control Module unit or Auto control by 3 modes selection pattern.

(Operation setting of boiler shall be responsible by installer.)

Depending on the settings of the boiler, it is recommended to install buffer tank as temperature of circulating water may get higher. (It must connect to buffer tank especially when select Advanced Parallel setting) However, buffer tank connection requires Control Module unit.

Note: Buffer tank thermistor must be connected to Control Module unit PCB.



/ CAUTION

Make sure the boiler and its integration in the system complies with applicable legislation.

Make sure the return water temperature from the heating circuit to the Outdoor Unit does NOT exceed 70°C.

Boiler is turned off by safety control when the water temperature of the heating circuit exceed 85°C.

If you wish to use optional features other than connecting DHW tank or boiler, purchase an optional indoor unit or Control Module unit.

Functions that become available by purchasing an indoor unit, etc. include:

- Buffer tank connection
- 2-zone control
- · Solar connection
- · SG Ready
- Demand control


and others

Optional PCB is required


12.5.2 System Installation


12.5.2.1 Remote Controller Outline

The LCD display as shown in this manual are for instructional purpose only, and may differ from the actual unit.




First time of power ON (Start of installation)






12.5.3 Setup

12.5.3.1 Installer Setup



The above description is for outdoor unit alone case.
For indoor units, please refer to the installation manual supplied with the indoor unit.



The above description is for outdoor unit alone case.
For indoor units, please refer to the installation manual supplied with the indoor unit.

12.5.3.2 System Setup



12:00am,Mon 2. Anti freezing Initial setting: Yes System setup Zone & Sensor Operate anti-freezing of water circulation circuit. Anti freezing If select "Yes", when the water temperature is reaching its freezing temperature, the Tank connection circulation pump will start up. If the water temperature does not reach the pump stop temperature, heat pump will be activated. DHW capacity Select [←] Confirm (NOTE) If set to "No", when the water temperature is reaching its freezing temperature or below 0°C, the water circulation circuit may freeze and cause malfunction.

3. Tank connection

Initial setting: No

Select whether a hot water storage tank is connected or not. If set to "Yes", the water heating function is set to be used.

The tank water temperature can be set from the main screen.

System setup

Zone & Sensor

Anti freezing

Tank connection

DHW capacity

Select

Select

Confirm

4. DHW capacity Initial setting: Variable 12:00am,Mon System setup Zone & Sensor Variable DHW capacity setting normally runs with efficient boiling which is energy Anti freezing saving heating. But while hot water usage is high and tank water temperature is low, variable DHW mode will run with fast heat up which heat up the tank with high Tank connection heating capacity. DHW capacity If standard DHW capacity setting is selected, heat pump runs with heating rated [🗗] Confirm capacity at tank heat up operation. Select

5. Base pan heater Initial setting: No
Select whether Base pan heater is installed or not.
If set to "Yes", select to use either heater A or B.
A: Turn on Heater when heating with defrost operation only

System setup
12:00am,Mon
Tank connection
DHW capacity

Base pan heater

Select


[←] Confirm

* The above description is for outdoor unit alone case. For indoor units, please refer to the installation manual supplied with the indoor unit.

Mean "Yes" is selected for tank connection

below 5 °C.

B: Turn on Heater during heating operation when outside temperature is



Auto


There are 3 different modes in the boiler auto pattern operation. Movement of each mode is as shown below:

- 1 Alternative (switch to boiler operation when drops below setting temperature)
- 2 Parallel (allow boiler operation when drops below setting temperature)
- 3 Advanced Parallel (able to slightly delay boiler operation time of parallel operation)

When the boiler operation is "ON", "boiler contact" is "ON", "_"(underscore) will be displayed below the boiler icon.

Please set target temperature of boiler to be the same as heat pump temperature.

When boiler temperature is higher than heat pump temperature, zone temperature cannot be achieved if mixing valve is not installed. This product only allows one signal to control the boiler operation. Operation setting of boiler shall be responsible by installer.



In Advanced Parallel mode, setting for both Heat and Tank can be made simultaneously. During operation of "Heat/Tank" mode, when each time the mode is switched, the boiler output will be reset to OFF. Please have good understanding on the boiler control characteristic in order to select the optimal setting for the system.

• Smart


There are Energy price (both electricity and boiler) and Schedule to be set on remote controller.

Operation setting of Energy price and Schedule shall be responsible by installer.

Based on these settings, system will calculate the final price for both electricity and boiler.

When final price of Electricity is lower than Boiler's, heat pump will operate.

When final price of Electricity is higher than Boiler's, boiler will operate.



X The above description is for outdoor unit alone case.

For indoor units, please refer to the installation manual supplied with the indoor unit.

7. Circulation Liquid

Initial setting: Water

Set circulation of heating water.

There are 2 types of settings: water and glycol.

(NOTE) Please set glycol when using anti-freeze liquid.

It may cause error if setting is wrong.

System setup 12:00am,Mon

DHW capacity
Base pan heater
Bivalent connection

Circulation Liquid

\$\Displays \text{ Select} \text{ Confirm}\$

8. Force Defrost

Initial setting: Manual

Under manual mode, user can turn on force defrost through quick menu.

If 'Auto' is selected, the outdoor unit will run defrost operation once if heat pump have long hour of heating without any defrost operation at low ambient condition. (Even when Auto is selected, user still can turn on force defrost through quick menu)


System setup	12:00am,Mon
Base pan heater	
Bivalent connection	
Circulation Liquid	
Force Defrost	
Select	[←] Confirm

9. Pump flowrate

Initial setting: ∆T

If pump flowrate setting is ${}^*\Delta T$, the unit adjusts pump duty to use different water inlet and outlet based on the setting of ${}^*\Delta T$ for heating ON and ${}^*\Delta T$ for cooling ON in operation setup menu during indoor operation.

If pump flowrate setting is set to Max. duty, the unit will set the pump duty at *Pump maximum speed in the service setup menu during room side operation.



*1

10. DHW Defrost

Initial setting: Yes

When DHW defrost set to "YES", hot water of domestic hot water tank will be used during defrost cycle.

When DHW defrost set to "NO", hot water of floor heating circuit will be used during defrost cycle.

System setup	12:00am,Mon
Circulation Liquid	
Force Defrost	
Pump flowrate	
DHW Defrost	
Select	[←] Confirm

11. Heating control

Initial setting: Comfort

Compressor frequency control can be selected from two modes: Comfort and Efficiency.


Select "Comfort"

- The compressor operates at maximum frequency at the upper zone limit and reaches the set temperature faster.

Select "Efficiency"

The compressor frequency is gradually increased to reduce power consumption.
 The system has 3 steps to achieve maximum compressor frequency. You can set the duration of each stage on the remote control (R/C).

(compressor frequency for each stage)
1st stage: 50% of the maximum frequency
2nd stage: 66% of the maximum frequency
3rd stage: 83% of the maximum frequency



1st stage 2nd stage 3rd stage

Total time

*1 Only when the selection for Tank connection is Yes

* The above description is for outdoor unit alone case.

For indoor units, please refer to the installation manual supplied with the indoor unit.

12. External meter

Initial setting: [Heat-cool meter : No]

[Tank meter : No] *only available when Heat-cool meter select Yes

[Elec. meter HP: No] [Elec. meter 1 (PV meter): No] [Elec. meter 2 (Total building): No] [Elec. meter 3 (Reserve): No]

System setup	12:00am,Mon
Pump flowrate	
DHW Defrost	
Heating control	
External meter	
Select	[←] Confirm

There are two systems for generation meter connection: single generation meter system (Heat-cool meter) or two generation meter system (Heat-cool meter and Tank meter)

Both systems can provide all generation data of heating, cooling and DHW directly from external meter.

If Heat-cool meter is set to "Yes", it will read from external meter for heat pump's energy generation data during heating, cooling and DHW operation *1.

If Heat-cool meter is set to "No", it will base on unit's calculation for heat pump's energy generation data during heating, cooling and DHW operation.

If Heat-cool meter is set to "Yes", it will read from external meter for heat pump's energy generation data during heating, cooling and DHW operation 1.

If Elec. meter HP is set to "Yes", it will read from external meter for heat pump's energy consumption data.

If Elec. meter HP is set to "No", it will base on unit's calculation for heat pump's energy consumption data.

If Elec. meter 1 (PV meter) is set to "Yes", it will read from external meter for energy generation data of solar system and display it on Cloud system.

If Elec. meter 2 (Building) is set to "Yes", it will read from external meter for energy consumption data of the building and display it on Cloud system.

If Elec. meter 3 (Reserve) is set to "Yes", it will read from external meter for energy consumption data obtained from reserved electricity meter and display it on Cloud system.

^{↑1} Set Heat-cool meter to Yes and set Tank meter to No when the 1 generation meter system is installed.

Set Heat-cool meter to Yes and set Tank meter to Yes when the 2 generation meter system is installed.

Remarks: Elec. meter HP refers to the electricity meter that measures Heat Pump unit's consumption.

Elec. meter 1 / 2 / 3 refers to the Electricity meter No. 1 / No. 2 / No. 3.

13. Static pressure

Initial setting: No

If set to "No", the outdoor fan motor operates at a normal speed.

If set to "YES", the outdoor fan motor operates at a higher speed in response to high static pressure.

System setup 12:00am,Mon

DHW Defrost

Heating control

External meter

Static pressure

\$\Delta\$ Select [44] Confirm

14. Cooling Capacity

Initial setting: Efficiency

Select the cooling capacity.

If set to "Efficiency", the unit performs cooling operation efficiently at rated capacity.

If set to "Comfort", the cooling operation is performed at maximum capacity.

System setup 12:00am,Mon

Heating control

External meter

Static pressure

Cooling capacity


\$\Displays \text{ Select} \text{ Confirm}\$


※ The above description is for outdoor unit alone case.


For indoor units, please refer to the installation manual supplied with the indoor unit.

12.5.3.3 Operation Setup

Heat









The above description is for outdoor unit alone case.
For indoor units, please refer to the installation manual supplied with the indoor unit.

Cool ** Cooling model only

18. Water temp. for cooling ON Initial setting: compensation curve Set target water temperature to perform cooling operation. Compensation curve: Target water temperature change in conjunction with outdoor ambient temperature change. Direct: Set the circulation water temperature directly.




Auto ** Cooling model only




X The above description is for outdoor unit alone case.
For indoor units, please refer to the installation manual supplied with the indoor unit.


Tank X Only when the selection for Tank connection is Yes




The above description is for outdoor unit alone case. For indoor units, please refer to the installation manual supplied with the indoor unit.


12.5.3.4 Service Setup








12.5.3.5 Remote Control Setup




The above description is for outdoor unit alone case.
For indoor units, please refer to the installation manual supplied with the indoor unit.


12.6 Service and Maintenance



12.6.1 Maintenance Menu



12.6.2 Custom Menu



X The above description is for outdoor unit alone case.

period of time.

For indoor units, please refer to the installation manual supplied with the indoor unit.

Disable is selected may stick if not operated for a long

13. Installation and Servicing Air-to-Water using R290



This symbol shows that this equipment uses a flammable refrigerant with safety A3 group per ISO 817. If the refrigerant is leaked, together with an external ignition source, there is a possibility of fire / explosion.

13.1 About R290 Refrigerant

Hydrocarbon is a class of organic chemical made up only with the element Carbon (C) and Hydrogen (H). R290 is the type of Hydrocarbon refrigerant which is environmentally good-natured and odorless refrigerant. Under Kigali Amendment to the Montreal Protocol, 80% reduction of greenhouse gas emission by next 30 years is required, and due to this requirement, further reduction in the emission of high greenhouse effect gas is required. Therefore, the conversion of air-conditioning refrigerant into one which has no greenhouse effect, even if it is dissipated into the atmosphere became our responsibility.

Nevertheless, in case of air-conditioning refrigerant, it would be the best if there is a refrigerant which has no impact on global warming but ensures good energy efficiency and performance, and is safe; however, there is no such refrigerant which satisfies all these conditions. As a result, we have been considering the practical usage, within the safety frame-work, of R290 refrigerant which has no effect of global warming but highly flammable.

13.2 Characteristics of R290 Refrigerant

1. Chemical Characteristics

R290 (Propane) is refrigerant grade propane, which is natural, non toxic, and chemically stable compound formed by hydrogen.

R290 is one of natural refrigerant, therefore it has almost zero greenhouse gas effect. R-290 is a single-component hydrocarbon substance and the most hydrocarbon properties as it is highly flammable.

Chemical Characteristic Table of R290 and R32

	R290	R32
Chemical Formula	C3H8	CH2F2
Composition	Single Composition	Single Composition
Boiling point (°C)	-42.1	-51.7
50°C vapor pressure (MPa)	1.71	3.14
Ozone Depletion Potential	0	0
Global Warming Potential (GWP)	3	675
Inflammability	Highly Inflammable (A3)	Slightly Inflammable (A2L)
Toxicity	None	None

2. Characteristic of Pressure

As shown in Table 2, R290 has half the vapor pressure of R32 at the same refrigerant temperature. As such, it can be installed and maintained with the same high-pressure tools and components as the R32.

Table 2. Saturated vapor pressure comparison table

(Unit: MPaG)


Temperature (°C)	Refrigerant	
	R290	R32
-20	0.14	0.30
0	0.37	0.71
20	0.74	1.37
40	1.27	2.38
60	2.03	3.84
65	2.23	4.29

Reference : Thermal properties table of Japan Society of Refrigerating and Air Conditioning Engineers (60, 65°C) NIST REFPROP V8.0 (-20 \sim 40°C)

3. Flammable characteristic

As shown in below table, R290 is highly flammable and explosive when heated. The installation must be equipped with ATEX (Atmospheres Explosible) certified equipment and must always turn on the combustible gas detector during servicing and when entering the service area. Service must also be performed in a well-ventilated area, especially if the refrigerant system is being accessed.

3.1 Safety class



Increasing Toxicity


Refrigerant	Burning Speed cm/s
R32	6.7
R290	38.7

3.2 Concentration control for R290

Because R290 is highly flammable, it can burn or explode if there is enough product concentrated in one space and the refrigerant comes in contact with an ignition source.

Control measurement;

Descriptions	Specifications
Lower flammability limit (LFL) [kg/m³]	0.038
Lower flammability limit (LFL) [%]	2.1
Practical limit (PL) [kg/m³]	0.008
Density of vapour [kg/m³]	1.83



The concentration of R290 between the lower flammable limit (2%) and upper flammable limits (10%) is enough to ignite fire.

Note:

LFL – Lower flammable limit whereby the concentration of flammable gas, vapour or mist in the air below which an explosive gas atmosphere will not be formed.

UFL – Upper flammable limit whereby the concentration of flammable gas, vapour or mist in the air below which an explosive gas atmosphere will not be formed.

PL – Defined as concentration used for simplified calculation to determine the maximum acceptable amount of refrigerant in an occupied space (20% of LFL)

3.3 Material classification and Hazard statement

H280	Contain gas under pressure; may explode if heated
CGA-HG01	May cause frostbite

13.3 Refrigerant piping installation • Tools used in services

13.3.1 Required Tools

R290 refrigerant air conditioners must use ATEX (Atmosphere Explosible) certified equipment. The common parts as R32 air conditioners for two-way valves and three-way valves (diameters of service ports); thus, they maintain commonality in the maintenance of the compressive strength, the size of pipe flaring, and the size of flare nuts as R32. However refrigerant pipe installation and services must use tools certified for highly flammable gas.

However, mixing of refrigerants is not allowed, so that you have to separate the cylinders for the recovery of refrigerants.

Tools used for installation • relocation • replacement of air conditioning units

Works	R290	R32	
Connecting of refrigerant pipes	Not applicable for Monobloc		
Connecting of reingerant pipes	Not applicable	for Monobloc	
Manifold gauge charging hose	HC Manifold gauge to avoid refrigerant contamination R32 & R410A Common		
Air purging	Vacuum pump complied with ATEX (Atmosphere Explosible) Vacuum pump + Reducer / expande		
Gas leakage test	Combustible gas detector Detection liquid or soup water, HFC detector		

For other installation, you can use general tools such as screw drivers (+, -), metal saws, long-nose pliers, hole core drills, linen tape, levels, temperature gauges, clamp meters, electric knives, nippers, pipe cutters, reamers or scrapers, spring benders, monkey wrenches, fixing wrenches, feeler gauges, hexagon wrenches (4 mm), testers, megohm testers, etc.

Tools used for services.

Works	R290	R32
Insertion of refrigerant	Digital scale for refrigerant charging, refrigera	nt cylinders, cylinder adopters and packing *a
Recovery of refrigerant	Refrigerant recovery devices, refrigerant cylinders, manifold gauges, charging hoses *b	

^{*}a. Use cylinder for each refrigerant, cylinder adopter and packing.

^{*}b. Use refrigerant recovery cylinder separately for each refrigerant (no mixture of refrigerant allowed).

13.3.2 Tools for R290

1. Manifold gauges

R32 gauge can be used for R290 pressure.

Each port of manifold has different shapes in order to prevent inserting wrong refrigerant.

*However, the port shape for R290 and R32 is the same; therefore, attention need to be paid not to insert wrong refrigerant.

Differences in high/low pressure gauges

	R290 (common R32)
High pressure gauges (red)	-0.1 ~ 5.3 MPa -76 cmHg ~ 53 kgf / cm²
Low pressure gauges (blue)	-0.1 ~ 3.8 MPa -76 cmHg ~ 38 kgf / cm²

Difference in manifold port sizes


	R290 (common R32)
Port sizes	1/2 UNF20

2. Charging hoses

The material is changed to HC resistant, and the size of each manifold adopter is common, as the R32 port size of manifold gauge.

Further, some hoses are with anti-gas pressure backflow valves placed near the adopters. (hoses with the valves recommended)

Manifold gauges / Charging hoses



Differences in charging hoses

		R290 (common R32)	
Normal operation pressure		5.1 MPa (52 kgf / cm²)	
Resistance	Burst pressure	27.4 MPa (280 kgf / cm²)	
Material		HNBR rubber Internal nylon coating	

3. Vacuum pump and isolator.

When using a vacuum pump, it is compulsory to use an ATEX certified vacuum pump.

When connecting service equipment (such as vacuum pumps) to a power source, the connection should be made in outside the Temporary Danger Zone. It is recommended to use an ATEX Isolator switch to facilitate a safe shutdown in the danger zone. It is necessary to set a solenoid valve in order to prevent backflow of vacuum pump oil into the charge hoses and use a vacuum pump with oil backflow prevention function.

If vacuum pump oil (mineral oil-based) mixes with R290, it may cause damage to the machine.

Vacuum pump



Isolator



4. Leak Detector

HC refrigerant Electric gas leakage tester is used for R290. The usage of existing HFC detectors cannot be use as they can produce spark. We recommend to use detectors specifically designed for combustible gas.

Combustible gas leak detector



5. Digital scale for refrigerant charging R290 has lower pressure level and the evaporates speed is slow. Thus, the digital scale for refrigerant charging can be used in common with R32. The charging port for R32 is (1/2 UNF20), common with R290

Digital scale for refrigerant charging



6. Refrigerant cylinders

Refrigerant cylinders for R290 are painted in other colors that might subject to change according to the international standards. R290 is a single refrigerant, so that both liquid and gas insertion are possible. Additional charging is also possible.

Refrigerant cylinders



Connection ports of refrigerant cylinders and packing

Charging ports which fit to the charging hose connection port size (1/2 UNF20) is needed. At the same time, the packing has to be of HC resistant materials.

Connection ports and packing



8. Tools used for refrigerant piping installations and services

	Common tools	R290	R32
1.	Pipe cutters, reamers or scrapers	Not applicable for Monobloc	Not applicable for Monobloc
2.	Flare tools (clutch type)	Not applicable for Monobloc	Not applicable for Monobloc
3.	Torque wrench (1/4, 3/8)	Not applicable for Monobloc	Not applicable for Monobloc
4.	Torque wrench (1/2, 5/8)	Not applicable for Monobloc	Not applicable for Monobloc
5.	Manifold gauges, charging hose	0	0
6.	Vacuum pump, vacuum pump isolator *2	Connection 5/16 [ATEX certified] *1	
7.	Electric gas leakage detectors	Combustible gas detector	HFC detector
8.	Digital scale for refrigerant charging	0	0
9.	Recovery devices (connection port 5/16) *2	ATEX certified	HFC recovery devices
10.			
11.	Refrigerant cylinder connection port and packing x		0
12.	Allen wrench (4mm) Electric knives x		
*1	*1 Those testers only for HC only cannot be for common use with HFC		
*2	*2 Recovery devices which are certified by Atmosphere Explosible (ATEX)		

[Knowledge for the common usage of tools for R290 & R32] R290 and R32 machines use different compressor oils.

• If unregulated compressor oil gets mixed into, it may cause damage to the machine function.

[Inserting wrong refrigerant]

- It may cause "not cooling" and "not heating" customer claims because each component (expansion valve, compressor, PCB) of the refrigerant cycle is specially adjusted for R290.
- At the same time, it is not subject to product warranty, if wrong refrigerant was inserted into system.


Reference:-

- ASHRAE Standard 34-2019
- ISO Standard ISO 5149
- ISO 817:2014

13.4 New installation, and Repairing of Refrigerant Cycle System Procedures

Personnels working on A3 systems may be subject to applicable occupational hazard or regulations required by local or national law.


For safe servicing and disposal, technicians must have detailed knowledge and skills in handling of flammable refrigerants, prevention of refrigerant leaks, leak detection, personal protective equipment, cylinder handling and loading. A dry powder or CO₂ fire extinguisher must be available at the place of service.



13.5 Servicing


13.5.1 Recover R290 refrigerant with refrigerant recovery machine CAUTION!

- Always turn ON the combustible leak detector.
- Keep all ignition sources, hot surface, and open flames 3 meter away from the product.
- Ensure the servicing area is well ventilated.
- Ensure the product is service by certified serviceman.
- Ensure to always have the approved fire extinguisher.



CAUTION!

All equipment and material must be ATEX certified to be allowed to operate within Atmosphere Explosible zone.




CAUTION!

Do not refill R290 refrigerant more that 50% of recovery cylinder capacity to avoid overpressure. (Safety risk)

Refrigerant Type Recovery Cylinder Capacity	
R32	80% of the weight
R290	50% of the weight

- 2. Connect the Low side charging hose of the manifold gauge to the service valve (2-way valve) in the outdoor unit.
- 3. Connect the center hose of the manifold gauge to the recovery machine.
- 4. Attached the manifold gauge correctly and tightly. Ensure both valve (Low side and High side) is in close position.
- 5. Connect the hose from recovery machine to the recovery cylinder.
- 6. Turn ON the recovery machine, turn the low side valve, service valve and recovery valve to open position.

13.5.2 Purging by using Nitrogen Gas Before Servicing and Disposal



- 1. Connect nitrogen cylinder to the high side at the manifold gauge. Ensure nitrogen cylinder is connected to pressure regulator.
- 2. Close air release valve and open service valve.
- 3. Open High side valve and nitrogen release valve. (Set the pressure regulator to 200psi).
- 4. Charge nitrogen gas up to 0.7MPa (101psi) or charge 400 grams of nitrogen into the unit.
- 5. Close high side valve and open air release valve (half open) to release remaining propane to the atmosphere. Air release valve must be directed 1 meter from the floor to enable the propane gas to spread properly in the atmosphere. [Beware not to fully open the air release valve to avoid high pressure and compressor oil discharge].
- 6. When gauge 1 pressure reach near atmospheric (15psi) point the combustible leak detector to air release valve to detect the presence of propane. If presence of propane can still be detected, repeat procedure 2 to 5 until presence of propane cannot be detected.
 - [Then refrigerant circuit repairment or unit decommissioning should be done].
- 7. Before charging new refrigerant, vacuum the system until it reaches to 500micron (67Pa) to remove foreign gas in the system and hold for 15 minutes.

14. Operation and Control

14.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal water setting temperature and water outlet temperature.

14.1.1 Internal Water Setting Temperature

Once the operation starts, control panel setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the Air-to-Water Heat pump settings and the operation environment. The final shifted value will be used as internal water setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.

14.1.2 Heating Operation

14.1.2.1 Thermostat Control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > 3°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) < -3°C.

14.1.2.2 Thermostat Control (Outdoor Ambient Temperature)

Stops provide heating to room side during high outdoor ambient condition. Control content:

- Heating operation and water pump will turn OFF when outdoor ambient temperature > outdoor thermo off temperature + 3°C.
 - (Outdoor thermo off set temperature is set by control panel. Thermo off set temperature is between 5°C ~ 35°C)
- Heating operation will resume when Outdoor ambient temperature < Outdoor thermo OFF set temperature + 1°C.

14.1.2.3 Heat Mode Operation

Operation of heat pump provide heating capacity to room side by hot water through heating panel, floor heating or fan coil unit.

- 1 3 ways valve control:
 - 3 ways valve switch and fix to heating side.
- 2 Heat pump operates follow normal heating operation.
- 3 Back up heater operate follow normal operation.
- 4 2 ways valve control:
 - 2 ways valve opens.

14.1.3 Cooling Operation

14.1.3.1 Thermostat Control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature < -1.5°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) > 3°C.

14.1.3.2 Cool Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch and fix to cooling side.
- 2 Heat pump operates follow normal cooling operation.
- 3 Room heater DOES NOT operate during cool mode.
- 4 2 ways valve control:
 - o 2 ways valve is closed.

14.1.3.3 Cooling Capacity Control

The cooling capacity can be set to either Efficiency or Comfort priority. (However, this is only available for WH-WXG12ME8 and WH-WXG16ME8.)

Remocon setting: Cooling capacity = Efficiency (default)

Prioritize efficiency and operate the cooling with reduced capacity

Remocon setting: Cooling capacity = Comfort

Prioritize comfort and operate the cooling at maximum capacity.

14.1.4 Target Water Temperature Setting

14.1.4.1 Target Water Temperature Control of Standard System (Optional PCB not Connected)

There are 2 types of temperature control selection which are Compensation and Direct.

• Temperature control type selection by installer:

1 Compensation: Wlo, WHi, ODLo, ODHi can be set at installer menu.

2 Direct : Direct Water Temperature Set

Remote control setting by user:

1 Compensation : Shift value ±5°C from the compensation curve

2 Direct : Direct water temperature set change

- Target water temperature is calculated as below condition.
 - Target water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct
A (base reinperature)	Value from the curve + User shift value set	Direct value from user setting

o B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below	
Sensor selection		
Water temperature	B = 0	
External Room thermostat	B = 0	
Internal Room thermostat &	Cool Mode: B = 0; when Zone OFF or Zone Room Thermo OFF B = B = 1* (room set temp (R/C) – actual room temp) Max/Min Regulation of B: (Max = 5; Min = -5)	
Room Thermistor	Heat Mode: B = 0; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic	

Maximum/minimum regulation of Target Water Temperature

	Heating	Cooling
MAX	55°C (Below Ambient -25°C) * 75°C (Above Ambient -15°C) *	20°C
MIN	25°C	5°C


^{*} Between outdoor ambient -15°C and -25°C, max target decreases gradually from 75°C to 55°C.

^{*}This setting only able to set when room sensor select as Water Temperature.

^{*}Instead of water temperature, user will set target room temperature when room sensor select as Room Thermistor OR Internal Room Thermostat.

Compensation Type: (Operation under Heat Mode and Cool Mode)


• The set temperature defines the parameters for the ambient (Outdoor temperature) dependent operation of the unit. The water temperature is determined automatically depending on the outdoor temperature. Default setting is the colder outdoor temperature will result in warmer water and vice versa. The user has the possibility to shift up and shift down the target water by remote control setting.



- Outdoor ambient is updated every 30 minutes when operation ON.
- Setting water outlet temperature always follow W_(LO) or W_(HI) whenever is higher if outdoor ambient sensor or indoor communication error happen.

However, when powerful mode is requested by remote control during heating mode, the higher value of HLo or Whi will be used for A calculation.

- * There are 2 compensation curves (for heating and cooling). During heating mode, the heating curve is used and during cooling mode, the cooling curve is use.
- Compensation curve set shift value:



14.1.5 Target Water Temperature at Extension System (Optional PCB is Connected)

Target water temperature is calculated as below.

- Heat Mode:
- When buffer tank selection is "YES:"
 Target water temperature = Target buffer tank temperature + [2°C]
- When buffer tank selection is "NO"
 - If both zone 1 and zone 2 is active
 Target Water Temperature = Higher zone target water temperature of Zone 1 and Zone 2.
 - If only one zone is active
 Target Water Temperature = Zone target water temperature of active zone.

- Cool mode:
- When buffer tank selection is "YES"
 - o If both zone 1 and zone 2 active

Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2

If only one zone is active

Target Water Temperature = Zone Target Water Temperature of active zone

- When buffer tank selection is "NO"
 - o If both zone 1 and zone 2 active
 - Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2
 - If only one zone is active
 - Target Water Temperature = Zone Target Water Temperature of active zone

14.1.6 Target Zone Water Temperature Control

Purpose:- To control zone mixing and zone pump according to the zone sensor temperature

14.1.6.1 Target Zone 1 Water Temperature Setting Control

- Start condition
 - o Heating zone 1 is ON by remote control or Timer or Auto Mode OR
 - Cooling zone 1 is ON by remote control or Timer or Auto Mode.
- Cancel condition
 - Heating zone 1 is OFF by remote control or Timer or Auto mode AND
 - Cooling zone 1 is OFF by remote control or Timer or Auto mode.
- Target Zone 1 water temperature is calculated as below condition.
 - Target Zone 1 water temperature = A (Base temperature) + B (shift temperature)

A (Page Temperature)	Compensation	Direct
A (Base Temperature)	Value from the curve + User shift value set	Direct value from user setting

- During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.
 - B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below	
Sensor selection		
Water temperature B = 0		
External Room thermostat	B = 0	
Internal Room thermostat & Room Thermistor	Cool Mode: B = 0; when Zone OFF or Zone Room Thermo OFF B = B = 1* (room set temp (R/C) – actual room temp) Max/Min Regulation of B: (Max = 5; Min = -5)	
	Heat Mode: B = 0; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic	
Pool Function Selected	B = Delta value setting from remocon	

^{*} B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)

^{*}Cool Mode does not have SG ready control

^{**} Pool function also can be select at Zone 1 when optional PCB is connected and Zone 1 system is select.

Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
MAX	55°C (Below Ambient -25°C) * 75°C (Above Ambient -15°C) *	20°C
MIN	25°C	5°C

^{*} Between outdoor ambient -15°C and -25°C, max target decreases gradually from 75°C to 55°C.

- Target Zone 1 Water Temperature (Heat mode only) during SG ready control
 - o If buffer tank selection is "NO" then following shift is carried out.
 - While digital input is "10" or "11" then,
 Final Target Zone 1 water temperature
 - = Target Zone 1 water temperature* (SG ready % setting (remote control menu))%
 - If buffer tank selection is "YES"
 - No shift of Target Zone 1 Water Temperature. Target Buffer Tank Temperature will change accordingly.
 * Refer to "Buffer tank temperature control"

14.1.6.2 Target Zone 2 Water Temperature Setting Control

- Start condition
 - Heating zone 2 is ON by remote control or Timer or Auto Mode OR
 - Cooling zone 2 is ON by remote control or Timer or Auto Mode.
- Cancel condition
 - Heating zone 2 is OFF by remote control or Timer or Auto mode AND
 - o Cooling zone 2 is OFF by remote control or Timer or Auto mode.
- Target Zone 2 water temperature is calculated as below condition.
 - Target Zone 2 water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct
A (base reinperature)	Value from the curve + User shift value set	Direct value from user setting

- * During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.
 - B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below		
	Sensor selection		
Water temperature	B = 0		
External Room thermostat	B = 0		
Internal Room thermostat & Room Thermistor	Cool Mode: B = 0; when Zone OFF or Zone Room Thermo OFF B = B = 1* (room set temp (R/C) – actual room temp) Max/Min Regulation of B: (Max = 5; Min = -5)		
Room memistor	Heat Mode: B = 0; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic		
Pool Function Selected	B = Delta value setting from remocon		

^{*} B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool "B" value)

^{**} Pool function also can be select at Zone 2 when optional PCB is connected and Zone 2 system is select.

Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
MAX	55°C (Below Ambient -25°C) * 75°C (Above Ambient -15°C) *	20°C
MIN	25°C	5°C

- * Between outdoor ambient -15°C and -25°C, max target decreases gradually from 75°C to 55°C.
- Target Zone 2 Water Temperature (Heat mode only) during SG ready control
 - o If buffer tank selection is "NO" then following shift is carried out.
 - While digital input is "10" or "11" then,
 Final Target Zone 2 water temperature
 - = Target Zone 1 water temperature* (SG ready % setting (remote control menu))%
 - If buffer tank selection is "YES"
 - No shift of Target Zone 2 Water Temperature. Target Buffer Tank Temperature will change accordingly.
 * Refer to "Buffer tank temperature control"

14.1.6.3 Zone Temperature Control Contents


- During Standard System (Optional PCB not connected)
 - Only 1 zone temperature control is available
 - This zone room temperature is control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temperature)
 - Target Zone Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor. Target Water Temperature will set same as Target Zone Water Temperature
 - Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).
- * There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.
- During Extension System (Optional PCB connected)
- * There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.
- During Extension System (Optional PCB connected)
- Buffer Tank connection select "NO" &
 - o One zone system is select
 - This zone room temperature control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temp.)
 - Target Zone Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor.
 - Target Water Temperature will set same as Target Zone Water Temperature
 - Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).
- * There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.
 - o 2 zone system select
 - Each zone room temperature is control by each sensor which select from either one of the 4 room sensor
 - Target Zone 1 & 2 Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor.
 - * Zone Mixing Valve & Zone pump will operate to achieve Target Zone Water Temperature which refer to zone sensor.
 - * Zone Sensor will detect if zone sensor is open or short.
 - Target Water Temperature will set same as the active & higher zone water temperature setting. (When cooling mode, lower zone water temp setting)

- Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
- Heat pump and water pump OFF when ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat).

Buffer Tank Connection select "YES" &

- 1 zone system or 2 zone system select
 - Each zone control by each sensor which select from either one of the 4 room sensor
 - Target Zone 1 & 2 Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor. Each zone have their own Target Zone Water Temperature.
 - * Zone Mixing Valve & Zone pump will operate to achieve each Target Zone Water Temperature which refer to zone sensor
 - * Zone Sensor will detect if zone sensor is open or short.
 - Target Buffer Tank Temperature will be set as active & higher zone water temperature setting + Buffer Delta T. (Heating) Target Buffer Tank Temperature will be set as active & lower zone water temperature setting (Cooling).
 - Target Water Temperature will set as Target Buffer Tank Temperature + [2°C] (Heating) Target Water Temperature will set as Lower or Active Target Zone Water Temp. + [-3°C] (Cooling)
 - Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM thermo OFF
 - Heat mode: ROOM thermo OFF (Buffer Tank Temperature > Target Buffer Tank + [0°C]
 - Cool mode: ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat)

14.1.7 Auto Mode Operation




Control details:

- o To enable the unit to operate either heat or cool mode automatically, heat to cool set temperature and cool to heat set temperature can be set by control panel.
- Automatic operation is judged based on control panel setting temperature and outdoor ambient temperature.
- * Minimum setting of heat to cool set temperature is 1°C higher than cool to heat set temperature.

Judgement control:

- o If outdoor ambient temperature < Heat to Cool Set Temperature, unit will operate in Heat Mode or else the unit will operate in Cool Mode.
- If current operation is Cool mode, outdoor ambient temperature > Cool to Heat Temperature, unit will maintain Cool mode operation or else the unit will operate Heat mode.
- o If current operation is Heat mode, outdoor ambient temperature > Heat to Cool Temperature, unit will maintain Heat mode operation or else the unit will operate Cool mode.
- Every 60 minutes the outdoor ambient temperature is judged.
- When Auto + Tank mode is selected, operation mode switching is judged by both outdoor ambient temperature and indoor air temperature.

14.1.8 Auto Cooling Mode Operation Limit



- Auto Mode Cooling Only operation will start once the outdoor ambient temperature reaches 19°C and compressor will continue to run until the outdoor ambient temperature drops to 16°C.
- Due to this limitation,
 If Heat to Cool temperature is set lower than 19°C, the compressor will not operates until the outdoor ambient temperature reaches 19°C or higher.

14.1.9 Tank Mode Operation

- 3 ways valve direction
 - 3 ways valve switch to tank side during Tank Thermo ON condition. Switch 3 ways valve to room side when tank achieve Tank Thermo OFF temperature.
- Tank Thermo ON/OFF Characteristic
 - o Tank Thermo OFF

Case 1: Internal Tank Heater is select and Tank Heater ON

- o Tank temperature > Tank Set Temperature continuously for 15 seconds.
- Water outlet >75°C
- Case 2: Tank Heater OFF OR External Heater is select
 - When heat pump OFF due to water thermos & Tank temperature > Tank water set temperature for continuously 20 seconds. OR
 - Tank temperature > Tank set temperature + 1°C for continuously 20 seconds.
 - o Tank Thermo ON

Case 1: Tank Heater ON (Internal Tank Heater)

Tank temperature < Tank set temperature + R/C (Tank re-heat temperature)

Case 2: Tank Heater OFF (Internal Tank Heater)

- o Tank temperature < Tank water set temperature + R/C (Tank re-heat temperature)
- * When tank thermo ON, water pump will ON for 3 minutes then only heat pump turn ON.
- * Tank water set temperature = tank set temperature or 65°C whichever lower.
- 2 ways valve close
- Heat pump Thermostat Characteristic
 - Heat pump Water Outlet set temperature is set to below table:

Outdoor ambient temperature	Heat pump water outlet temperature
< -20°C	55°C
> -20°C	65°C
> -10°C	75°C

Characteristic of heat pump thermos ON/OFF under tank mode condition:

Water Outlet Thermo Condition

- Heat pump thermos OFF temperature:
 - 1 Heat pump thermo OFF temperature = Target Water outlet temperature + (2°C)
 - Water outlet temperature > heat pump thermo OFF temperature for continuously 3 minutes, heat pump OFF but water pump continue ON.

- Heat pump thermo ON temperature
 - 1 Heat pump thermo ON temperature = water inlet during thermo OFF time + [-3°C]
 - When water outlet temperature < heat pump thermo ON temperature, heat pump ON.

Water inlet thermo protection condition

- Heat pump thermo OFF temperature:
 - 1 Water inlet temperature > [75°C/55°C] for continuously 30 seconds, heat pump OFF, water pump continue ON.
- Heat pump thermo ON temperature:
 - 1 Heat pump thermos ON temp = water inlet temperature < [75°C/55°C].

Outdoor ambient temperature	Water inlet temperature
< -25°C	55°C
> -25°C	75°C

Thermo ON/OFF for Heat Pump in Tank Operation:

When tank temperature achieve heat pump OFF condition, refer below condition:

Conditon 1 : Tank Heater ON (Internal Tank Heater)

 Heat pump will turn OFF, water pump continue ON and room heater will continue ON if tank temperature below tank heater thermo ON condition. 3 ways valve will only switch to room side after tank temperature reach tank heater thermo OFF condition.

Conditon 2: Tank Heater OFF (Internal Tank Heater)

• If tank temperature achieve tank thermo OFF, heat pump turn OFF, water pump turn OFF, room heater OFF and 3 ways valve switch to room side.

When tank temperature achieve heat pump ON condition, water pump ON, heat pump ON and room heater turn OFF.

Heat pump OFF condition at Tank Mode

- Tank temperature > tank water set temperature continuously for 20 seconds after heat pump thermos OFF due to water thermo. (Heat pump turn OFF but water pump continue ON and room heater turn ON to achieve tank set temperature) OR
- Tank temperature > tank set temperature + [1°C] for continuously 20 seconds. (Heat pump OFF, water pump OFF, room heater OFF and 3 ways valve switch to room side)

Heat pump ON condition at Tank Mode

Tank temperature < tank water set temperature + R/C setting (Tank re-heat temp) (Water pump turn ON OR continue ON, heat pump ON and 3 ways valve switch to tank side or maintain at tank side)

Tank heater control

Internal heater only operates to tank side if Tank heater ON and backup heater is enable.

Internal heater turn ON condition:

- Tank temperature < tank set temperature AND
- Heat pump thermos OFF AND
- 20 minutes from previous heater off AND
- Internal tank heater selects USE from control panel.

Internal heater turn OFF condition:

- Tank temperature > tank set temperature for continuously 15 seconds OR
- Heat pump thermo ON OR
- Mode change or operation is off by control panel.

14.1.10 Heat + Tank Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch to room side during room heat-up interval and switch to tank side during tank heatup interval. Both modes will switch alternately. Tank mode is the initial running mode of Heat + Tank mode.
- 2 Heat pump operation control:
 - During room heat-up interval
 - Follow normal heating operation.

Switching to tank side depends to below cases:

Case 1:

[Previous switch from tank interval to room interval due to thermo OFF]

Switch to tank heat-up interval when Tank temp < Tank thermos ON temp (Room heat-up interval ends)

Case 2:

[If heating operation at room side is less than 30 minutes and switch to tank side 3 times consecutively]

 Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature. Case 3:

[Previous switch from tank interval to room interval due to tank interval timer is complete]

- Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete OR Room heat pump thermo OFF) AND tank temperature < Tank thermo ON temperature.
- During Tank heat-up interval
 - Tank interval is the first mode running when heat + tank mode is select.
 - Switch to room interval only when tank achieve tank thermo OFF OR tank heat-up interval timer is complete.
 - Heat pump operates according to normal tank mode operation.
- 3 Room heater control:
 - During heating heat-up interval
 - Follow normal room heater control operation.
- 4 Tank heater control:
 - During heating heat-up interval
 - Internal tank heater will not function under heating heat-up interval.
 - During tank heat-up interval
 - Internal tank heater will turn ON after heat pump thermo off to boil tank temperature to tank set temperature.
 - o 2 ways valve control is open
 - o Indoor water pump control:
 - Indoor water pump always turn ON if room heat pump thermo ON **OR** Tank thermo ON.

14.1.11 Cool + Tank Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch to room side during room cooling interval and switch to tank side during tank heatup interval. Both mode will switch alternately. Tank mode is the initial mode of cool + tank mode.
- 2 Heat pump operation control:
 - During room heat-up interval
 - Follow normal cooling operation.

Switching to tank side depends to below cases:

Case 1:

[Previous switch from tank interval to room interval due to thermo OFF]

 Switch to tank heat-up interval when Tank temperature < Tank Thermo ON temperature (Room interval will ends)

Case 2:

[If cooling operation at room side is less than 30 minutes and switch to tank side for 3 times consecutively]

 Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature.
 Case 3:

[Previous switch from tank interval to room interval is due to tank interval timer is complete]

 Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank thermo ON temperature.


*Tank Thermo ON temperature:

Internal Tank Heater select USE	<tank (tank="" +="" c="" p="" r="" re-heat="" set="" setting="" temperature="" temperature)<=""></tank>
Others	<tank (tank="" +="" c="" p="" r="" re-heat="" set="" setting="" temperature="" temperature)<="" water=""></tank>

- During Tank heat-up interval
 - Tank interval is the first mode running when the cool + tank mode is select.
 - Switch to room interval only when tank achieve tank thermo OFF OR tank heat-up interval timer is complete.
 - Heat pump operates according to normal tank mode operation.
- 3 Room heater control:
 - During room cooling interval
 - · Room heater is OFF and not operates.
- 4 Tank heater control:
 - During room cooling interval
 - Internal tank heater will not function under room cooling interval.
 - During tank heat-up interval
 - Internal tank heater will turn ON after heat pump thermos off to boil tank temperature to tank set temperature.
- 5 2 ways valve is close.
- 6 Indoor water pump control:
 - Indoor water pump always turn ON if room heat pump thermo ON OR Tank thermo ON.

14.1.12 Outdoor Fan Motor Operation

It starts 30 seconds before compressor starts operation and it stops 60 seconds after compressor stops operation.



The reason the outdoor fan stops 60 seconds after the compressor stops is to exhaust heat.


The reason why the compressor starts operating 30 seconds before it starts is to accurately detect the outside temperature.

14.2 Water Pump

The system will start checking on the water flow level after operation start for 70 seconds. If water pressure level is detected low or high continuously 300 seconds, the water pump and the compressor will be OFF permanently and OFF/ON control panel LED will blink (H21 error occurs).

14.2.1 Water Pump Control

- Once the indoor unit is ON, the water pump will be ON immediately and no error judgment for 30 seconds.
 However, during this 30 seconds operation, if there is any abnormality cause at outdoor or malfunction, the compressor should be OFF immediately and restart delay after 3 minutes.
- The system will start checking on the water flow level after operation start for 30 seconds. If water flow level is detected low continuously 140 seconds, the water pump and the compressor will be OFF permanently and OFF/ON control panel LED will blink (H62 error occurs).
- When error happens, the power has to be reset to clear the error.
- If there is no error indication, the water pump shall be continuously running.
- The water pump will remain ON when compressor OFF due to thermostat OFF setting is reached.
- Water pump will OFF when room thermo OR tank thermo OR buffer tank thermo OFF.
- Water pump will delay 15 seconds to turn OFF when request to OFF except during anti-freeze deice activate or air purge mode.



Maximum pump speed setting on remote control


• Standard pump speed is automatically controlled to get the designed water temperature different between water inlet and outlet (ΔT). Instead of setting the standard pump speed, maximum pump speed is manually adjusted by the installer according to water circuit pressure drop.

However, the following sequences do not follow maximum pump duty setting by remote control.


- Pump down mode
- Air purge mode
- Normal deice

1) P-Q graph for different pump HEX duty

• Connection Control Module (WH-WXG09ME8, WH-WXG12ME8)




• Connection Control Module (WH-WXG16ME8)



14.2.2 Zone Water Pump Control

Purpose:

• Water pump install at each zone to circulate the water inside each zone during buffer tank connection selected "YES" or 2 zone systems.



Content:

- AC type water pump install for this zone water pump control. When optional PCB connected, 230V output will
 drive this zone pump.
- There are three pump can be connected through Optional PCB. (Zone 1 Pump, Zone 2 Pump, & Pool Pump)
 - * Zone 1 pump [P1] use to circulate zone 1 water circuit & Zone 1 mixing valve [M1] adjust to control the Zone 1 target water temperature.
 - * Zone 2 pump [P2] use to circulate zone 2 water circuit & Zone 2 mixing valve [M2] adjust to control the Zone 2 target water temperature.
 - * When Pool Function select as Zone 2 circuit, [P2] use to circulate water to heat exchanger which use to transfer heat to pool water.
 - * Pool pump [P3] circulates the pool water through the heat exchanger to get warm water.
- Zone 1 and Zone 2 water pump start condition:
 - Zone room request ON (eg. Zone 1 thermo ON, only zone 1 pump will turn ON)
- Zone 1 and Zone 2 water pump stop condition:
 - Zone room request OFF
- Pool water pump start condition:
 - Pool Zone request ON AND
 - Pool function is selected
- Pool water pump stop condition
 - o Pool zone: Zone room request OFF OR
 - Pool function is cancel
 - * Zone 1 & Zone 2 water pump need to turn OFF when antifreeze deice pump stop control activate and turn ON back after the antifreeze deice pump stop control end under setting of "NO" buffer tank connection.

Zone Pump Prohibit ON control:

Start condition:

Zone 1 water temperature ≥ 80°C continuously for 5 minutes *stop zone water pump operates if the zone water fulfilled.

Cancel condition:

After 30 minutes from start condition fulfilled.

*zone water pump operates according to normal condition.

Zone Pump Control during Anti-Freeze

Zone pump control during Zone Anti-Freeze Control:

- When Zone Anti-Freeze Flag=1, Zone Pump Turn ON.
- When Zone Anti-Freeze Flag=0, Zone Pump Turn OFF.

Zone pump control during Indoor Anti-Freeze Control:


Zone pump only ON/OFF if the Extension PCB connected and Buffer Tank select "NO" condition

When Indoor Anti-Freeze flag=1, Zone Pump Turn ON When Indoor Anti-Freeze flag=0, Zone Pump Turn OFF

* Pool Water Pump will not affected by both Indoor anti-freeze control or zone anti-freeze control.

14.2.3 Water Pump Speed Feedback Error

- Basically pump speed feedback is control by micon.
- When pump speed is below low limit or over high limit for a few seconds, micon detect pump error and system is stopped.
- Error detection conditions:
 - Detect abnormal water pump speed for continuous 10 secs.
 - o Current pump speed < 300 rpm or
 - Current pump speed > 6000 rpm for 10 seconds.
- Control contents:
 - When error occurs, water pump, heating and heater is stopped for 30 seconds then restart again (Retry control).
 - When micon detect error again, system is stopped and error code [H20] is displayed at control panel.



14.3 Extra Pump Function (Optional)

There are three different controls for the external pump, Heat (default), DHW or NO.

Remocon setting: Extra pump = Heat (default)

This is the conventional setting for adding an external water pump when the flow rate is insufficient due to water pressure loss, etc.

Start conditions:

- 1) Outdoor Water Pump Turn ON
- 2) 3 ways valve switch at room side
- 3) External Pump control for Bivalent ON. (Alternative or SG ready mode or Smart mode)
- 4) Heat Pump OFF AND Boiler turn ON under Bivalent control
- 5) When Optional PCB Connectivity select No AND Buffer Tank Connection select Yes
- 6) Not Tank only mode AND Zone room thermo ON When [(1) AND (2)] OR [(3) AND (4)] OR [(5) AND (6)] fulfill, turn ON extra pump. *Output 230V to the external pump when fulfil start condition.

Cancel conditions:

- Outdoor water pump turn OFF
- 2) 3 ways valve switch to tank side
- 3) Heat pump OFF and Boiler OFF under Bivalent Control
- When Optional PCB Connectivity select No AND Buffer Tank Connection select Yes
- 5) Tank Only mode
- 6) Zone room thermo OFF

When {[(1) OR (2)] AND (3) } OR { (4) AND [(5) AND (6)]} fulfill, turn OFF extra pump.

*Stop output 230V to external pump when either one stop condition fulfil.

Remocon setting: Extra pump = DHW

This is the setting when using DHW circulation operation.

DHW circulation start conditions

All of the following holds

- 1) Extra pump = "DHW"
- 2) DHW circulation is effective time.
- 3) Tank mode is "ON"

DHW circulation start conditions

Which of the following holds

- 1) Extra pump = "No" or "Heat"
- 2) DHW circulation isn't effective time.
- 3) Tank mode is "OFF"

DHW circulation operation

Operation is 2 type, Confort or Efficiency

DHW circulation operation (Comfort)


Prioritize comfort over power consumption

- 1) When DHW circulation request is received, pump port is supply 230V
- 2) During this operation, 230V is always supply
- 3) When operation is "OFF", 230V is stopped

DHW circulation operation (Efficiency)

Pump operate intermittent (ON/OFF)

- 1) When DHW circulation request is received, pump port is supply 230V.
- 2) Pump operate intermittent (ON/OFF)
 ON time and OFF time is decided by Remocon.
- 3) When operation is "OFF", 230V is stopped




Remocon setting: Extra pump = No

The extra pump does not work.

14.4 Indoor Unit Safety

14.4.1 Indoor Unit Safety Control

- 1 When water pump is ON, the system will start checking flow switch status (ON/OFF).
- 2 If the flow switch ON for 10 seconds, the system will check on the water inlet temperature for 10 seconds. If the water inlet temperature not exceeds 80°C, the water pump shall be continuously running with normal mode.
 - If the water inlet temperature exceeds 80°C for continuously 10 seconds, the water pump will be OFF immediately.
- 3 After water pump OFF for more than 10 minutes, it will be ON back and the indoor unit safety control checking is restarted.



14.5 Auto Restart Control

1 When the power supply is cut off during the operation of Air-to-Water Heatpump, the compressor will reoperate after power supply resumes.

14.6 Indication Panel

LED	Operation
Color	Green
Light ON	Operation ON
Light OFF	Operation OFF

Note:

• If Operation LED is blinking, there is an abnormality operation occurs.

14.7 External Heater Control (Optional)

Control for attaching an external heater

When the external heater is In-line heater.

- Select "in-line" in the "External Heater" menu on the remote control.
- The heaters enabled by the above selection will operate in the same way as "Back-Up Heater" during Heating operation.

When the external heater is Buffer tank heater.

• Select "Buffer tank" in the "External Heater" menu on the remote control.

14.8 Indoor Back-Up Heater Control

14.8.1 Indoor Electric Heater Control

- 1 Normal Heating Mode
 - o Heater On condition:
 - a. Heater switch is ON
 - b. After Heatpump thermo ON for [30] mins
 - c. After water pump operate [9] mins
 - d. Outdoor air temperature < Outdoor set temperature for heater
 - e. When water outlet temperature < Water set temperature + [-4°C]
 - f. [20] minutes since previous Backup heater Off
 - * When heatpump cannot operate due to error happens during normal operation, heater will go into force mode automatic
 - * Heater need to operate during deice operation
 - Heater Stop Condition:
 - a. When outdoor set temperature > outdoor set temperature + [+2°C] for continuous 15 secs OR
 - b. When water out temp> water set temperature + [-2°C] for continuous 15 secs OR
 - c. Heater switch is Off OR
 - d. Heatpump thermo-off or OFF condition

2 Force Heater Mode

- o Heater On condition:
 - a. After water pump operate [9] mins
 - b. When water outlet temperature < water set temperature + [-4°C]
 - c. [20] minutes since previous Backup heater Off
- Heater Stop condition
 - a. Force mode off OR
- b. When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs
- * Do not operate heater at the following situation
- 1 Water outlet temperature sensor, and water inlet sensor abnormal
- 2 Flow switch abnormal
- 3 Circulation pump stop condition

^{*}However, a heater that has external heater control enabled cannot be used for protection control.

14.9 Tank Heater Control (Excluding when Operating in Standalone)

14.9.1 Tank Heater Remote Control Setting


- 1 Tank heater selection:
 - External: Booster Heater use to heat up tank when select external
 - * When select External Tank Heater, Heater Delay ON Timer need to set. (range 20 min ~ 3 hrs)
- 2 Tank Heater ON/OFF selection by user.

The remote control Tank set Temperature range will change according to the External and Internal Tank Heater use.

Tank Heater Selection	Range
External	40 ~ 75°C

14.9.2 External Heater Control at Tank Side

Heating operation condition:



- Tank heater Turn On condition:
 - 1 External Heater selected for Tank heater by remote controller.
 - 2 Tank Heater select ON by user.
 - 3 Tank mode operation ON (Tank mode, Heat + Tank, or Cool + Tank).
 - 4 After TANK HEATER DELAY TIMER fulfill during heat pump startup time in tank mode, or during switching from heating heat-up interval to tank heat + up interval in heat + tank mode.
 - 5 Tank temperature < tank set temperature + [Remote controller Set Tank Re-heat Temp] + [-1°C].</p>
 - 6 20 minutes since previous heater off.
 - * TANK HEATER DELAY TIMER is clear when tank heat-up interval end.
- Tank heater Turn Off condition:
 - 1 Tank temperature > tank set temperature + [0°C] for continuous 15 seconds.
 - When BOOSTER HEATER DELAY TIMER start count after switch from heating heat-up interval to tank heat-up interval
 - 3 Tank Heater select OFF by user.
 - 4 Tank Mode Operation OFF.

14.10 Base Pan Heater Control (Optional)

- To enable the base pan heater function, control panel initial setting has to be manually adjusted by activating Base Pan Heater menu.
- There are 2 optional start condition can be selected, Type A or Type B.
- Control details:
 - 1 Type A: (Default Auto Mode)

Start conditions:

o When outdoor air temperature ≤ 3°C during heating and deice operation is ON.

Control contents:

 Base pan heater is ON during deice operation and continues ON for 10 minutes after deice operation ends.

Cancel condition:

- When outdoor temperature > 6°C after deice end or
- When operation is not at heating mode or
- Base pan heater ON timer count is completed.

2 Type B: (ON Mode)

Start conditions:

When outdoor air temperature is ≤ 5°C and operates in heating mode, base pan heater is ON.

Cancel conditions:

- When outdoor air temperature is > 7°C or
- When operation is not at heating mode.

14.11 Force Heater Mode

Purpose of Force Heater Mode:

As a backup heat source when heat pump error. Force heater Mode only control backup heater to heat up the
room circuit, and turn ON back up heater or booster heater to boil up tank water base on the tank heater
selection.

Force Heater Control start condition:

- Force heater request ON by user during error OR auto turn ON by remote controller during error AND
 (Force Heater mode can be operate regardless of mode selection, remocon will send the latest mode selection
 force bit by bit to indoor. Indoor will judge to turn ON heater to room side if it is heat mode selected, and turn ON
 heater to heat tank water base on tank heater selection)
- During Error Happen (exclude the error list below)

Error List which not allow Force Heater operation

H12	Capacity Mismatch	H90	Abnormal ID/OD communication
H20	Abnormal Water Pump	H95	Abnormal Voltage Connection
H21	Abnormal Water Pressure	F30	Abnormal water outlet 2 sensor
H62	Abnormal Water Flow	F37	Abnormal Water Inlet sensor
H70	Abnormal Back-up Heater OLP	F45	Abnormal Water Outlet sensor
H74	PCB Communication Error	F50	Abnormal Water Inlet 2 sensor
H76	Indoor-Remote Controller Communication Error		
[When tank mode operate with external heater selected & tank heater select ON]		ON]	
H22	Abnormal tank 2 sensor	H91	Abnormal tank heater OLP
H72	Abnormal tank 1 sensor		

Force Heater Control Stop Condition:

- Force Heater request OFF OR
- Operation OFF request OR
- Power reset OR
- Error of above list happens during force heater operation.

Control contents:

- After fulfill start condition, indoor will operate the force heater operation according to below mode condition Heat mode Only: Turn ON backup heater to achieve room heat pump target water temperature.
 - Heat + Tank mode: Turn ON backup heater to heat up room **OR** Turn ON Heater to Boil up tank water.
 - Cool mode Only: Water pump and backup heater will OFF in force heater mode.
 - Cool + Tank mode: Operate pump and internal Heater OR External heater to Boil up tank water.
 - Tank mode Only: Operate pump and internal Heater OR External heater to Boil up tank water.
 - * For heat mode condition, backup heater will only turn ON if the backup heater is enable regardless of Room Heater Selection.
 - * For tank mode condition, If internal heater selected backup heater will turn ON to boil up tank water.
 - If external heater selected, booster heater will turn ON to boil up tank water regardless of tank heater selection.

Room Side: (Heat Mode):

- When force heater mode start condition fulfilled, turn ON water pump and turn ON backup heater follow below control.
- Operate the 3 ways valve at room side only and turn ON 2 ways valve as heat mode operation.
- Turn ON the zone pump and mixing valve if system select 2 zone system or Buffer tank connect YES, control according to normal zone pump and mixing valve control.
- When Force heater mode stop condition fulfilled, turn OFF heater as below condition and turn OFF water pump after pump delay time.

Backup Heater On Condition:

- When Force Heater Control start condition fulfill AND
- After water pump operate 2 minutes AND
- When water outlet temperature < water set temperature + [-4°C] AND
- 20 minutes since previous Backup heater Off AND
- Backup Heater Enable

Backup Heater Stop condition:

- Force mode off OR
- Operation off OR
- When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs **OR**
 - * ON/OFF follow normal heater sequence.

Tank side (Tank mode):

- When tank mode select and force heater bit received, turn ON backup heater (INTERNAL) or Booster Heater (External) depend on the tank heater selection.
- If tank heater selection is INTERNAL, follow normal thermo judgement to switch 3 ways valve to tank side and room side.
- If tank heater selection is EXTERNAL, only turn ON booster heater according to tank thermo.

Tank Heater selection is EXTERNAL:

Booster Heater ON condition:

- Force Heater mode ON AND
- Tank temperature < tank set temperature + [Remocon Set Tank Re-heat Temp] 1°C, AND
- 20 minutes since previous heater off.

Booster Heater OFF condition:

- Tank temperature > tank set temperature for continuous 15 secs.
- Force mode OFF
- Tank Mode Operation OFF
 - (During tank interval or tank mode condition, water pump and 3 ways valve will OFF)

14.12 Powerful Operation

Powerful mode is use to increase the capacity of heat pump to achieve higher target temperature. Powerful mode is applicable when heat mode is operating.

Remote control setting:

On quick menu of remote control, there is 4 options of powerful mode can be select.

OFF
: Cancel powerful mode
: Set powerful for 30 minutes
: Set powerful for 60 minutes
: Set powerful for 90 minutes

Control contents:

During the time set by remote control, powerful will activate according to 2 shift up controls. However, this function is applicable only for heating. Remote control will transmit the signal to indoor unit once this function is select then transmit OFF signal to indoor when the timer is complete. Indoor will transmit signal to outdoor for frequency control.

Indoor setting temperature shift

- If system is standard system (Optional PCB is not connected)
 - o Target water temperature will shift up to Wlo or Whi whichever higher.
- If system is extension system (Optional PCB is connected)
 - o Target water Zone 1 and Zone 2 temperature will shift up to Wlo or Whi whichever higher.
 - * If "Direct Type" temperature control is select, this powerful shift up setting is not effective.

Start condition

o Powerful function is select by remote control.

End Condition

- OFF/ON button is pressed.
- Powerful function is OFF by remote control.

14.13 Quiet Operation

Quiet mode is use to reduce the noise of outdoor unit by reducing the frequency or fan speed.

Quiet level

There are 3 level (Level 1, Level 2, Level 3) to set by quick menu function on remote control.

Control content

Once the quiet function is select, the remote control will transmit the signal to indoor and outdoor unit.

Quiet priority

Set whether to prioritize "Sound" or "Capacity"

In case of "Sound" is set for "Quiet priority" in the function setup of the remote control Start condition

Quiet mode is set on remote control.

Quiet mode is request ON by weekly timer.

Stop condition

OFF/ON button is pressed.

Quiet mode is OFF by remote control.

Quiet mode is request OFF by weekly timer.

In case of "Capacity" is set for "Quiet priority" in the function setup of the remote control Start condition

- 1) Quiet mode is set on remote control.
- 2) Quiet mode is request ON by weekly timer.
- 3) During heating: Water outlet temperature > Target Water Temperature 3°C
- 4) During Cooling: Water outlet temperature < Target Water Temperature + 3°C
- 5) During operation mode when 3 way valve is at tank direction : Tank temperature > Tank set Temperature 3°C

When condition {(1) or (2)} and {(3) or (4) or (5)} is fulfilled, after the quiet mode start by user or timer.

Stop condition

- 1) Quiet mode is OFF by remote control.
- 2) OFF/ON button is pressed.
- 3) Quiet mode is request OFF by weekly timer.
- 4) During heating : Water outlet temperature ≤ Target Water Temperature 5°C for continues 30 minutes
- 5) During Cooling : Water outlet temperature ≥ Target Water Temperature + 5°C for continues 30 minutes
- 6) During operation mode when 3 way valve is at tank direction : Tank temperature <= Tank set temperature 5°C for continues 30 minutes

When any of above mentioned condition is achieved, this control is cancelled.

14.14 Sterilization Mode

• Purpose:

o To sterilize water tank by setting the required boiling temperature.

Remote control setting

- Days for sterilization function to start can be select.
- o Time of selected day to start sterilization function.
- Boiling temperature (External heater is 55°C ~ 75°C)
- o Maximum operation time is 5 minutes to 1 hour.

Start condition

- Tank connection set to "YES" by remote control
- Sterilization function selects "YES".
- Sterilization signal received from remote controller by timer.
- o Tank mode request ON.

Stop condition

- When boiling timer is completed. Boiling timer (Remote control set maximum operation time) start counting once tank achieve boiling set temperature **OR**
- o After 8 hours of operation since sterilization start.
- Tank mode request OFF.

• Control content:

- During sterilization function activation time, target tank set temperature will internally change to boiling set temperature.
- During sterilization activates, heat pump and heater (external or internal) will operate as normal tank mode to achieve the boiling set temperature.
- Sterilization operation will end when stop condition is fulfill.
- o After sterilization is complete, tank set temperature will resume to normal operation.

14.15 DHW Circulation Pipe Sterilization Operation

Purpose:

This control is designed to prevent legionella for DHW circulation pipe.

DHW circulation pipe sterilization mode start conditions

All of the following holds

- 1) Remocon setting: Extra pump = DHW
- 2) Tank sterilization operation is finished.
- 3) Tank sterilization is completed within 490 minutes since sterilization function start

DHW circulation pipe sterilization mode stop conditions

Which of the following holds

- 1) After 490 minutes of operation since DHW circulation pipe sterilization start
- 2) Circulation pump operated 30 minutes
- 3) Tank mode Request OFF
- 4) Remocon setting: Extra pump = Heat or NO

^{*} Tank temperature may not achieve boiling set temperature if tank heater is select OFF **OR** external compressor switch.

DHW circulation pipe sterilization mode control contents


It works in the following order.

- 1) Tank sterilization mode is ON
- 2) Tank boiling start Target temp. is RC setting
- 3) Tank sterilization mode finish or stop.
- 4) DHW circulation pump operate during 30 minutes
- 5) Back to normal operation

14.16 Outdoor Ambient Thermo OFF Control

Purpose:

Stop provides heating to room side during high outdoor ambient condition.



Control content:

- Heating outdoor ambient thermo OFF control only applicable when heat pump operate in heat mode. (This
 control will not activate when running in tank side)
- Heat pump and water pump will turn OFF when outdoor ambient is higher than outdoor thermo OFF set temperature.
- Heat pump will thermo ON back when outdoor ambient < Outdoor thermo ON set temperature and RC delay time has passed after Heating thermo-ON temperature is reached.

14.17 Alternative Outdoor Ambient Sensor Control

Purpose of the Alternative Outdoor Ambient Sensor:

• It is some possibility that the air to water heat pump unit will install at a location where the original ambient sensor is expose to direct sunlight. Therefore, another optional ambient sensor can be connect to indoor PCB and locate at new and better reading location to improve the heat pump performance.

Control Detail:

- Remocon can select either the extra outdoor ambient sensor is connected or not. (YES/NO)
- The alternative outdoor ambient sensor will connect to indoor unit main PCB terminal.
 - when alternative sensor select NO
 - Original Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
 - Data communication direction: OUTDOOR send outdoor temperature reading to INDOOR.
 - Error judge: OUTDOOR will judge the original outdoor sensor error (F36 display if error detect). No
 judge error on alternative outdoor sensor
 - when alternative sensor select YES
 - Alternative Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
 - Data communication direction: INDOOR send outdoor temperature reading to OUTDOOR.
 - Error judge: INDOOR will judge the Extra outdoor sensor error only after operation ON request received from remocon.
 - (F36 display if error detect). No judge error on original outdoor sensor.

14.18 Force DHW Mode

Purpose:

When user want to use hot water now, user can press this force DWH mode under the quick menu to operate tank only mode to boil up the tank temperature.

Remocon setting:

Force DHW function can be activate under quick menu.

Control Content:

- when press the Force DHW function during operation OFF condition:
 - When receive this Force DHW bit from remocon, indoor will run tank only mode regardless of the mode selection.
 - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to operation OFF with previous mode selection.
- When press the Force DHW function during operation ON condition:
 - When receive this Force DHW bit from remocon, indoor will memories the running mode and run tank only mode regardless of the mode selection.
 - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to previous memories running mode.
 - * When operation OFF or mode change request from remocon during force DHW mode operation, End force DHW mode and follow the new request operation.
 - * Once receive force DHW mode from remocon, indoor direct start tank mode and consider tank thermo ON. Thermo OFF only when achieve tank thermo OFF depend on the Tank System Setting.

14.19 SMART DHW Mode

Panasonic All In One model provide the option to choose STANDARD DHW Mode or SMART DHW Mode for Tank Heat Up according to requirement. SMART DHW mode comparatively consume lower tank heat up power but longer re-heat time than STANDARD DHW Mode.

SMART DHW control

- During SMART DHW start time 20:00 (Default Setting) to SMART DHW stop time 05:00 (Default setting)
 Heat pump re-heat the tank water only when tank temperature drop below 20°C (Default setting)
- Time between 05:00 to 20:00
 Heat pump reheat the tank water when tank temperature as below condition

Condition 1: Tank Heater ON

Reheat when tank temperature below tank set temperature + R/C (Tank re-heat Temperature) - 3°C

Condition 2: Tank Heater OFF


Reheat when tank temperature below Tank set temperature or 52°C (Whichever lower) + R/C (Tank re-heat Temperature) -3°C

* SMART DHW start time, stop time and SMART ON Temperature can change in CUSTOM menu.

14.20 Anti Freeze Control

- Anti freeze protection control menu can be set YES or NO by control panel.
 - 1. Models without Back up heater (Standalone and connection control module):

Outdoor air temp zone is defined as below:



- Water pump circulation anti freeze control
 - Water pump turns ON when ALL below conditions are fufilled:
 - o Heat pump OFF (Stand by) OR error occurs.
 - Water flowing flag is ON.
 - o Water flow sensor is not abnormal.
 - o Outdoor air temp zone is any of Zones 1 to 4 OR outdoor ambient temp. sensor is abnormal.
 - Water inlet 2 / outlet 2 temp. < [A°C]
 - o After 5 minutes from previous water pump OFF.
 - Water pump turns OFF when <u>ANY</u> below conditions is fufilled:
 - o Outdoor air temp zone is Free Zone
 - Outdoor air temp zone is any of Zones 1 to 4.
 - After water pump ON for 4 minutes, and water inlet temp. ≥ [B°C]
 - Else, shift to Heat pump unit operation anti freeze control.
 - However, if flow sensor is abnormal (H62), then water pump circulation anti freeze control will not activate.
- Heat pump unit operation anti freeze control
 - Heat pump unit operation turns ON when <u>ALL</u> below conditions are fufilled:
 - Water pump circulation anti freeze control activated and water pump ON for 4 minutes.
 - Heat pump unit operation turns OFF when <u>ANY</u> below conditions is fufilled:
 - Water inlet / Water inlet 2 temp. > [C°C] for 3 minutes.


	A°C	В°С	C°C
Zone 1	20°C	19°C	24°C
Zone 2	20°C	19°C	24°C
Zone 3	20°C	23°C	28°C
Zone 4	20°C	27°C	33°C

Table: Threshold condition for Water temp when Models without Back up heater

14.20.1 Zone Anti-Freeze Control

• If buffer tank selection is "NO" and Anti- Freeze function select "NO" from remote control, this control cannot activate.

Outdoor air temp zone is defined as below:



Start condition:

- After [5] min from previous Zone pump off. AND
- Outdoor air temp zone is any of Zones 1 to 4 OR outdoor ambient temp. sensor is abnormal. AND
- Zone water temperature < [A°C] **OR** Zone Sensor Short or Open

Cancel condition:

- After water Zone pump ON [4] min AND
- Outdoor air temp zone is Free Zone OR
- Outdoor air temp zone is any of Zones 1 to 4.
 Zone water temperature sensor ≥ [B°C]

*However, Zone water temperature sensor is Open or Short, cancel zone water temperature condition is ignored.

	A°C	В°С
Zone 1	6°C	8°C
Zone 2	10°C	15°C
Zone 3	16°C	21°C
Zone 4	25°C	33°C

Table: Threshold condition for Water temp when Models with Back up heater

	A°C	В°С
Zone 1	20°C	19°C
Zone 2	20°C	19°C
Zone 3	20°C	23°C
Zone 4	20°C	27°C

Table: Threshold condition for Water temp when Models without Back up heater


14.21 Solar Operation (Optional)

14.21.1 Solar Operation:

Solar function:

 This function allow user to control the solar pump to operate depend on the solar sensor reading compare to the tank installed. Solar pump will circulate the hot water energy store at solar panel to heat up the DHW Tank or Buffer Tank.

Solar Connection Diagram:



- Solar function can only enable when the Optional PCB is connected.
- Few part as below need to install to control the solar operation:
 - o Solar Panel
 - Solar Pump
 - Solar Panel Sensor
 - Tank Sensor (Buffer tank sensor OR DHW Tank sensor depend on the connection direction)
 - * During Solar Connection to the system, installer need to alert on the high water temperature may flow to the zone circuit or DHW piping circuit. Therefore pipe which withstand higher water temperature need to be installed.
- Solar remote control setting
 - 1 Solar Setting can only be set when the optional PCB connection is select "YES"
 - 2 By remote controller, Setting as below list can be set for solar function operation (Installer Menu)
 - Solar Function ("YES" or "NO")
 - o Tank Connection Direction ("DHW TANK" or "BUFFER TANK")
 - Delta T turns ON: Difference temperature setting between solar panel sensor and Tank to turn on solar pump. (Range :5 ~ 15°C)
 - Delta T turns OFF: Difference temperature setting between solar panel thermistor and Tank to turn off solar pump. (Range :2 ~ 10°C)
 - \circ Outdoor temp for Anti-Freeze : Outdoor temp to start Anti-Freeze control for solar circuit. (Range : -20 ~ 10°C)
 - Tank Temperature HI Limit Set (Range : 70 ~ 90°C)

14.21.2 Solar Operation Control

• Solar function can only be activate if the solar function selection "YES" from remote control. To achieve hot water from solar panel, indoor need to control the solar pump and circulate hot water from solar panel.

Under normal case:

- Solar pump start condition:
 - Solar panel temperature > Delta T turn on setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) AND
 - Tank temperature (DHW or Buffer) < Solar HI Limit Temp (R/C) AND
 - Operation ON with heat mode (apply to solar connect to "Buffer Tank" case)
 - * Condition c) ignore if the solar system is connect to DHW tank (control active under operation OFF time for Tank connection case)
- Solar pump stop condition:
 - Solar panel temperature < Delta T turn OFF setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) OR
 - Tank hot water temp >= Solar HI Limit Temp (R/C) + [2]°C

Under solar Anti-freeze protection control:

- Solar pump start condition:
 - Outdoor temp < Outdoor temp setting for Anti-Freeze (R/C)
- Solar pump stop condition:
 - Outdoor temp > Outdoor temp setting for Anti-Freeze + [2]°C

- Solar operation during error:
 - o During Tank sensor (DHW or Buffer depend on selection) abnormal, Solar operation will not able to function.
 - o During Solar Panel sensor detect OPEN (not include SHORT), Solar operation will not able to function too.

14.22 Boiler Bivalent Control

- Boiler is an additional or alternative heat source to heat up the room when necessary.
- Purpose of this control is to turn ON and turn OFF the Boiler output signal when boiler heating capacity needed in the system.
- Boiler is possible to connect to DHW Tank and Buffer Tank depends on the installer.
- Boiler operation parameter need to be set on Boiler itself, indoor do not control the boiler operation direction and operation.
- There are Alternative mode, Parallel mode, & Advance Parallel mode available to select by installer to fit to the total system.

Bivalent control selection by remote controller

■ Auto

Remote control setting value:

1 Outdoor Ambient Set = (Range: -15°C ~ 35°C)

Alternative Mode

o Only one heat source operates at one time, either heat pump or boiler depends on condition.

Control detail:

During Operation ON at Heat mode or Tank mode or Heat + Tank Mode

- Boiler signal turn ON and heat pump and water pump turn OFF when:
 - Outdoor ambient < Outdoor Ambient Set AND
 - Boiler prohibit flag = 0

^{**}However, During Cool mode this function cannot activate if Tank selection is "Buffer Tank".

^{**}Solar pump can operate even if Heat pump is under error stop.

^{**} However indoor water pump can operate when Anti-freeze control condition fulfilled.

Parallel Mode

 Parallel mode allows heat pump and boiler ON at the same time. Boiler operates as an additional heating capacity when low heat pump capacity at low ambient condition.

Control detail:

During operation ON at Heat mode or Tank mode or Heat + Tank mode

- Boiler signal turns ON when:
 - Outdoor ambient < Outdoor Ambient Set AND
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when:
 - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
 - Boiler prohibit flag = 1

Advance Parallel Mode

 Advance parallel mode allow heat pump to operate and turn ON boiler only when ambient and temperature condition is fulfilled.

Remote control setting value:

- 1 Outdoor Ambient Set = (Range : -15°C ~ 15°C)
- 2 Selection of boiler connection direction. (Heat only, DHW only, Heat & DHW)
- 3 Setting data under Heat Direction
 - Start Temperature | START_TEMP |
 Start Delay Timer | START_TIMER |
 Stop Temperature | STOP_TEMP |
 Stop Delay Timer | STOP TIMER |
- 4 Setting data under DHW Direction
 - Delay Timer | DELAY_TIMER |

Control detail:

During operation ON at Heat Mode

- Boiler signal turns ON when
 - Outdoor ambient < Outdoor Ambient Set AND
 - Buffer tank temperature < Target Buffer Tank Temperature + [START_TEMP] for [START_TIMER]
 AND
 - Heat pump operate at room side AND
 - Connection of Boiler to Heating Select "YES" From installer menu AND
 - Buffer Tank connection select "YES" AND
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when
 - Outdoor ambient > Outdoor Ambient Set + [-2°C] OR
 - Buffer Tank temperature > Target Buffer Tank temperature + [STOP TEMP] for [STOP TIMER] OR
 - Heat pump not at room side. OR
 - Boiler prohibit flag = 1

During operation ON at Tank Mode

- Boiler signal turns ON when
 - Outdoor ambient < Outdoor Ambient Set AND
 - Heat pump operate at tank side for continuous | DELAY TIMER | AND
 - Connection of Boiler to DWH Tank select "YES" from installer menu. AND
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when
 - Outdoor ambient > Outdoor Ambient Set + [2°C] OR
 - Heat pump not operates at tank side. OR
 - Boiler prohibit flag = 1

■ SG readv

SG ready (Only available to set when optional PCB set to YES)

- SG Ready input from optional PCB terminal control ON/OFF of boiler and heat pump as below condition

SG signal		Operation pattern
Vcc-bit1	Vcc-bit2	
Open	Open	Heat pump OFF, Boiler OFF
Short	Open	Heat pump ON, Boiler OFF
Open	Short	Heat pump OFF, Boiler ON
Short	Short	Heat pump ON, Boiler ON

^{*} This bivalent SG ready input is sharing same terminal as [16. SG ready] connection. Only one of these two setting can be set at the same time.

When one is set, another setting will reset to not set.

Smart


There are Energy price (both electricity and boiler) and Schedule to be set on remote controller.

Operation setting of Energy price and Schedule shall be responsible by installer.

Based on these settings, system will calculate the final price for both electricity and boiler.

When final price of Electricity is lower than Boiler's, heat pump will operate.

When final price of Electricity is higher than Boiler's, boiler will operate.



Boiler prohibit flag control

Purpose:

o For product safety. Boiler signal is OFF when water temperature is too high.

Start condition:

- Water outlet ≥ 85°C continues for 5 minutes.
- o Water inlet ≥ 85°C continues for 5 minutes.
- o Zone1 water temp ≥ 75°C continues for 5 minutes.
- Zone2 water temp ≥ 75°C continues for 5 minutes.

Contents:

After start condition fulfilled, set boiler prohibit flag = 1

Cancel condition:

o After 30 minutes from start condition fulfilled.

Contents:

Set boiler prohibit flag = 0

14.23 External Room Thermostat Control (Optional)

Purpose:


Better room temperature control to fulfill different temperature request by external room thermostat. Recommended external room thermostat:

Maker	Characteristic
Siemen (REV200)	Touch panel
Siemen (RAA20)	Analog

Connection of external room thermostat:

Wire Connection and thermo characteristic of Siemen REV200:


Setting	L/L1 (H)	Heat Thermo	L/L2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



heating and cooling line for heat + cool model. And connect both

Wire Connection and thermo characteristic of Siemen RAA20:

Setting	L/Y1 (H)	Heat Thermo	L/Y2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



Connect only heating line for heating only model. And connect both heating and cooling line for heat + cool model.

Control Content:

- External room thermostat control activate only when remote thermostat connection select YES by Indoor control
 panel.
- When indoor running heat mode, refer thermo On/Off from heating line feedback. And when indoor running cool
 mode, refer thermo On/Off from cooling line feedback.
- Heat pump Off immediately when receive thermo off feedback.


14.24 Three Ways Valve Control

Purpose:

- 3 ways valve is used to change flow direction of hot water from heat pump between heating side and tank side.

Control contents:

- 1 3 ways valve switch Off:
 - During 3 ways valve switch Off time, the hot water will provide heat capacity to heating side.
- 2 3 ways valve switch On:
 - o During 3 ways valve switch On time, the hot water will provide heat capacity to tank side.
- 3 Stop condition:
 - During stop mode, 3 ways valve will be in switch off position.



- * During pump down and force mode, fix 3 ways valve in close condition.
- * Recommended Parts: SFA 21/18 (Siemens)


14.25 Two Ways Valve Control

Functionality of 2 ways valve:

Use to allow hot water to floor heating panel or block cold water to floor heating panel.

Control contents:

- 1 When indoor running in heat mode, OPEN the 2 ways valve.
- 2 When indoor running in cool mode, CLOSE the 2 ways valve.
- 3 Stop condition:
 - a. During stop mode, fix 2 ways valve in close condition.



- * During pump down mode, fix 2 ways valve in close condition.
- * During force mode, open 2 ways valve.
- * Recommended Parts : SFA 21/18 (Siemens)

14.26 Anti-Stick Mode Operation

This mode is a control to prevent the water circuit actuator from locking up if not used for an extended period of time.

Start conditions

- 1) A.M 3:00 o'clock every Monday.
- 2) Anti-stick mode = Enable. (Anti-stick mode is selected in custom menu)

Control Contents:

It works in the following order.

- 1) If any mode operated, all operation is stopped.
- 2) Anti-stick mode operates
- 3) If Anti-stick mode finished, back to the last operation.


Cancel conditions:

Which of the following holds

- 1) Anti-stick mode is finished.
- When the customer manually starts any mode operation. (include weekly timer, sterilization mode)


Anti-stick mode

If zone 2 or pool or solar are not connected, they are skipped



14.27 External OFF/ON Control


• Communication circuit between indoor unit and external controller is as per below.



- Maximum length of communication cable is 50 meter.
- Control content:

External Control Switch	Control Panel OFF/ON	Control Panel Power LED	System Status
ON	ON	ON	ON
ON	OFF	OFF	OFF
OFF	ON	ON	OFF
OFF	OFF	OFF	OFF

Remocon Screen Display and Control Detail:



When External SW connection select "YES" from remocon installer menu:

- Heating or Cooling system will operate normally if the External Switch signal is ON.
- Once the External Switch turn OFF, System Turn OFF (Heat pump, water pump, heater etc...)
- Remocon LED remain ON or OFF according to the current operation request.
- Pop up menu at remocon main screen as above screen to inform customer system stop by External Switch.
- It is possible to press cancel and return to main screen to do change of operation setting while waiting the External Switch turn ON back.
- Remocon LED will always follow the latest changes from remocon.
- If no action on remocon for continuous 5 minutes, the pop up screen will show again on the screen.
- But once the External Switch Turn ON back, pop up screen will disappear and system can operate normally
 according to the latest operation setting and request.

14.28 External Compressor Switch (Optional PCB)

External compressor switch port can have two purpose of control as below:

- Heat source ON/OFF function (Dip switch Pin 3 on PCB "OFF")
- Heater ON/OFF function (Dip switch Pin 3 on PCB "ON")
- Heat source ON/OFF function

Purpose:

 Heat pump ON/OFF function is use to turn OFF the high power consumption device (Heat pump, & Heater) when there is energy or electric current limitation. Other optional function still can be operate under heat pump and heater OFF condition.

Control Detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "OFF"
 This heat pump ON/OFF function will activate
- The ON/OFF signal of this External Compressor Switch is same as External Switch.
- When the External Compressor Switch is ON:
 - Heat pump system operate normally
- When the External Compressor Switch is OFF:
 - o Heat pump, Indoor water pump & Heater (Booster heater & Backup Heater) need to turn OFF
 - o Solar, Boiler and zone control can be operate follow normal control condition.
 - * pump delay OFF also included in this control

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

Heater ON/OFF function

Purpose:

Heater ON/OFF function is use to turn OFF the heater (backup heater & booster heater) when there is energy or
electric current limitation. Heat pump and other optional function still can operate.

Control detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & Dip Switch on PCB "ON" This heater ON/OFF function will activate
- When the External Compressor Switch is ON:
 - Heat pump and heater operate normally
- When the External Compressor Switch is OFF:
 - o Backup heater and booster heater cannot operate even heater request is ON.
 - Heat pump and option function (Solar, Boiler and zone control) can be operate follow normal control condition.

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

14.29 Heat/Cool Switch (Optional PCB)

Purpose:

• User can switch the running mode from heat to cool or cool to heat through external installed Heat/Cool switch. This kind of heat / cool switch may built in inside the field supply room remocon as well.

Control contents:

- Heat/Cool Switch can only be set when Cool Function is "enable" at custom menu setting, & Extension PCB select "YES" & Zone 1 not set "Pool" condition.
- This heat/cool switch control will be activate only when installer set the Heat/Cool Switch "USE" through remocon.
 - Once the Heat/Cool Switch Set "USE", remocon will check indoor send Signal to judge the option of mode select.
 - When Heat/Cool Switch Contact Open : Remocon only can select Heat Mode, or Heat + Tank Mode, or Tank Mode
 - When Heat/Cool Switch Contact Close: Remocon only can select Cool Mode, or Cool + Tank Mode, or Tank Mode


- Operation ON/OFF will depend on remocon request.
- When Heat Mode is running with Contact Open, user change this setting to contact close, indoor will this signal to remocon judge and change mode to cool and send back to indoor. And it is same as from cool mode change to heat mode.
 - * This switch have higher priority, remocon follow indoor send signal when control activated.
 - * There is no effect to the operation when the mode running is only Tank Mode.

(Weekly Timer are ignored and cannot be set during Heat / Cool Switch is "Enable" Condition.)

14.30 SG Ready Control (Optional PCB)

Purpose:

To set ON/OFF of heat pump and target temperature by digital input of third party device if necessary in field.



Remote control setting

For this function, following items need to be set on R/C (installer menu) –

- SG control = YES or NO
- Capacity up setting 1
 - Heating capacity [50 ~ 150 %]
 - DHW capacity [50 ~ 150 %]
 - Cooling capacity [-15 ~ 0 °C]
- Capacity up setting 2
 - Heating capacity [50 ~ 150 %]
 - DHW capacity [50 ~ 150 %]
 - Cooling capacity [-15 ~ 0 °C]
- HPU stop consumption [0.5 ~ 10.0 kW]
- Power consumption setting 1
 - Heating Power consumption [0.5 ~ 10.0 kW]
 - DHW Power consumption [0.5 ~ 10.0 kW]
 - Cooling Power consumption [0.5 ~ 10.0 kW]
- Power consumption setting 2
 - Heating Power consumption [0.5 ~ 10.0 kW]
 - DHW Power consumption [0.5 ~ 10.0 kW]
 - Cooling Power consumption [0.5 ~ 10.0 kW]

Control contents:

If SG control on remote control = "Yes", then following control only activate by digital input.

- While Digital input is "00" (Normal operation)
 - Normal operation. Once detect '00' system will operate back to normal condition.
 (All the target set temperature for heating side and DHW side will return back to previous set temperature when digital signal change from "10" or "11" back to "00".)
- While digital input is detected "01" (HP stop)
 - Heat pump & room heater & tank heater cannot operate.
 (Solar control and Boiler back up and 2 Zone control can activate.)

• While digital input is detected "10" (Capacity 1)

- Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.
- Target temperature of cooling is change according to the adjustment value set by remocon setting.

While digital input is detected "11" (Capacity 2)

- Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.
- o Target temperature of cooling is change according to the adjustment value set by remocon setting.

While digital input is detected " 10 " (Capacity 1)

Setting temperature for heating and Tank is changed.
 However, which setting temperature is change depend on system setting.

If Buffer selection is "YES"

Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature * Remote Control setting (" capacity 1) %

* Max Min regulation is follow Target Buffer tank temperature control specification

** No change of Target zone water temperature, only set higher buffer tank temperature.

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 1) % * (Max regulation depend on the tank max setting limit)

If Buffer selection is "NO"

Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature * Remote Control Setting (*Capacity 1) %

(Zone 1 and Zone 2 will change according to its own target zone water temperature.)

(Max regulation depend on the temperature control type select)

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 1) % * (Max regulation depends on the tank max setting limit)

Setting temperature for cooling is changed

New Target water temperature = target water temperature + R/C setting for cool (*Capacity 1)

* (Min/max regulation of cooling water set apply)

While digital input is detected "11" (Capacity 2)

Setting temperature for heating and Tank is changed.
 However, which setting temperature is change depend on system setting.

If Buffer selection is "YES"

Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature * Remote Control setting (" capacity 2) %

* Max Min regulation is follow Target Buffer tank temperature control specification

** No change of Target zone water temperature, only set higher buffer tank temperature.

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 2) % * (Max regulation depends on the tank max setting limit)

If Buffer selection is "NO"

Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature * Remote Control Setting (*Capacity 2) %

(Zone 1 and Zone 2 will change according to it's own target zone water temperature.)

(Max regulation depend on the temperature control type select)

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 2) %

* (Max regulation depends on the tank max setting limit)

** This function is not applicable for Cooling mode.

Setting temperature for cooling is changed

New Target water temperature = target water temperature + R/C setting for cool (*Capacity 2)

* (Min/max regulation of cooling water set apply)

HPU stop consumption

Operation will stop when the power consumption of the entire system exceeds (HPU stop consumption kW).

While digital input is detected "10" (Power consumption 1)

Room side

Operate with the target of reducing power consumption to (Heating Power consumption 1) or less.

DHW Tank side

Operate with the target of reducing power consumption to (DHW Power consumption 1) or less.

Cool mode

Operate with the target of reducing power consumption to (Cooling Power consumption 1) or less.

• While digital input is detected "11" (Power consumption 2)

Room side

Operate with the target of reducing power consumption to (Heating Power consumption 2) or less.

DHW Tank side

Operate with the target of reducing power consumption to (DHW Power consumption 2) or less.

Cool mode

Operate with the target of reducing power consumption to (Cooling Power consumption 2) or less.

14.31 Demand Control (Optional PCB)

Remote control setting:

When Optional PCB connection select "YES", Demand Control function can select "YES" or "NO".

Purpose:

- After the demand control select YES, below control will activated.
 - o 0-10V Demand control

0-10V Demand control

Demand control is use to reduce the current usage of heat pump unit by third party device.

Control start condition:

- Select "YES" at Demand control at installer menu.
- 0-10V input for this electrical current control is detected.

Control content:

- If start condition is fulfilled, indoor will receive the voltage signal from optional PCB. Indoor will send the rate value to outdoor unit.
- Outdoor will change the current limit according to the percentage receive from indoor unit.

14.32 Holiday Mode

Purpose:

Promotes energy saving by allowing the user to stop the system during holiday and enables the system to resume at the preset temperature after holiday.

Control details:

- Indoor operate the unit according running mode request. Target temperature will follow holiday setting temperature.
 - If heat mode request is receive, Target Water Out Temperature will change according to holiday shift temperature set.
 - [If heat is set OFF at holiday, unit, water pump and zone control will OFF]
 - If tank mode request is receive, Target Tank Set Temperature will change according to the holiday tank shift temperature set.
 - [If tank is set OFF at holiday, heat pump and tank heater will OFF]
- After days of holiday have been set, heat pump will stop and only resume operation at the end of holiday countdown.

Start condition:

- o Holiday timer set and the holiday timer start
 - * The day holiday mode was set is counted as day 1.

Stop condition:

- o OFF/ON button is pressed.
- Holiday timer is reached.

14.33 Dry Concrete

Purpose

Provide heat to floor heating panel and dry the wet concrete during installation.

Setting condition:

- Dry concrete parameter can be set through remote control under system setup.
- Parameters are possible to set up to 99 days with different target set temperature

Control details:

- Dry concrete mode will be activates when select ON from service setup.
- Once start dry concrete function, remote control will send step 1 setting temperature to indoor unit.
 - * This temperature is set at zone temperature. If system is 2 zones, both zone target temperature is set as same temperature.
- Heat pump will start heat mode operation to room side with received target water outlet temperature.
 - * Heat pump will operate according to Heat pump Target Water Temperature.
- After complete day 1 setup operation, day 2 data will be send to indoor at 12.00am on the second day.
- Each preset data will be send every day until dry concrete mode is complete, unit will turns OFF and exit dry concrete function.
- o 3 ways valve and booster heater will turn OFF and 2 ways valve will turns ON.

Cancel condition:

- o Dry concrete mode is complete and OFF signal is received.
- OFF signal is received by pressing OFF/ON button.

14.34 Flow Sensor

- The water flow sensor serves as an overload protector that shuts down the unit when the water level is detected to be low.
- Abnormal flow detection:

Sequence	Abnormal flow	Normal flow
Normal case	Flow rate < 8 l/min or ≧ 69 l/min	≧ 8 l/min
During status 2~6 on Anti-freeze deice	≧8 l/min	< 8 l/min

15. Protection Control

15.1 Protection Control for All Operations

15.1.1 Time Delay Safety Control

1 The compressor will not start for three minutes after stop of operation.

15.1.2 Total Running Current Control

- 1 When the outdoor running current exceeds X value, the compressor frequency will decrease.
- 2 If the outdoor running current does not exceed X value, the compressor frequency will return to normal operating frequency.
- If the outdoor running current continue to increase till exceed Y value, compressor will stop, and if this occurs 3 times within 20 minutes, system will stop operation and OFF/ON control panel LED will blink (F16 error occurs).


	WH-WXG09ME5		WH-WX	G12ME5
Operation Mode	X (A)	Y (A)	X (A)	Y (A)
Heating	28.0	31.0	28.0	31.0
Cooling	20.0	31.0	20.0	31.0

A. DC Peak Current Control

- 1 When the current to IPM exceeds set value of 60.5 A, compressor will stop. Compressor will restart after one minutes.
- 2 If the set value exceeds again for more than 30 seconds after the compressor restarts, operation will restart after two minutes.
- If the set value exceeds again for within 30 seconds after the compressor restarts, operation will restart after one minute. If this condition repeats continuously for seven times, system will stop operation and OFF/ON control panel LED will blink (F23 error occurs).

15.1.3 Compressor Overheating Prevention Control

 The compressor operating frequency is regulated in accordance to discharge temperature as shown in below figures. When the discharge temperature exceeds 107°C, compressor will stop, and if this occurs 4 times within 30 minutes, system will stop operation and OFF/ON control panel LED will blink (F20 error occurs).




15.1.4 High Pressure Sensor Control


- Purpose:
 - To protect the system operation.
- Detection period:
 - After compressor on for 1 minute.
- Detection conditions:
 - When abnormal high voltage detection, 5 V or when open circuit detection 0V for 5 seconds continuously.
- After detection:
 - When abnormality is detected 4 times within 120 minutes, unit stop operation.
 - OFF/ON control panel LED will blink (H64 error occurs).

15.1.5 Outside Temperature Current Control

Heating



Cooling



15.1.6 Pre-Heat Control

- Purpose:
 - For compressor protection during low outdoor ambient operation (during heating low temperature operation).
- · Control content:
 - a. Trigger Pre-Heat Control condition
 - When the outdoor air temperature is below than -10°C, and discharge temperature is -10°C or below.
 - b. Resetting Pre-Heat Control condition
 - 1. When the outdoor air temperature exceeds entry condition (-7°C)
 - 2. When the discharge temperature exceeds entry condition (-7°C)

15.2 Protection Control for Heating Operation

15.2.1 Outdoor Air Temperature Control


The maximum current value is regulated when the outdoor air temperature rises above 14°C in order to avoid compressor overloading.

15.2.2 Deice Operation

When outdoor pipe temperature and outdoor air temperature is low, deice operation start where outdoor fan motor stop.

• Deice judging condition

Outdoor Unit Deice Control




Deice start depends:

- 1. Outdoor air sensor temp.
- 2. Outdoor pipe sensor temp.
- 3. Heating accumulation time

• Deice mode selection condition

 There are 2 deice modes, according to water inlet temperature and outdoor ambient temperature the deice mode is decided.




Judgement details:


- 1 When water inlet temperature is more than 74°C, unit will operate deice mode 1.
- 2 When water inlet temperature is less than 19°C, unit will operate deice mode 2.
- When water inlet temperature is less than 74°C and outdoor ambient temperature is less than -10°C, unit will operate deice mode 2.
- 4 When water outlet temperature sensor 2 detect temperature is less than 14°C, unit will operate deice mode 2.

• Deice operation time diagram

a. Deice mode 1 control:



b. Deice mode 2 control:



15.2.2.1 Ice Choke Detection Control

This control is only available on models equipped with [Deice mode 2].

Purpose

Ice choke detection and forced defrosting to melt the ice are performed to prevent abnormal rises in discharge port temperature.

Control Content

1. During heating operation (excluding deice control)

Start Conditions

- 1 During heating operation (excluding deice mode 2 control)
- 2 Outdoor temperature < 10°C
- 3 Compressor is ON
- 4 After Compressor starting control ends
- 5 High-pressure saturation temperature Indoor piping temperature >= 40°C
- 6 EVA outlet temperature Outdoor piping temperature >= 35°C
- 7 Outdoor piping temperature < -35°C
- 8 Outdoor temperature EVA outlet temperature < -4°C

If all the above start conditions 1 to 7 are met continuously for 30 seconds, or if all the above start conditions 1 to 5 and 8 are met continuously for 30 seconds, deice mode 2 control will be executed.

If the conditions are no longer met during the timer 30 seconds, the timer of 30 seconds count will be reset.

2. During normal deice (excluding antifreezing deice control)

Start Conditions


- 1 During normal deice (including 0Hz instruction sequence)
- 2 Outdoor temperature < 10°C
- 3 High-pressure saturation temperature Indoor piping temperature >= 20°C
- 4 Indoor piping temperature < -25°C

If all the above start conditions 1 to 4 are met continuously for 30 seconds, forced antifreezing deice control will be executed.

15.3 Protection Control for Cooling Operation

15.3.1 Outdoor Air Temperature Control

- The Compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust base on outdoor air temperature.



15.3.2 Freeze Prevention Control 1


- 1 When refrigerant temperature is lower than 0°C continuously for 10 seconds, compressor will stop operating.
- 2 Compressor will resume its operation three minutes after the refrigerant heat exchanger is higher than 2°C.
- 3 Heat exchanger freeze prevention (H99) will memory in error history.

16. Servicing Mode

16.1 Open the Front Cover

Before opening the front cover ① (ID) of the Indoor Unit, always switch off all power supplies (e.g. the Indoor Unit power supply, the outdoor unit power supply, and the heater power supply).

- 1. Remove the 2 mounting screws located at the top of the enclosure (2) (ID).
- 2. Gently pull the upper section of the front cover ① (ID) towards you. (The front cover will stops once it has opened about 2 degrees.)
- 3. Gently rotate the front cover (1) (ID) to open 180 degrees.



16.2 Test Run

- 1. Check the items below before the test run.
 - a) Pipework are properly done.
 - b) Electric cable connecting work are properly done.
 - c) Water circuit unit is filled up with water and trapped air is released.
 - d) Turn ON the power supply after filling the indoor until full.
- Turn ON the power supply for the Indoor, and RCCB/ELCB in the Indoor Unit. Then, refer to the Operation Instruction for operation of Remote Controller (3) (ID).

Note:

During winter, turn ON the power supply and standby the unit for at least 15 minutes before test run. To allow sufficient time to warm up refrigerant and prevent wrong error code judgement.

- 3. For normal operation, the water pressure reading should be in between 0.50 bar and 4.00 bar (0.05 MPa and 0.4 MPa). If not, adjust the speed of the water pump to bring it into the aforementioned pressure operating range. If this procedure does not solve the problem, contact a local authorized dealer.
- 4. After test run, clean the Magnet Water Filter (8) (OD) with reference to "Maintenance for magnetic water filter" in the Installation Manual of the AIR-TO-WATER HEAT PUMP OUTDOOR UNIT and reinstall it. After the cleaning is finished.

16.2.1 Check Water Flow of the Water Circuit

Select Installer setup \rightarrow Service setup \rightarrow Pump maximum speed \rightarrow Air purge.


Confirm that the maximum water flow rate is not less than 25 I/min when the main pump is in operation.

- * Water flow can be checked in Service setup (Pump maximum speed)
 [Heating operation at low water temperature with lower flow rate may cause "H75" during defrost process.]
- * If there is no water flow or H62 is displayed, stop pump operation and release the air (See "Check Air Accumulation").

16.3 Expansion Vessel Pre Pressure Checking

- The system where the Indoor Unit is installed is equipped with an expansion vessel with the capacity of 10 L and the initial pressure of 1 bar.
- The total volume of water in the system should not exceed 200 L.
- If the total water volume exceeds 200 L, add an expansion vessel. (Supplied on site)
- The installed height difference of the water circuit of the system should not exceed 30 m. (Extra pump may be required).
 - * In case of 30 m, set the pressure in the circulation circuit to 0.5~1.0 bar. Higher than 1.0 bar may cause water leakage due to component breakage.

16.4 How to Unlock Cool Mode




16.5 EEPROM Factory Default Data Setup Procedure



- EEPROM default data setup is only possible during initialization process.
- Press (▲ , ▼ , ◀ , ▶) simultaneously for 5secs continuously, initialization process will stop & EEPROM default data setup process will start.


During EEPROM default data setup process, display should be as shown below.




- Once EEPROM default data setup process is complete, initialization process will re-start from beginning.



16.6 Dry Concrete Setup






17. Maintenance Guide


To ensure the safety and optimum performance of the indoor unit, seasonal inspections of the indoor unit and functional checks of RCCB/ELCB, field wiring and pipe should be carried out on a regular basis. This maintenance and scheduled inspection should be carried out by authorized dealer.

Regular maintenance of the expansion vessel (at least once a year) is recommended and should be performed by authorized dealer. First, make sure that the expansion or pressure tank is completely drained of water, that the system is switched off, and that there are no live electrical components. If you need to reset the preload pressure, set 1bar.

1. Check Water Pressure * (0.50 bar = 0.05 MPa)
Water pressure must not be lower than 0.50 bar. (Check the water pressure by the remote controller.) If it is lower, fill Space Heating/Cooling pipes with water through the tube connector on the outdoor unit.



- 2. Check Pressure Relief Valve
 - *Pressure Relief Valve is mounted in the Outdoor Unit.
 - o Confirm that the pressure relief valve is working properly. Pull the lever horizontal direction.
 - Release the lever when water comes out of the drain pipe of the pressure relief valve.
 (While the air continues to come out of the drain pipe, keep raising the lever to completely discharge the air.)
 - o Confirm that the water from the drain pipe stops.
 - o If water is leaking, pull the lever several times and return it to make sure the water stops.
 - o If water keeps coming out of the drain, drain water.
 - Turn off the system and contact your local authorized dealer.



3. Check Air Accumulation

• Open the air vent plugs on the heating panel, fan convector, etc., and remove the air accumulated in the equipment and piping.

4. Check RCCB/ELCB

- a. Ensure the RCCB/ELCB set to "ON" condition before check RCCB/ELCB.
- b. Turn ON the power supply to the Indoor Unit.


This check can only be done when power is supplied to the Indoor Unit.

⚠ WARNING

Be careful not to touch parts other than RCCB/ELCB test button when the power is supplied to Indoor Unit. Otherwise, electrical shock may be caused. Before obtaining access to terminals, all supply circuits must be disconnected.

- c. Push the "TEST" button on the RCCB/ELCB. The lever would turn down, if it works properly.
- d. Contact authorized dealer if the RCCB/ELCB malfunction.
- e. Turn OFF the power supply to the Indoor Unit.
- f. If RCCB/ELCB functions normal, set the lever to "ON" again.

- 5. Maintenance for Magnet Water Filter (8) (OD)
 - a. Turn OFF the power supply.
 - b. Place a container below Magnet Water Filter (8) (OD).
 - c. Turn to remove the Magnet Bar at bottom of Magnet Water Filter (8) (OD).
 - d. Remove the Cap of Discharge Port with Allen key (8mm).
 - e. Open the Service Valve with Allen key (4mm) to release the dirty water from the Discharge Port into a container. Close the service valve when the container is full to avoid spillage in the outdoor unit. Dispose the dirty water.
 - f. Reinstall the Cap of Discharge Port and Magnet Bar.
 - g. Re-charge the water to Space Heating / Cooling circuit if necessary.
 - h. Turn ON the power supply.



17.1 Service and Maintenance

If forget Password and cannot operate remote controller


+ + + > Press for 5 seconds.

Password unlock screen appears, press Confirm and it shall reset.


Password will become 0000. Please reset it again.

Note: This is displayed only when the remote controller is password-locked.

17.1.1 Maintenance Menu



17.1.2 Custom Menu



Parts and other components that may not operate if Disable is selected may stick if not operated for a long period of time.

17.2 Specifications

17.2.1 Specifications of Fresh Water was Heat Transfer Medium in Brazed Heat Exchanger

Parameter	Quality Limits for Tap Water on the Secondary Side
Temperature	Below 75°C
рН	7 to 9
Alkalinity	60mg/I <hco₃ <300mg="" i<="" td=""></hco₃>
Conductivity	<750 or 1250
Hardness	[Ca ⁺ , Mg ⁺] / [HCO ₃ ⁻] > 0.5
Chloride	< 200mg/l at 60°C
Sulphate	[SO ₄ ²⁻] < 100mg/I and [HCO ₃ ⁻] / [SO ₄ ²⁻] > 1
Nitrate	NO ₃ < 100mg/I
Chlorine	< 0.5mg/l

17.2.2 External Filter

Solids in the water must be filtered.


Minimum filter mesh size required for the field supply external filter in the water inlet is 20 mesh.

18. Troubleshooting Guide

18.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle.

Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan.



18.2 Relationship Between the Condition of the Air-to-Water Heatpump Indoor and Outdoor Units and Electric Current

Condition of the Air-to-Water Heatpump	Heating Mode	Cooling Mode	
indoor and outdoor units	Electric current during operation	Electric current during operation	
Water leakage or insufficient water flow rate in the system		1	
Excessive amount of refrigerant			
Inefficient compression	-	-	
Insufficient refrigerant (gas leakage)	-	-	
Outdoor heat exchange deficiency	-		
Clogged expansion valve or Strainer			

Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

18.3 Breakdown Self Diagnosis Function


18.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- When abnormality occur during operation, the system will stop operation, and OFF/ON control panel LED will blink and error code will display on the control panel.
- Even error code is reset by turning OFF power supply or by selecting ERROR RESET, if the system abnormality
 is still unrepaired, system will again stop operation, and OFF/ON control panel LED will again blinks and error
 code will be display.
- The error code will store in IC memory.

To check the error code

- 1 When an abnormality occurs, system will stop operation and OFF/ON control panel LED will blink.
- 2 Error code of the abnormality will be display on the control panel.
- 3 To determine the abnormality description, the error code table needs to be referred.

eg:




Press < > to select Close / Reset then press <

To display past/last error code

- 1 Turn ON power supply.
- 2 Refer below procedure to retrieve the error code history.

To permanently delete error code from IC memory

- 1 Turn ON power supply.
- 2 Refer below procedure to clear error history.



4. --

[+-] Clear history

18.4 Error Codes Table

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
H00	No abnormality detected	_	_
H12	Indoor/Outdoor capacity unmatched	10s after power supply	Indoor/outdoor connection wire Indoor/outdoor PCB Specification and combination table in catalogue
*H15	Outdoor compressor temperature sensor abnormality	Continue for 5 sec.	Compressor temperature sensor (defective or disconnected)
*H17	Zone 2 water pump abnormality	Continue for 10 sec.	Indoor PCB (main)Water pump (malfunction)
H20	Water pump abnormality	Continue for 10 sec.	Outdoor PCB (main), Outdoor PCB (sub) Water pump (malfunction)
H21	Abnormal water pressure	Continue for 300 sec.	Water pressure sensor
*H22	Abnormal tank 2 sensor	Continue for 5 sec.	Tank 2 sensor
H23	Refrigerant liquid temperature sensor abnormality	Continue for 5 sec.	Refrigerant liquid temperature sensor (defective or disconnected)
*H27	Service valve error	Continue for 5 minutes	High pressure sensor (defective or disconnected)
H28	Abnormal solar sensor	Continue for 5 sec.	Solar temperature sensor (defective or disconnected)
H31	Abnormal swimming pool sensor	Continue for 5 sec.	Pool temperature sensor (defective or disconnected)
H36	Abnormal buffer tank sensor	Continue for 5 sec.	Buffer tank sensor (defective or disconnected)
H38	Brand code not match	When indoor and outdoor brand code not same	_
H42	Compressor low pressure abnormality	_	 Outdoor pipe temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB (main) Compressor
H43	Abnormal Zone 1 sensor	Continue for 5 sec.	Water temperature Zone 1 sensor
H44	Abnormal Zone 2 sensor	Continue for 5 sec.	Water temperature Zone 2 sensor
H62	Water flow switch abnormality	Continue for 140 sec.	Water flow switch
H64	Refrigerant high pressure abnormality	4 times in 120 minutes	Outdoor high pressure sensor (defective or disconnected)
H65	Abnormal deice water circulation	Water flow > 8 l/min continuously for 10 seconds during anti freeze deice	Water pump
H67	Abnormal External Thermistor 1	Continue for 5 sec.	Room temperature Zone 1 sensor
H68	Abnormal External Thermistor 2	Continue for 5 sec.	Room temperature Zone 2 sensor
H70	External heater OLP abnormality	Continue for 60 sec.	External heater OLP (Disconnection or activated)
H72	Abnormal tank 1 sensor	Continue for 5 sec.	Tank 1 sensor
H74	PCB communication error	Communication or transfer error	Indoor main PCB and Sub PCB
H75	Low water temperature control	Room heater disable and deice request to operate under low water temperature	Heater operation must enable to increase water temperature
H76	Communication error (RC-1 & Indoor or RC-1 & RC-2)	_	Indoor - control panel (defective or disconnected) control panel 1 - control panel 2 (defective or disconnected)
H90	Indoor/outdoor abnormal communication	> 15 sec after starting operation	Internal/external cable connections Indoor/Outdoor PCB

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
H91	Tank heater OLP abnormality	Continue for 60 sec.	Tank heater OLP (Disconnection or activated)
H95	Indoor/Outdoor wrong connection	_	Indoor/Outdoor supply voltage
H98 / F95	Outdoor high pressure overload protection Cooling high pressure overload protection	_	Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB (main)
H99	Indoor heat exchanger freeze prevention	_	Water heat exchangerRefrigerant shortage
F12	Pressure switch activate	4 times occurrence within 30 minutes	Pressure switch
F14	Outdoor compressor abnormal revolution	4 times occurrence within 20 minutes	Outdoor compressor
F15	Outdoor fan motor lock abnormality	2 times occurrence within 20 minutes	Outdoor PCB (main)Outdoor fan motor
F16	Total running current protection	3 times occurrence within 20 minutes	Excess refrigerant Outdoor PCB
F20	Outdoor compressor overheating protection	4 times occurrence within 30 minutes	Compressor tank temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB (main) Compressor
F22	IPM (power transistor) overheating protection	3 times occurrence within 30 minutes	Improper heat exchangeIPM (Power transistor)
F23	Outdoor Direct Current (DC) peak detection	7 times occurrence continuously	Outdoor PCB (main) Compressor
F24	Refrigeration cycle abnormality	2 times occurrence within 30 minutes	Insufficient refrigerantOutdoor PCB (main)Compressor low compression
F25	Cooling/Heating cycle changeover abnormality	4 times occurrence within 30 minutes	4-way valve V-coil
F27	Pressure switch abnormality	Continue for 1 min.	Pressure switch
F30	Water outlet sensor 2 abnormality	Continue for 5 sec.	Water outlet sensor 2 (defective or disconnected)
F32	Internal thermostat error (RC-1 or RC-2)	Continue for 5 sec.	Control panel PCB thermostat
F35 (No Self-diagnosis Method)	External meter communication error	Continue for 180 sec.	External meter
F36	Outdoor air temperature sensor abnormality	Continue for 5 sec.	Outdoor air temperature sensor (defective or disconnected)
*F37	Indoor water inlet temperature sensor abnormality	Continue for 5 sec.	Water inlet temperature sensor (defective or disconnected)
F40	Outdoor discharge pipe temperature sensor abnormality	Continue for 5 sec.	Outdoor discharge pipe temperature sensor (defective or disconnected)
F41	PFC control	4 times occurrence within 10 minutes	Voltage at PFC
F42	Outdoor heat exchanger temperature sensor abnormality	Continue for 5 sec.	Outdoor heat exchanger temperature sensor (defective or disconnected)
*F43	Outdoor defrost sensor abnormality	Continue for 5 sec.	Outdoor defrost sensor (defective or disconnected)
F45	Indoor water outlet temperature sensor abnormality	Continue for 5 sec.	Water outlet temperature sensor (defective or disconnected)
*F46	Outdoor Current Transformer open circuit	_	Insufficient refrigerant Outdoor PCB (main) Compressor low
F48	Outdoor EVA outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor EVA outlet temperature sensor (defective or disconnected)
F49	Outdoor bypass outlet temperature sensor abnormality	Continue for 5 sec.	Outdoor bypass outlet temperature sensor (defective or disconnected)
F50	Water inlet 2 sensor error	Continue for 5 sec.	Water inlet 2 sensor

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
F51	Economizer outlet sensor abnormality	Continue for 5 sec.	Economizer outlet sensor (defective or disconnected)
F52	Bypass inlet sensor abnormality	Continue for 5 sec.	 Bypass inlet sensor (defective or disconnected)
F53	Main expansion valve overcurrent protection	4 times occurrence within 40 minutes	Main expansion valve
F54	Bypass expansion valve overcurrent protection	4 times occurrence within 40 minutes	Bypass expansion valve
F55	Electrical anode error	Continue for 60 sec.	Electric anodeElectric anode PCBIndoor PCB (main)
F56	Outdoor heat exchanger middle sensor abnormality	Continue for 5 sec.	Outdoor heat exchanger middle sensor (defective or disconnected)

Note: * This error code is not applicable for this system.

18.5 Self-Diagnosis Method

18.5.1 Connection Capability Rank Abnormality (H12)

Malfunction Decision Conditions:

During startup operation of cooling and heating, the capability rank of indoor checked by the outdoor is used to determine connection capability rank abnormality.


Malfunction Caused:

- 1 Wrong model interconnected.
- 2 Wrong indoor unit or outdoor unit PCB (main) used.
- 3 Faulty indoor unit or outdoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds.

Troubleshooting:



18.5.2 Compressor Tank Temperature Sensor Abnormality (H15)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the compressor tank temperature sensor are used to determine sensor error.


Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:



18.5.3 Zone 2 Water Pump Abnormality (H17)


Malfunction Decision Conditions:

During startup and operation of cooling and heating, the rotation speed detected by the IPM of water pump motor during water pump operation is used to determine abnormal water pump (feedback of rotation > 6,000rpm or < 300rpm).

Malfunction Caused:

- 1 Operation stop due to short circuit inside the water pump motor winding.
- 2 Operation stop due to breaking of wire inside the water pump motor.
- 3 Operation stop due to breaking of water pump lead wires.
- 4 Operation stop due to water pump motor IPM malfunction.
- 5 Operation error due to faulty indoor unit PCB (main).

Abnormality Judgment:



18.5.4 Water Pump Abnormality (H20)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the rotation speed detected by the IPM of water pump motor during water pump operation is used to determine abnormal water pump (feedback of rotation > 6,000rpm or < 300rpm).

Malfunction Caused:


- 1 Operation stop due to short circuit inside the water pump motor winding.
- 2 Operation stop due to breaking of wire inside the water pump motor.
- 3 Operation stop due to breaking of water pump lead wires.
- 4 Operation stop due to water pump motor IPM malfunction.
- 5 Operation error due to faulty outdoor unit PCB (main).
- 6 Operation error due to faulty outdoor unit PCB (sub).

Abnormality Judgment:

Continue for 10 seconds.

Troubleshooting:





18.5.5 Water Pressure Abnormality (H21)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the pressure detected by the water pressure sensor while the water pump is running is used to determine abnormalities in the water circuit (water pressure feedback > 5.0 bar or < 0.2 bar).

Malfunction Caused:

- 1 Water leak in system.
- 2 Faulty connector connection.
- 3 Faulty water Pressure sensor.
- 4 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 300 seconds.

For safety reason and to prevent component breakdown, **Troubleshooting:** Caution always switch off the power before remove and connect the component. Check the water system passage Is there any water leakage Is there any water leakage No Check the CN-DPS connector connection: **CN-DPS** WATER PRESSURE Turn OFF the power. (WHITE) SENSOR - Check the connector connection Figure 1 No Is the CN-DPS connector Poor contact connection normal? Correct connection Yes Check the Vdc from the outdoor unit PCB (main): Defective outdoor unit PCB - Disconnect Water pressure sensor Nο (main) from the outdoor unit PCB (main) Replace outdoor unit PCB terminal CN-DPS Turn ON the power. (main) Measure the Vdc as shown in Figure 1 (pin 1 and 2) Is the Vdc measurement 5Vdc? Yes - Defect in water pressure Replace the water pressure sensor.

18.5.6 Tank 2 Temperature Sensor Abnormality (H22)

Malfunction Decision Conditions:

When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





18.5.7 Refrigerant Liquid Temperature Sensor Abnormality (H23)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the refrigerant liquid temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





18.5.8 Service Valve Error (H27)

Malfunction Decision Conditions:

During cooling operation, when:-

- [a] Indoor refrigerant pipe temperature at compressor startup present indoor refrigerant pipe temperature < 2°C
- [b] Present high pressure high pressure at compressor startup < 5kg/cm²
- **Judgment only for first time cooling operation and not during pump down operation.

Malfunction Caused:


- 1 3 way valves closed.
- 2 Faulty high pressure sensor.
- 3 Faulty indoor refrigerant pipe temperature sensor
- 4 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 300 seconds.

Troubleshooting:






18.5.9 Abnormal Solar Sensor (H28)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty solar sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:




18.5.10 Abnormal Swimming Pool Sensor (H31)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty swimming pool sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:




18.5.11 Abnormal Buffer Tank Sensor (H36)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.


Abnormality Judgment:



18.5.12 Brand Code Not Matching (H38)

Malfunction Caused:

1 Indoor and outdoor brand code not match.



18.5.13 Compressor Low Pressure Protection (H42)

Malfunction Decision Conditions:


During operation of heating and after 5 minutes compressor ON, when outdoor pipe temperature below -40°C or above 37°C is detected by the outdoor pipe temperature sensor.

Malfunction Caused:

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 Faulty outdoor unit fan motor.
- 4 Refrigerant shortage (refrigerant leakage).
- 5 Clogged expansion valve or strainer.
- 6 Faulty outdoor pipe temperature sensor.
- 7 Faulty outdoor unit main PCB (main).

Troubleshooting:






18.5.14 Abnormal Zone 1 Sensor (H43)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:




18.5.15 Abnormal Zone 2 Sensor (H44)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:



18.5.16 Water Flow Switch Abnormality (H62)

Malfunction Decision Conditions:

During operation of cooling and heating, the water flow detected by the outdoor water flow switch is used to determine water flow error.

Malfunction Caused:


- 1 Faulty water pump.
- 2 Water leak in system.
- 3 Faulty connector connection.
- 4 Faulty water flow switch.
- 5 Faulty outdoor unit PCB (sub).

Abnormality Judgment:

Continue for 140 seconds (but no judgment for 30 seconds after water pump startup/restart).

Troubleshooting:





18.5.17 Outdoor High Pressure Abnormality (H64)

Malfunction Decision Conditions:

During operation of cooling and heating, when the outdoor high pressure sensor output signal is 0 Vdc or 5 Vdc.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 120 minutes.

Troubleshooting:





18.5.18 Deice Circulation Error (H65)

Malfunction Decision Conditions:

During startup and operation of deice (mode 2), the water flow (> 8 l/min) detected by the water flow switch is used to determine deice circulation error.

Malfunction Caused:


- 1 Water flow in air-to-water heatpump unit circuitry.
- 2 Faulty outdoor unit water flow switch.
- 3 Faulty outdoor unit water pump.
- 4 Faulty outdoor unit PCB (sub).
- 5 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds.

Troubleshooting:






18.5.19 Abnormal External Thermistor 1 (H67)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 1 sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:




18.5.20 Abnormal External Thermistor 2 (H68)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 2 sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:



18.5.21 External Heater OLP Abnormality (H70)

Malfunction Decision Conditions:

During operation of external heater, when no power supplies to external heater or OLP open circuit.

Malfunction Caused:


- 1 Faulty power supply connector connection.
- 2 Faulty connector connection.
- 3 Faulty external heater overload protector (OLP).
- 4 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 60 seconds.

Troubleshooting:





18.5.22 Tank Temperature Sensor Abnormality (H72)

Malfunction Decision Conditions:

When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).
- 4 Faulty outdoor unit PCB (sub).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





18.5.23 PCB Communication Error (H74)

Malfunction Decision Conditions:


When External PCB connection is select "YES" and no communication with External PCB micon for 10 seconds and above.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty indoor PCB.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

After 1 minute operation started.



18.5.24 Indoor-Control Panel Communication Abnormality (H76)

Malfunction Decision Conditions:


During standby and operation of cooling and heating, indoor-control panel error occur.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty control panel.
- 3 Faulty indoor unit PCB (main).
- 4 Faulty outdoor unit PCB (sub).

Troubleshooting:





18.5.25 Indoor/Outdoor Abnormal Communication (H90)

Malfunction Decision Conditions:

During operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

Malfunction Caused:


- 1 Faulty outdoor unit PCB (main).
- 2 Faulty outdoor unit PCB (sub).
- 3 Faulty indoor unit PCB (main).
- 4 Indoor-outdoor signal transmission error due to wrong wiring.
- 5 Indoor-outdoor signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- 6 Indoor-outdoor signal transmission error due to disturbed power supply waveform.

Abnormality Judgment:

Continue for 15 seconds after operation.

Troubleshooting:





18.5.26 Tank Booster Heater OLP Abnormality (H91)

Malfunction Decision Conditions:

During operation of tank booster heater, and tank booster heater OLP open circuit.

Malfunction Caused:

- Faulty connector connection.
- Faulty tank booster heater overload protector (OLP).
- Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 60 seconds.

Troubleshooting: always switch off the power before remove and connect the component. Caution Yes Does the abnormality happen during - Defect in indoor unit PCB (main). operation of tank booster heater? - Replace the indoor unit PCB (main). No Check the CN6 connector connection: No - Turn OFF the power. - Connector poor contact. - Correct the connection. - Check the connector connection. Is the CN6 connector connection normal? Yes Turn OFF the power and disconnect OLP lead wire. Yes Turn ON the power Replace the tank heater booster heater OLP and measure Vdc between CN6 connector. Is there 12Vdc? See Fig 1 CN₆ **OLP BOOSTER** No **HEATER** Replace the indoor unit main PCB ROOM TEMP. ZONE 1

For safety reason and to prevent component breakdown,

Fig 1

18.5.27 Unspecified Voltage between Indoor and Outdoor (H95)

Malfunction Decision Conditions:


The supply power is detected for its requirement by the indoor/outdoor transmission.

Malfunction Caused:

- 1 Insufficient power supply.
- 2 Faulty outdoor unit PCB (noise filter/main).

Troubleshooting:





18.5.28 Outdoor High Pressure Protection (H98 / F95)

Malfunction Decision Conditions:


During operation of cooling / heating, when pressure 3.2 MPa and above is detected by outdoor high pressure sensor.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 Dust accumulation in the outdoor unit heat exchanger.
- 5 Air short circuit at outdoor.
- 6 Faulty outdoor unit fan motor.
- 7 Clogged expansion valve or strainer.
- 8 Excessive refrigerant.
- 9 Faulty outdoor high pressure sensor.
- 10 Faulty outdoor unit PCB (main).


Troubleshooting:





Troubleshooting:





18.5.29 Indoor Freeze-up Protection (H99)

Malfunction Decision Conditions:


During anti-freezing control in cooling operation, when the refrigerant liquid temperature < 0°C.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 Clogged expansion valve or strainer.
- 5 Refrigerant shortage (refrigerant leakage).
- 6 Faulty indoor refrigerant liquid temperature sensor.
- 7 Faulty outdoor unit PCB (main).

Troubleshooting:





18.5.30 Outdoor High Pressure Switch Activate (F12)

Malfunction Decision Conditions:

During operation of cooling and heating, when pressure 3.9 MPa and above is detected by outdoor high pressure switch.

Malfunction Caused:


- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 Faulty water pump.
- 4 Insufficient water flow rate in system.
- 5 Water leak in system.
- 6 Clogged expansion valve or strainer.
- 7 Excessive refrigerant.
- 8 Faulty outdoor high pressure sensor and switch.
- 9 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 30 minutes.

Troubleshooting:





18.5.31 Compressor Rotation Failure (F14)

Yes

Malfunction Decision Conditions:

A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused:

- 1 Compressor terminal disconnect.
- 2 Faulty outdoor unit PCB (main).
- 3 Faulty compressor.

Abnormality Judgment:

Continue 4 times in 20 minutes.

For safety reason and to prevent component breakdown, **Troubleshooting:** always switch off the power before remove and connect the component. Check the U, V, and W connector connection: - Turn OFF the power. MS - Check the U, V, and W connector connection at outdoor unit PCB (main) and compressor terminal. Is the connector connection - Connector poor contact. normal? - Correct the connection. **♦** Yes Disconnect the harnesses U, V, and W from the compressor terminal. From the disconnected harnesses U, V, and W, connect them to the inverter checker. Turn ON the power and operate the system. Check the inverter checker 6 LEDs blinking condition. $\bigcirc\bigcirc$ (BLU) BLUE (RED) RED - IPM defective. No Is the blinking of the 6 LEDs in $\bigcirc\bigcirc$ Replace the outdoor unit PCB same sequence/condition? TRADE MARK 00 (main). COMP. TERMINAL

Replace the compressor.

Inverter checker

18.5.32 Outdoor Fan Motor (DC Motor) Mechanism Locked (F15)

Malfunction Decision Conditions:

The rotation speed detected by the Hall IC of the fan motor during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550 rpm or < 20 rpm).


Malfunction Caused:

- 1 Operation stop due to short circuit inside the fan motor winding.
- 2 Operation stop due to breaking of wire inside the fan motor.
- 3 Operation stop due to breaking of fan motor lead wires.
- 4 Operation stop due to fan motor Hall IC malfunction.
- 5 Operation error due to faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 2 times in 20 minutes.

Yes



Replace the outdoor unit PCB (main).

18.5.33 Input Over Current Detection (F16)

Malfunction Decision Conditions:

During operation of cooling and heating, when outdoor current above WH-WXG09ME5 31.0A & WH-WXG12ME5 31.0A is detected by the current transformer (CT) in the outdoor unit PCB.

Malfunction Caused:


- 1 Excessive refrigerant.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 3 times in 20 minutes.

Troubleshooting:





18.5.34 Compressor Overheating (F20)

Malfunction Decision Conditions:

During operation of cooling and heating, when temperature above 112°C is detected by the outdoor discharge pipe temperature sensor.

Malfunction Caused:


- Faulty outdoor discharge pipe temperature sensor.
- Refrigerant shortage (refrigerant leakage).
- Clogged expansion valve or strainer. 3
- Faulty outdoor unit PCB (main).
- Faulty compressor.

Abnormality Judgment:

Continue 4 times in 30 minutes.

Troubleshooting:





18.5.35 IPM Overheating (F22)

Malfunction Decision Conditions:

During operation of cooling and heating, when temperature 95°C is detected by the outdoor IPM temperature sensor.

Malfunction Caused:


- 1 Faulty outdoor unit fan motor.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 30 minutes.

Troubleshooting:





18.5.36 Output Over Current Detection (F23)

Normal resistance Abnormal resistance

Malfunction Decision Conditions:

During operation of cooling and heating, when outdoor DC current is above set value is detected by the IPM DC Peak sensing circuitry in the outdoor unit PCB (main).

For safety reason and to prevent component breakdown,

(-)


Malfunction Caused:

- Faulty outdoor unit PCB (main).
- Faulty compressor.

Abnormality Judgment:

Continue for 7 times.

Troubleshooting:



(+)

Several kohms to several Mohms

0 or ∝

18.5.37 Refrigeration Cycle Abnormality (F24)

Malfunction Decision Conditions:


- 1 During compressor running (heating / cooling) for more than 10 minutes except deice and test mode.
- 2 During heating, water outlet and water inlet difference is less than 3°C.
- 3 During cooling, water outlet and water inlet difference is less than 2°C.
- 4 During heating, high pressure < 0.16 MPa (23 Psi) for more than 10 minutes or during cooling, high pressure < 0.04 MPa (6 Psi) for more than 10 minutes or high pressure < 0.01 MPa (1 Psi) for more than 5 minutes.
- 5 During heating, discharge temperature saturation temperature of high pressure ≥ 65°C.
- 6 During cooling, discharge temperature saturation temperature of high pressure ≥ 70°C.

Malfunction Caused:

- 1 Refrigerant shortage (refrigerant leakage).
- 2 Faulty indoor water inlet, indoor water outlet, compressor discharge temp sensor or high pressure sensor.
- 3 Clogged expansion valve or strainer.
- 4 Faulty indoor or outdoor PCB (main).

Abnormality Judgment:

Continue 2 times in 30 minutes.



18.5.38 Four Way Valve Abnormality (F25)

Malfunction Decision Conditions:

- 1 During heating operation, when the refrigerant liquid temperature of thermostat ON indoor unit < 0°C.
- 2 During cooling operation, when the refrigerant liquid temperature of thermostat ON indoor unit > 45°C.

Malfunction Caused:


- 1 Faulty sensor.
- 2 Faulty connector connection.
- 3 Faulty outdoor unit PCB (noise filter/main).
- 4 Faulty four way valve.

Abnormality Judgment:

Continue 3 times in 40 minutes.

Troubleshooting:





18.5.39 Outdoor High Pressure Switch Abnormal (F27)

Malfunction Decision Conditions:

During compressor stop, and outdoor high pressure switch is remain opened.

Malfunction Caused:


- Faulty connector connection.
- 2 Faulty switch.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 1 minute.

Troubleshooting:





18.5.40 Outdoor Water Outlet Temperature Sensor 2 Abnormality (F30)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the water outlet temperature sensor 2 are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





18.5.41 Internal Thermostat Error [RC-1 or RC-2] (F32)

Malfunction Decision Conditions:


During startup and operation of cooling and heating, the temperatures detected by Internal thermostat in control panel are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty control panel.
- 3 Faulty Indoor unit PCB (main).
- 4 Faulty Outdoor unit PCB (sub).

Abnormality Judgment:

Continue for 5 seconds.



18.5.42 Outdoor Air Temperature Sensor Abnormality (F36)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





18.5.43 Indoor Water Inlet Temperature Sensor Abnormality (F37)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water inlet temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





18.5.44 Outdoor Discharge Pipe Temperature Sensor Abnormality (F40)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





18.5.45 Power Factor Correction (PFC) Abnormality (F41)

Malfunction Decision Conditions:

During operation of cooling and heating, when the PFC protection circuitry in the outdoor unit PCB (main) senses abnormal high DC voltage level.

Malfunction Caused:


- 1 Power supply surge.
- 2 Compressor windings not uniform.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 20 minutes.

Troubleshooting:





18.5.46 Outdoor Pipe Temperature Sensor Abnormality (F42)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





18.5.47 Outdoor Defrost Temperature Sensor Abnormality (F43)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor defrost temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





18.5.48 Indoor Water Outlet Temperature Sensor Abnormality (F45)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor are used to determine sensor errors.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:





18.5.49 Outdoor Current Transformer Open Circuit (F46)

Malfunction Decision Conditions:

A current transformer (CT) open circuit is detected by checking the compressor running frequency (≥ rated frequency) and CT detected input current (< 0.65 A) for continuously 20 seconds.

Malfunction Caused:


- 1 CT defective.
- 2 Faulty outdoor unit PCB (main).
- 3 Compressor defective (low compression).

Abnormality Judgment:

Continue 3 times in 20 minutes.

Troubleshooting:





18.5.50 Outdoor Evaporator Outlet Temperature Sensor Abnormality (F48)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the temperature detected by outdoor evaporator outlet sensor is used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection
- 2 Faulty sensor
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:

Continuous for 5 seconds

Troubleshooting:





18.5.51 Outdoor Bypass Outlet Temperature Sensor Abnormality (F49)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the temperature detected by outdoor bypass outlet sensor is used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection
- 2 Faulty sensor
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:

Continuous for 5 seconds

Troubleshooting:





18.5.52 Outdoor Water Inlet 2 Temperature Sensor Abnormality (F50)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water inlet 2 temperature sensor are used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds.

Troubleshooting:





18.5.53 Outdoor Economizer Outlet Temperature Sensor Abnormality (F51)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the temperature detected by outdoor economizer outlet sensor is used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continuous for 5 seconds.

Troubleshooting:





18.5.54 Outdoor Bypass Inlet Temperature Sensor Abnormality (F52)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the temperature detected by outdoor bypass inlet sensor is used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continuous for 5 seconds.

Troubleshooting:





18.5.55 Main Expansion Valve Overcurrent Protection (F53)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the determination is made based on whether or not an overcurrent flows through the main expansion valve coil.

Malfunction Caused:


- 1 Faulty connector connection
- 2 Faulty main expansion valve coil
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:

4 times occurrence in 40 minutes

Troubleshooting:





18.5.56 Bypass Expansion Valve Overcurrent Protection (F54)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the determination is made based on whether or not an overcurrent flows through the bypass expansion valve coil.

Malfunction Caused:


- 1 Faulty connector connection
- 2 Faulty bypass expansion valve coil
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:

4 times occurrence in 40 minutes

Troubleshooting:





18.5.57 Electrical Anode Error (F55)

Malfunction Decision Conditions:

If the indoor unit type is Control module, an error will occur due to a mismatch in settings.

Malfunction Caused:

1 The settings are incorrect.

Abnormality Judgment:

Continuous for 60 seconds

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.

Check the [Electrical anode] menu.

- -Turn on the power
- Check [Installer setup System setup Electrical anode] menu.
- Change setting to [No] from [Yes]

18.5.58 Outdoor Heat Exchanger Middle Temperature Sensor Abnormality (F56)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the temperature detected by outdoor heat exchanger middle sensor is used to determine sensor error.

Malfunction Caused:


- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continuous for 5 seconds.

Troubleshooting:





19. Disassembly and Assembly Instructions


MARNING

High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.

19.1 Indoor Unit


19.1.1 To Remove Front Cover

- 1. Remove 2 mounting screws located at the top of the enclosure
- Gently pull the upper section of the front cover towards you.
 (The front cover will stops once it han opened
- 3. Gently open the front cover.




19.1.2 To Remove Remote Controller


 Remove both left and right decoration panel from the front cover while gently pushing them from the behind.




2. Remove the 4 screws and take out the holder with remote controller.




3. Remove the body from the base.




4. Remove the cable between remote controller and Indoor Unit terminal.



19.1.3 To Remove RCCB




1. Remove the terminal cover screw. Then remove the terminal cover.



3. Remove the RCCB screw. Then remove the RCCB.

19.1.4 To Remove Electronic Controller Board

3. Relese the hooks and remove the electronic controller board.



- Disconnect all connectors and lead wires from the electronic controller board. (Refer indoor unit wiring diagram).
- 2. Remove 2 screws from electronic control board.





This symbol shows that this equipment uses a flammable refrigerant with safety A3 group per ISO 817. If the refrigerant is leaked, together with an external ignition source, there is a possibility of fire / explosion.


- If you are working on the R290 product, before starting work and when entering the service area, always turn ON
 the combustible gas leak detector to ensure there is no leakage.
- Keep all ignition sources away from the product. In particular, open flames, hot surfaces, electrical devices that are not free from electrical sources, static discharges.
- Ensure the servicing area is well ventilated.
- Ensure all the serving tools and equipment complied with ATEX (Atmosphere Explosible) standard.
- Ensure the product is service by certified and authorized serviceman.
- Ensure to always have the approved fire extinguisher during servicing.
- Use a warning placard to ensure that unauthorized personnel cannot enter the protective zone.


19.2 Outdoor Unit

19.2.1 Electronic Controller Removal Procedures









Note: During re-assemble the Main PCB, ensure to attach the O-ring properly to avoid gas leakage into the control board complete.

20. Technical Data

20.1 Operation Characteristics


20.1.1 WH-WXG09ME5


Heating Characteristics at Different Outdoor Air Temperature


Condition

Outdoor air temperature: 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature: 30°C Indoor water outlet temperature: 35°C










Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C










Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 19°C Indoor water outlet temperature : 14°C










Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 23°C Indoor water outlet temperature : 18°C








20.1.2 WH-WXG12ME5


Heating Characteristics at Different Outdoor Air Temperature


Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C










Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 12°C Indoor water outlet temperature : 7°C










Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 19°C Indoor water outlet temperature : 14°C










Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 23°C Indoor water outlet temperature : 18°C







20.2 Heating Capacity Table

20.2.1 WH-WXG09ME5

Rating Frequency

Water Out (°C)		25			35			45		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	
-25	7900	3500	15.5	8200	4200	18.6	7900	4800	21.3	
-20	7900	2940	13.0	8200	3340	14.8	7900	3990	17.7	
-15	9000	2740	12.2	9000	3300	14.6	9000	3970	17.6	
-7	9000	2260	10.0	9000	2610	11.6	9000	3350	14.9	
2	8800	1950	8.9	9000	2360	10.5	9000	2910	12.9	
7	9000	1240	6.1	9000	1720	7.6	9000	2300	10.2	
25	7200	860	4.6	9000	1080	5.4	9000	1550	7.0	

Water Out (°C)		55			65			75		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	
-25	7600	5700	25.3	-	-	-	-	-	-	
-20	7600	4760	21.1	7100	5300	23.5	-	-	-	
-15	9000	4480	20.0	9000	5270	23.4	8200	6500	28.8	
-7	9000	3830	17.0	9000	4680	20.8	9000	5900	26.2	
2	9000	3540	15.7	9000	4290	19.0	9000	5500	24.4	
7	9000	2780	12.3	9000	3460	16.1	8900	4980	22.1	
25	9000	2050	9.3	9000	2680	11.9	8400	3450	15.3	

Minimum Frequency

Water Out (°C)		25		35			45		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	5400	1980	9.2	5700	2490	11.2	5900	3060	13.7
-20	6300	2000	9.3	6300	2690	12.0	6700	3270	13.9
-15	5500	1560	7.2	5500	1900	8.8	5800	2350	10.5
-7	4900	1160	5.5	4500	1400	6.6	4200	1690	7.7
2	4500	920	4.5	4300	1080	5.2	4100	1310	7.1
7	5200	780	4.1	5000	980	4.8	4700	1250	6.0
25	5600	660	3.6	7300	810	4.2	7200	1170	5.8

Water Out (°C)		55		65			75		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	6000	3600	16.1	-	-	-	-	-	-
-20	7100	3850	17.1	7000	4660	20.7	-	-	-
-15	6200	3100	13.8	7400	4100	18.1	7800	5100	22.6
-7	4100	2170	9.6	6100	3080	13.6	5900	3810	17.0
2	3800	1630	7.5	6800	2950	13.1	6700	3750	16.6
7	4400	1520	7.1	7800	2900	12.9	7400	3700	16.4
25	7000	1460	6.9	8900	2660	11.8	8300	3430	15.2

20.2.2 WH-WXG12ME5

Rating Frequency

Water Out (°C)		25			35			45		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	
-25	10200	4900	21.7	10500	5550	24.6	9500	5750	25.5	
-20	11000	4250	18.9	11200	4750	21.1	10000	5000	22.2	
-15	12000	4270	18.9	12000	4560	20.4	11500	5420	24.0	
-7	11500	3680	16.3	12000	4000	17.7	12000	5020	22.3	
2	11500	2920	13.0	12000	3390	15.0	12000	4200	18.6	
7	12000	1930	8.7	12000	2370	10.4	12000	3130	13.9	
25	9800	1100	5.4	12000	1400	6.6	12000	2000	9.2	

Water Out (°C)		55			65			75		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	
-25	8650	5900	26.2	-	-	-	-	-	-	
-20	10000	5700	25.3	9100	5800	25.7	-	-	-	
-15	11000	5500	24.4	10000	5880	26.1	9000	6100	27.1	
-7	12000	5530	24.5	11000	6010	26.7	10000	6200	27.5	
2	12000	4950	22.0	12000	5940	26.4	10500	6200	27.5	
7	12000	3710	16.6	12000	4620	20.7	12000	6100	27.1	
25	12000	2600	11.5	12000	3260	14.5	12000	3920	17.5	

Minimum Frequency

Water Out (°C)		25		35			45		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	5400	1980	9.2	5700	2490	11.2	5900	3060	13.7
-20	6300	2000	9.3	6300	2690	12.0	6700	3270	14.5
-15	5500	1560	7.2	5500	1900	8.8	5800	2350	10.5
-7	4900	1160	5.5	4500	1400	6.6	4200	1690	7.7
2	4500	920	4.5	4300	1080	5.2	4100	1310	6.2
7	5200	780	4.1	5000	980	4.8	4700	1250	6.0
25	5600	660	3.6	7300	810	4.2	7200	1170	5.8

Water Out (°C)		55		65			75		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	6000	3600	16.1	-	-	-	-	-	-
-20	7100	3850	17.1	7000	4660	20.7	-	-	-
-15	6200	3100	13.8	7400	4100	18.1	7800	5100	22.6
-7	4100	2170	9.6	6100	3080	13.6	5900	3810	17.0
2	3800	1630	7.5	6800	2950	13.1	6700	3750	16.6
7	4400	1520	7.1	7800	2900	12.9	7400	3700	16.4
25	7000	1460	6.9	8900	2660	11.8	8300	3430	15.2

20.3 Cooling Capacity Table

20.3.1 WH-WXG09ME5


Water Out (°C)		7			14			18	
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
16	9800	2000	8.9	11000	2040	9.1	10800	1380	6.3
25	9300	2280	10.1	10500	2350	10.4	10200	1490	6.7
35	9000	2490	10.9	9800	2630	11.7	9000	1710	7.9
43	8400	2800	13.0	9000	2880	13.2	8600	2000	9.3

20.3.2 WH-WXG12ME5


Water Out (°C)		7			14			18	
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
16	12000	2500	11.2	13700	2600	11.5	12000	1730	7.9
25	12000	3050	13.5	13500	3120	13.8	12000	1880	8.6
35	12000	4210	18.7	13200	3250	16.1	12000	2800	12.4
43	9600	4350	19.0	10000	4350	19.0	12000	3600	16.0


21. Exploded View and Replacement Parts List

21.1 Indoor Unit



Note:






DTL B

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-CME5	REMARK
	1	CHASSIS	1	ACXD50-03101A	
	2	PACKING	4	ACXB81-00030	
	3	PACKING	1	ACXB81-00040	
	4	WASHER	1	H57094	
	5	MACHINE SCREW & WASHER ASSY	1	XYN4DC8FJ	
	6	BOX SHAPED PLATE	1	ACXD66-04380	
\triangle	7	ELECTRONIC CONTROLLER (MAIN)	1	ACXA74C13360	0
	8	MACHINE SCREW & WASHER ASSY	2	XTB3+8CFJ	
Ŵ	9	LEAD WIRE - COMPLETE (G01)	1	ACXA61C03470	
	10	SELF TAPPING SCREW	1	XTT4+8FFJ	
	11	BOX SHAPED PLATE	1	ACXD66-04390	
	12	BOX SHAPED PLATE	1	ACXD66-04400	
\triangle	13	CIRCUIT BREAKER	1	ACXA18-00011	0
	14	U-SHAPED PLATE	1	ACXD62-03010	
	15	SELF TAPPING SCREW	1	XTT4+12CFJ	
Ŵ	16	TERMINAL BOARD ASSY	1	A28K1064J	0
	17	SELF TAPPING SCREW	1	XTN4+20CFJ	
	18	U-SHAPED PLATE	1	ACXD62-02970	
	4	WASHER	1	H57094	
	5	MACHINE SCREW & WASHER ASSY	1	XYN4DC8FJ	
	19	HOLDER - P.S. CORD	1	H31103	
	20	SELF TAPPING SCREW	2	XTT4+16GFJ	
	21	HOLDER - P.S. CORD	1	H31042	
	15	SELF TAPPING SCREW	1	XTT4+12CFJ	
Ŵ	22	LEAD WIRE - COMPLETE (AC-N)	1	ACXA61C03380	
	23	LEAD WIRE - COMPLETE (CN-AC)	1	ACXA61C03390	
Ŵ	24	LEAD WIRE - COMPLETE (CN-DATA)	1	ACXA61C03460	
	25	SCREW	2	H551217	
	26	BOX SHAPED PLATE	1	ACXD66-04410	
Ŵ	27	TERMINAL BOARD ASSY	1	A28K1217	
	15	SELF TAPPING SCREW	3	XTT4+12CFJ	
Ŵ	28	TERMINAL BOARD ASSY	1	ACXA28K03110	
	17	SELF TAPPING SCREW	1	XTN4+20CFJ	
	21	HOLDER - P.S. CORD	2	H31042	
\triangle	30	LEAD WIRE - COMPLETE (WIRE1)	1	ACXA61C07890	
$\overline{\mathbb{A}}$	31	LEAD WIRE - COMPLETE (WIRE2)	1	ACXA61C03560	
\triangle	32	LEAD WIRE - COMPLETE (CN-TH1)	1	ACXA61C03490	
\triangle	33	LEAD WIRE - COMPLETE (CN-OLP1)	1	ACXA61C03500	
	34	BOX SHAPED PLATE	1	ACXD66-04420	
	35	A-PIECE	1	D77001	
	15	SELF TAPPING SCREW	1	XTT4+12CFJ	


SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-CME5	REMARK
	36	TERMINAL COVER	1	ACXH17-02080	
	15	SELF TAPPING SCREW	1	XTT4+12CFJ	
\triangle	37	REMOTE CONTROL SWITCH - COMPLETE	1	ACXA75C26382	0
	38	LEAD WIRE - COMPLETE (REMOTE CONTROL)	1	ACXA61C03510	
\triangle	39	LEAD WIRE - COMPLETE (CN-CNT2)	1	ACXA61C03520	
	40	BOX SHAPED PLATE (DECO)	1	ACXD66-03970	
	41	SELF TAPPING SCREW	2	XTB4+8CFJ	
	42	SELF TAPPING SCREW	4	XTB4+8FFJ	
	43	CABINET FRONT PLATE	1	ACXE06-05530A	
	44	WIRING DIAGRAM	1	ACXF29-01070	
	45	PARTICULAR PIECE	1	ACXD93-28250	
	46	RUBBER (DECO)	1	ACXB81-07400	
	47	DECORATION BASE ASSY (L)	1	ACXE35K03630	
	48	DECORATION BASE ASSY (R)	1	ACXE35K03640	
	49	SELF TAPPING SCREW	13	XTT4+8CFJ	
	50	SCREW	2	ACXH55-00120	
Λ	51	INSTALLATION INSTRUCTION COMPLETE	1	ACXF60C21270	
\triangle	52	MODEL LABEL	1	ACXF87-39530	
Δ	53	NAME PLATE	1	ACXF09-10240	
\triangle	54	NETWORK ADAPTOR / CZ-TAW1C	1	ACXA75C26830	0
	55	CORRUGATED CARDBOARD	1	ACXG57-13731	
	56	SHOCK ABSORBER	2	ACXG70-16800	
	57	INSTALLING HOLDER	1	ACXH36-01290	
	58	DUMMY COVER FOR REMOTE C	1	ACXE15-01170	


- All parts are supplied from PHVACCZ, Czech (Vendor Code: 00029407). "O" marked parts are recommended to be kept in stock.


21.2 Outdoor Unit





Note:



















DTL H



Note:


The above exploded view is for the purpose of parts disassembly and replacement.


The non-numbered parts are not kept as standard service parts.




The above exploded view is for the purpose of parts disassembly and replacement.

The non-numbered parts are not kept as standard service parts.







SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME5	WH-WXG12ME5	REMARK
	1	BASE PAN - COMPLETE	1	ACXD52C01871	←	
	2	BASE PAN ASSY	1	ACXD52K05580	←	
	3	CONVEX PIECE	2	ACXD75-00710	←	
	4	SCREW	2	H551040J	←	
	5	SCREW	4	H551049J	←	
	6	PACKING	4	B811017	←	
	7	ANTI - VIBRATION BUSHING	4	ACXH50-00480	←	
	8	FLAT PLATE ASSY	1	ACXD64K00080	←	
	9	NUT	4	H561049	←	
	10	PACKING	4	ACXB81-07660	←	
\triangle	11	COMPRESSOR	1	ACXB09-10080	←	0
	12	CONNECTING BAR ASSY	1	ACXE26K00011A	←	
	5	SCREW	4	H551049J	←	
	9	NUT	4	H561049	←	
\triangle	13	FIN & TUBE CONDENSER COMPLETE (U&L)	1	ACXB32C29732X	←	0
	14	MANIFOLD TUBE ASSY	1	ACXT07K11430	←	
	15	MULTIBENT TUBE	1	ACXT32-07000	←	
	16	SCREW	2	ACXH55-07140	←	
	17	SOUND - PROOF BOARD	1	ACXH15-04440	←	
	18	SOUND PROOF MATERIAL	1	ACXG30-14870	←	
	19	PACKING	1	ACXB81-00030	←	
	20	CAP	1	H521180	←	
	21	EPT SEAL	1	ACXD3A15-440	←	
	22	POLY - E. FOAM	1	ACXE5A45-80	←	
	16	SCREW	3	ACXH55-07140	←	
\triangle	23	FIXED INDUCTORS	1	G0C202K00003	←	
	16	SCREW	4	ACXH55-07140	←	
	24	4-WAYS VALVE COMPLETE	1	ACXB00C03632	←	0
	25	4-WAYS VALVE	1	ACXB00-01530	←	0
\triangle	26	PRESSURE SWITCH	1	ACXA10-00710	←	0
	27	STRAIGHT TUBE THERMISTOR HOLDER	1	T102044	←	
	28	TUBE ASSY Electromagnetic 2-way valve	1	ACXT00-87560	←	
	29	2-WAYS VALVE	1	ACXB02-04110	←	0
	30	STRAINER	1	B111032	←	
	27	STRAIGHT TUBE THERMISTOR HOLDER	1	T102044	←	
\triangle	31	HIGH PRESSURE SENSOR	1	ACXA50-06870	←	0
	32	TUBE ASSY [2-WAY VALVE BL]	1	ACXT00-87530CZ	←	
	33	2-WAYS VALVE	1	ACXB02-03960	←	0
	34	RECEIVER	1	ACXB14-00880	←	
	27	STRAIGHT TUBE THERMISTOR HOLDER	1	T102044	←	
	35	TUBE ASSY [SUB EXPANSION]	1	ACXT00-87590	←	
	36	EXPANSION VALVE [SUB]	1	ACXB05-01580	←	0

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME5	WH-WXG12ME5	REMARK
	29	2-WAYS VALVE	1	ACXB02-04110	←	0
	30	STRAINER	1	B111032	←	
	37	TUBE HEAT EXCHANGER	1	ACXB36-00130	←	
	38	TUBE ASSY [MAIN EXPANSION]	1	ACXT00-87600	←	
	39	EXPANSION VALVE [MAIN]	1	ACXB05-01570	←	0
	30	STRAINER	2	B111032	←	
	27	STRAIGHT TUBE THERMISTOR HOLDER	1	T102044	←	
	40	TUBE ASSY	1	ACXT00-87610	←	
	27	STRAIGHT TUBE THERMISTOR HOLDER	1	T102044	←	
	41	SOUND PROOF MATERIAL - COMP. BODY	1	ACXG30-14830	←	
	42	SOUND PROOF MATERIAL - COMP. TOP	1	ACXG30-14840	←	
	43	SOUND - PROOF BOARD	1	ACXH15K01171	←	
	44	PARTICULAR PLATE	1	ACXD90-30940	←	
	45	FOAMED POLYSTYRENE	1	ACXG07-08650	←	
	46	HOT WATER COIL - COMPLETE [SWEP]	1	ACXB90C02141	←	
	47	PARTICULAR PLATE	2	ACXD90-30950	←	
	48	ADH. POLY - E. FOAM	1	ACXG12-42390	←	
	49	BUSHING	2	ACXH51-01760	←	
	16	SCREW	4	ACXH55-07140	←	
	50	POLY - E. FOAM	1	ACXE15A25-60	←	
	51	HOLDER - COUPLING	1	ACXH35-02360	←	
	52	TUBE CONNECTER	2	ACXT29-01030	←	
	5	SCREW	4	H551049J	←	
	53	PLUG	2	B821027	←	0
\triangle	54	PACKING	2	ACXB81-06770	←	
À	55	PACKING	2	ACXB81-06910	←	
	16	SCREW	2	ACXH55-07140	←	
	56	FILTER COMPLETE	1	ACXB51C00170	←	
	57	RETAINING RING (14-23)	1	H581038	←	
\triangle	55	PACKING	1	ACXB81-06910	←	
	58	RETAINING RING (25.4)	1	ACXH58-00370	←	
Ŵ	59	PUMP	1	ACXB53-01000	←	0
	60	PARTICULAR PLATE	1	ACXD90-30970	←	
	61	SELF TAPPING SCREW	2	XTT4+16CFJ	←	
	16	SCREW	2	ACXH55-07140	←	
	62	U-SHAPED TUBE - COMPLETE	1	ACXT23C00180	←	
\triangle	55	PACKING	1	ACXB81-06910	←	
	58	RETAINING RING (25.4)	1	ACXH58-00370	←	
\triangle	55	PACKING	2	ACXB81-06910	←	
	58	RETAINING RING (25.4)	2	ACXH58-00370	←	
	63	L-SHAPED TUBE	1	ACXT20-15030	←	
\triangle	55	PACKING	2	ACXB81-06910	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME5	WH-WXG12ME5	REMARK
	58	RETAINING RING (25.4)	2	ACXH58-00370	←	
\triangle	64	FILTER COMPLETE	1	ACXB51C00160	←	
	65	TUBE ASSY COMPLETE INHOUSE	1	ACXT00C49260	←	
\triangle	55	PACKING	2	ACXB81-06910	←	
\triangle	66	PACKING	1	ACXB81-06820	←	
	58	RETAINING RING (25.4)	2	ACXH58-00370	←	
\triangle	67	FLOW SENSOR	1	ACXB62-00912	←	0
	68	LEAD WIRE - COMPLETE (FLOW SENSOR)	1	ACXA61C04000	←	
	69	U-SHAPED TUBE - COMPLETE	1	ACXT23C00170	←	
\triangle	55	PACKING	1	ACXB81-06910	←	
	58	RETAINING RING (25.4)	1	ACXH58-00370	←	
Ŵ	55	PACKING	1	ACXB81-06910	←	
	58	RETAINING RING (25.4)	3	ACXH58-00370	←	
	70	PARTICULAR PLATE	1	ACXD90-31030	←	
	16	SCREW	1	ACXH55-07140	←	
\triangle	71	VALVE BODY Pressure relief valve	1	ACXB62-01320	←	0
	57	RETAINING RING (14-23)	1	H581038	←	
	72	TUBE ASSY	1	ACXT00-85820	←	
	73	STRAIGHT TUBE	1	ACXT10-21230	←	
A	66	PACKING	1	ACXB81-06820	←	
	57	RETAINING RING (14-23)	1	H581038	←	
Ŵ	74	SENSOR - COMPLETE (CN-DPS)	1	ACXA50C20090	←	0
\triangle	75	PACKING	1	ACXB81-06790	←	
	76	SCREW	2	H55406J	←	
\triangle	77	SENSOR - COMPLETE (WATER OUTLET SENSOR2 & WATER INLET TEMP - CN-TH3)	1	ACXA50C20630	←	0
\triangle	78	PACKING	2	ACXB81-06780	←	
	79	SELF TAPPING SCREW	2	XTT4+8CFJ	←	
	16	SCREW	2	ACXH55-07140	←	
	80	PARTICULAR PLATE	1	ACXD90-30930	←	
\triangle	81	TERMINAL BOARD ASSY	2	ACXA28K02540	←	0
	82	SELF TAPPING SCREW	2	XTN4+16CFJ	←	
	50	POLY - E. FOAM	1	ACXE15A25-60	←	
	83	INDICATION LABEL	1	ACXF71-34381	←	
	84	LEAD WIRE - COMPLETE_SIGNAL	1	ACXA61C00650	←	
	16	SCREW	2	ACXH55-07140	←	
	85	PARTICULAR PLATE	1	ACXD90-30960	←	
	16	SCREW	1	ACXH55-07140	←	
	86	EPT SEAL	1	ACXD3A35-250	←	
	87	ADH. POLY - E. FOAM	1	ACXG12-42490	←	
	88	PARTICULAR PLATE	1	ACXD90-30980	←	
	16	SCREW	2	ACXH55-07140	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME5	WH-WXG12ME5	REMARK
	89	SCREW	2	H55440J	←	
	90	C-PIECE	2	ACXD79-00390	←	
	76	SCREW	4	H55406J	←	
	91	POLY - E. FOAM	1	ACXE25A25-55	←	
	92	RUBBER	1	G251015	←	
Ŵ	93	V-COIL COMPLETE - 4-WAY VALVE	1	ACXA43C08090	←	0
	94	SCREW	1	H55082J	←	
\triangle	95	V-COIL COMPLETE [MAIN EXP. VALVE - CN-EV]	1	ACXA43C08100	←	0
\triangle	96	V-COIL COMPLETE [BYPASS EXP. VALVE - CN-INJ]	1	ACXA43C08110	←	0
$\overline{\mathbb{V}}$	97	V-COIL COMPLETE [DIS/INLET BYPASS 2WAY - VALVE CN-V2]	1	ACXA43C08120	←	0
\triangle	98	V-COIL COMPLETE [CN-INJV2]	1	ACXA43C08130	←	0
	94	SCREW	2	H55082J	←	
	99	RUBBER	3	ACXG25-02300	←	
	92	RUBBER	2	G251015	←	
	100	RUBBER	1	G251021	←	
Ŵ	101	SENSOR - COMPLETE_TH1_WHITE1	1	ACXA50C20620	←	0
\triangle	102	SENSOR - COMPLETE_TH1-RED	1	ACXA50C19550	←	0
\triangle	103	SENSOR - COMPLETE_TH1_WHITE2	1	ACXA50C19710	←	0
\triangle	104	SENSOR - COMPLETE_TH2/SENSOR_YEL	1	ACXA50C19570	←	0
\triangle	105	SENSOR - COMPLETE_TH2/SENSOR_RED	1	ACXA50C19560	←	0
\triangle	106	SENSOR - COMPLETE_TH3/SENSOR_YEL	1	ACXA50C19720	←	0
	107	PLATE SPRING	8	H711010	←	
	108	FAN MOTOR BRACKET	2	ACXD54-05180	←	
	4	SCREW M5	2	H551040J	←	
À	109	FAN MOTOR_1	1	L6CBYYYL0475	←	0
\triangle	110	FAN MOTOR_2	1	L6CBYYYL0476	←	0
	111	SCREW	8	H551455	←	
	112	FAN ASSY	2	ACXH03K01200	←	0
	113	WASHER	2	H571075A	←	
	114	NUT	2	H561112A	←	
	115	CONTROL BOARD ASSY	1	ACXH10K03460A	←	
\wedge	116	ELECTRONIC CONTROLLER - COMPLETE	1	ACXA74C13130	ACXA74C13140	0
	117	PACKING	1	ACXB81-07211	←	
	118	SCREW	7	H551198	←	
\triangle	119	LEAD WIRE - COMPLETE [COMPRESSOR U/V/W]	1	ACXA61C03870	←	
Ŵ	120	LEAD WIRE - COMPLETE_RE1/2	1	ACXA61C03880	←	
	121	CONTROL BOARD	1	ACXH10-10540	←	
\triangle	122	CIRCUIT BREAKER	1	ACXA18-00011	←	
	123	U-SHAPED PIECE	1	ACXD90-32060	←	
	124	SELF TAPPING SCREW	2	XTT4+10CFJ	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME5	WH-WXG12ME5	REMARK
	125	WASHER	1	H571044	←	
	126	MACHINE SCREW & WASHER ASS'Y	2	XYN5DC10FJ	←	
<u> </u>	127	TERMINAL BOARD ASSY	1	A28K1294	←	0
	128	SELF TAPPING SCREW	1	XTN4+20CFJ	←	
	129	HOLDER - P.S. CORD	1	ACXH31-01480	←	
	130	HOLDER - P.S. CORD	1	ACXH31-01620	←	
	131	HOLDER - P.S. CORD	1	ACXH31-01630	←	
	132	BOX SHAPED PLATE - COMPLETE	1	ACXD66C00760	←	
	133	PACKING	1	ACXB81-07670	←	
	134	SELF TAPPING SCREW	6	XTT4+12CFJ	←	
<u> </u>	135	ELECTRONIC CONTROLLER (SUB)	1	ACXA74C07640	←	0
	136	CONTROL BOARD	1	ACXH10-10570	←	
	137	SCREW	4	XTB3+8CFJ	←	
A	138	LEAD WIRE - COMPLETE_CN-PWR	1	ACXA61C07530	←	
	139	LEAD WIRE - COMPLETE_CN-PUMP_CTR	1	ACXA61C00950	←	
	140	LEAD WIRE - COMPLETE_CN-COM	1	ACXA61C06400	←	
A	141	LEAD WIRE - COMPLETE_FG103	1	ACXA61C04260	←	
À	142	LEAD WIRE - COMPLETE_FG101	1	ACXA61C04270	←	
	124	SELF TAPPING SCREW	2	XTT4+10CFJ	←	
A	143	ELECTRONIC CONTROLLER (NF)	1	ACXA74C15130	←	0
	144	CONTROL BOARD	1	ACXH10-10560	←	
	137	SCREW	6	XTB3+8CFJ	←	
	124	SELF TAPPING SCREW	2	XTT4+10CFJ	←	
<u> </u>	145	LEAD WIRE - COMPLETE_ACN/ACL-IN	1	ACXA61C03830	←	
	146	LEAD WIRE - COMPLETE_CN-V3	1	ACXA61C06430	←	
\triangle	147	LEAD WIRE - COMPLETE_CN-CONTACT	1	ACXA61C00940	←	
\triangle	148	LEAD WIRE - COMPLETE_NF PCB_Earth L/W (left)	1	ACXA61C07460	←	
\triangle	149	LEAD WIRE - COMPLETE_NF PCB_Earth L/W (center)	1	ACXA61C04300	←	
Ţ	150	LEAD WIRE - COMPLETE_NF PCB_Earth L/W (right)	1	ACXA61C04310	←	
<u> </u>	151	CAUTION LABEL (WARNING)	1	F762691	←	
	152	PACKING	1	ACXB81-07680	←	
	118	SCREW	8	H551198	←	
	153	TOOTHED LOCK WASHER	1	XWC5BV	←	
	5	SCREW	1	H551049J	←	
	118	SCREW	4	H551198	←	
\triangle	154	LEAD WIRE - COMPLETE_ACN/ACL - IN/OUT	1	ACXA61C03860	←	
\triangle	155	LEAD WIRE - COMPLETE_	1	ACXA61C04290	←	
\triangle	156	LEAD WIRE - COMPLETE_	1	ACXA61C06750	←	
	157	CONTROL BOARD COVER - COMPLETE	1	ACXH13C06720	←	
	158	EPT SEAL	1	ACXD3A10-265	←	
	159	PACKING	1	ACXB81-07690	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME5	WH-WXG12ME5	REMARK
	118	SCREW	10	H551198	←	
	160	HOLDER - P.S. CORD	1	ACXH31-01680	←	
	161	SCREW	3	ACXH55-00120	←	
	162	CONTROL BOARD COVER - COMPLETE	1	ACXH13C06650	←	
	163	PACKING	1	ACXB81-07650	←	
	164	SCREW PEDESTAL	4	XYN4+F10FJ	←	
	165	HOLDER - SENSOR	1	ACXH32-01480	←	
	166	SOUND PROOF MATERIAL	1	ACXG30-14880	←	
	167	CABINET SIDE PLATE - COMPLETE (R)	1	ACXE04C09050	←	0
	168	HANDLE	1	ACXE16-00230G	←	
	169	EPT SEAL	1	ACXD3A10-92	←	
	170	SCREW	1	ACXH55-07980	←	
	171	CAP	6	ACXH52-04230G	←	
	170	SCREW	15	ACXH55-07980	←	
	16	SCREW	2	ACXH55-07140	←	
	172	CABINET FRONT PLATE (L)	1	ACXE06-05620	←	0
	168	HANDLE	1	ACXE16-00230G	←	
	169	EPT SEAL	1	ACXD3A10-92	←	
	170	SCREW	1	ACXH55-07980	←	
	170	SCREW	7	ACXH55-07980	←	
	16	SCREW	5	ACXH55-07140	←	
	173	CABINET SIDE PLATE (L)	1	ACXE04-13910	←	0
	174	PARTICULAR PLATE	1	ACXD90-29140	←	
	175	SCREW	3	ACXH55-07740	←	
	176	CABINET TOP PLATE COMPLETE	1	ACXE03C02510	←	0
	177	EPT SEAL	1	ACXD5A15-200	←	
	178	EPT SEAL	1	ACXD5A30-60	←	
	170	SCREW	9	ACXH55-07980	←	
	179	CABINET FRONT PLATE (R)	1	ACXE06-05630	←	0
	180	PARTICULAR PIECE	4	ACXD93-25230	←	
	181	NUT	4	ACXH56-00120	←	
	168	HANDLE	1	ACXE16-00230G	←	
	169	EPT SEAL	1	ACXD3A10-92	←	
	170	SCREW	1	ACXH55-07980	←	
	175	SCREW	8	ACXH55-07740	←	
	182	SOUND PROOF MATERIAL	1	ACXG30-14860	←	
	170	SCREW	9	ACXH55-07980	←	
	183	ACCESSORY - COMPLETE	1	ACXH82C29860	←	
	184	CAP (OR PART ACXH52-01980)	3	ACXH52-04310	←	
	185	DRAIN NOZZLE	1	ACXH41-00700	←	0
	186	ACCESSORY - COMPLETE (SCREW)	1	ACXH82C29870	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME5	WH-WXG12ME5	REMARK
	118	SCREW	8	H551198	←	
	187	ACCESSORY - COMPLETE	1	ACXH82C29920	←	
	188	CAP	15	ACXH52-04470	←	
Ŵ	189	WIRING DIAGRAM (CU)	1	ACXF22-12110	←	
Ŵ	190	INDICATION LABEL (FLAME)	1	F746943	←	
Ŵ	191	NAME PLATE (CU)	1	ACXF02-99470	ACXF02-99480	
	192	INDICATION LABEL [WATER OUTLET]	1	ACXF71-25701	←	
	193	INDICATION LABEL [WATER INLET]	1	ACXF71-25711	←	
	194	INDICATION LABEL	1	ACXF71-34832	←	
À	195	OPERATING INSTRUCTION - COMPLETE	1	ACXF55C31810	←	
\triangle	196	INSTALLATION INSTRUCTION COMPLETE	1	ACXF60C20621	←	
Ŵ	197	MODEL LABEL	2	ACXF87-47260	ACXF87-47270	
Ŵ	198	DISCHARGE GRILLE - COMPLETE L [TOP]	1	ACXE20C09371	←	0
\triangle	199	DISCHARGE GRILLE COMPLETE L [BOTTOM]	1	ACXE20C09380	←	0
\triangle	200	DISCHARGE GRILLE COMPLETE R [TOP]	1	ACXE20C09390	←	0
\triangle	201	DISCHARGE GRILLE COMPLETE R [BOTTOM]	1	ACXE20C09400	←	0
\triangle	202	BAG	1	ACXG86-06800	←	
	203	BASE BOARD - COMPLETE	1	ACXG62C03020	←	
	204	SHOCK ABSORBER [MIDDLE LEFT]	1	ACXG70-16301	←	
	205	SHOCK ABSORBER [MIDDLE]	1	ACXG70-16310	←	
	206	SHOCK ABSORBER [MIDDLE RIGHT]	1	ACXG70-16321	←	
	207	SHOCK ABSORBER [UPPER LEFT]	1	ACXG70-15320	←	
	208	SHOCK ABSORBER [UPPER RIGHT]	1	ACXG70-15330	←	
	209	CORRUGATED CARDBOARD	2	ACXG57-13711	←	
\triangle	210	C.C. CASE	1	ACXG50-64401	←	

- All parts are supplied from PHVACCZ, Czech (Vendor Code: 00029407).
- "O" marked parts are recommended to be kept in stock.